

## USBFS Bootloader Datasheet BootLdrUSBFS V 3.00

Copyright © 2010-2015 Cypress Semiconductor Corporation. All Rights Reserved.

Resources	PSoC® Blocks			API Memory (Bytes)		Pins (per External I/O)
	Digital	Analog CT	Analog SC	Flash	RAM	
CY7C64215, CY8C24794, CY8C24894-24LTXI, CY8C24994, CY8CLED04, CY8CTMA120-100BVXI, CY8CTMA120-56LFXI, CY8CTMA120-56LTXI, CY8CTMG120-56LFXI, CY8CTMG120-56LTXI, CY8CTST120, CYRF89235, CY8C24493, CY7C69xxx						
HID support	0	0	0	5 871	76	2
Without HID support	0	0	0	5 300	49	2
USB-UART support	0	0	0	6 380	65	2
CY7C643xx, CY8C20396/396A/496/496A-24LQXI, CY8C20646/646A/666/666A-24LTXI, CY8C20xx6AS, CY8C20XX6L, CY8CTMG200-48LTXI, CY8CTMG201-48LTXI, CY8CTMG200A-48LTXI, CY8CTMG201A-48LTXI, CY8CTST200-48LTXI, CY8CTST200A-48LTXI, CYONS2000, CYONS2100, CYONS2110, CYONS2010, CYONSFN2162-LBXC, CYONSTB2010-LBXC						
HID support	0	0	0	6 024	84	2
Without HID support	0	0	0	5 450	56	2

**Note** Expect an expansion of Flash and RAM when adding additional interfaces, HID classes, and other USB extensions. When the bootloader is in actual operation, it uses a large amount of RAM to download program data but frees it upon exit. Since operation of the bootloader precludes application operation, this RAM requirement is essentially invisible. ROM/Flash usage includes a complete USB interface. Additional code used for the bootloader function is only 2 kilobytes above the normal requirement of about 1.9 kilobytes of code used by USB itself.

## Features and Overview


- Flexible memory map
- Device reprogramming without engineering tools
- Product resident reprogrammability
- Communication interface integrated to minimize code overhead
- Field deployment of firmware upgrades
- USB Full Speed device interface driver
- Support for interrupt and control transfer types
- Setup wizard for easy and accurate descriptor generation
- Runtime support for descriptor set selection
- Optional USB string descriptors
- Optional USB HID class support
- Optional USB-UART (CDC) class support

The USB Bootloader User Module implements a bootloader that can reprogram the PSoC device over the USB interface. The PSoC device already gives an in-system serial programming interface (ISSP) that allows downloading new code into the device. However, the bootloader allows a code update to occur through an industry standard communication interface, such as USB. This user module can be useful for any device that has to be reprogrammed in the field. The bootloading information can be sent through a Cypress USB Bootloader Host interface.

The USB bootloader supports a fully functional device reprogramming ability with built in error detection and an industry standard communication interface.

Multiple USB device descriptors are coresident in the system to allow commanding a running device to self reconfigure and reprogram. Core USB functions are maintained during the reconfiguration to support host communication, while program data is being transferred and stored. At the end of the reconfiguration process the device resets itself, verifies the new program, and automatically executes it.

Figure 1. USBFS Bootloader Block Diagram



## Quick Start

1. Review this user module datasheet. A successful implementation of a bootloader project requires an understanding of this information.
2. Add the user module to a project.
3. Place the user module, selecting either a HID, NON-HID, or USB-UART(CDC) class application.
4. Right-click on the user module icon. Select **Boot Loader Tools**. Select **Get Files**. When this step is completed, the boot.tpl, custom.lkp, HTLinkOpts.lkp, and flashsecurity.example files must be in the project root directory.

- If HID or NON-HID class application is selected in step 3:

Right-click on the user module icon. Select **Device: Application USB Setup Wizard...** Verify that there is at least one string in the **Strings** area. At least one string must be present by default, if not, add a one character string.

For NON-HID application, skip the following setup and press **OK**.

- Click the **Import HID Report Template** operation.
- Select the 3 button mouse template.
- Click the **Apply** operation on the right side of the template.
- Edit the Interface Class: select HID Class in the Interface Attributes properties.
- Edit the HID class descriptor: select the 3 button mouse for the HID Report field.
- Click **OK** to save the USB descriptor information.

- If USB-UART application is selected in step 3:

Right click on the user module icon. Select **Device: Application USB Setup Wizard...** Configure the CDC properties and click **OK**.

5. Right-click on the user module icon. Select **Device: BootLoader USB Setup Wizard...** It is not necessary to make any modifications. Select **OK**.
6. Generate source code and compile the project.
7. Review the output file *<project>.mp* and *<project>.hex* to see how the project is built.
8. After creating a project that compiles without errors, go to the Sample Firmware Code section. Modify and adapt the code given in the sample.

## Functional Description

The BootLdrUSBFSe User Module gives:

- A USB full speed Chapter 9 compliant device framework.
- A low level driver for the control endpoint that decodes and dispatches requests from the USB host.
- A Setup Wizard to enable easy USB descriptor construction.

You have the option of constructing an HID based device, a generic USB Device or USB-UART device. Make your choice when you place the BootLdrUSBFSe User Module. To change your choice after initial selection, delete the existing instance of the BootLdrUSBFSe User Module and then add a new instance.

The bootloader portion of the user module gives a method to organize the memory map and major code functional blocks into areas that are compatible with device reprogramming. The memory organization of the project is considerably different from that of a conventional PSoC Designer™ project. Modifications to the memory map are necessary to meet the minimum device functionality requirements while the device application is being reprogrammed. Effectively, a project incorporating a bootloader contains two independent programs supporting different functions. A map of the memory is shown in Figure 2.


After a project incorporating a bootloader is deployed, the memory locations highlighted in gray are never reprogrammed. The application start address may be altered in the parameters window.

In addition to the parameters that are adjusted within the user module, two other important features are given. A built in set of tools can be accessed by right-clicking on the bootloader icon in the device manager

view. Additionally, a host application (including source code) is given along with instructions on how to set it up and use it on a system to demonstrate bootloader capability.

Further information about USB, including specifications, resources examples, and forums regarding use of USB are available at [www.usb.org](http://www.usb.org).

Figure 2. USBFS Bootloader Memory Organization



## Theory of Operation

Creating a project with a bootloader requires several nonstandard modifications to the PSoC Designer standard model. To facilitate this, the Bootloader User Module gives customized files and specialized tools to assist you in bootloader project development. The special tools are accessed by switching to the Device Editor view and right clicking the BootLdrUSBFSe User Module icon. In addition to the tools and files given as part of the user module, a host application example is also given with the user module installation that can demonstrate basic capability of the bootloader. This PC based application and source code for Microsoft Visual Studio® 2005 is contained in a .zip file in the installation directory of PSoC Programmer 3.

*[Install path]\Cypress\Programmer\3.xx\Bootloaders\BootLdrUSBFS\Bootloader\_Host\_PSoC1\...*

Using this application requires installation and limited customization of a generic USB driver capable of supporting the host demonstration application. This file is supplied as part of the installation and may be registered upon initial operation of a bootloader device. Use windows manual installation method to specify the location of the driver contained in the "\USB driver" directory of the location specified earlier.

The included driver.inf file must be modified to correctly specify the VID and PID of your chosen bootloader device. Note that this change must be made in two locations within the driver.inf file: one location is near the top of the file and the second is near the bottom.

## USBFS Bootloader Memory Organization

PSoC Designer uses standardized files, built in data about the part family, and attributes of specific devices to create compilable projects and correct API definitions. A project with a bootloader requires a memory map that is considerably different from that of a standard PSoC Designer project. Selection of the memory areas represents a core design decision that is maintained throughout the life of the design. A project without the requirements of a bootloader simply allows the compiler and linker to allocate RAM and ROM. However, a bootloader must group RAM and ROM in specific areas so that the program does not crash while a new application is being loaded.

In the memory layout shown in Figure 2, there are six key areas of ROM that are managed:

- The first area is the first 128 bytes of ROM. This area contains critical interrupt vectors and restart vectors. Since it is nearly impossible to control read access to this area by any operating device, they are never erased and reprogrammed. The first 128 bytes of ROM must not be modified and cannot be placed in any other location.
- The second area is the relocatable interrupt table. This table may consist of one or two blocks depending on the architecture of the device. This area contains interrupt and general purpose vectors to give a jump table for interrupts or code entries that may be altered when a new application is loaded using the bootloader. For example, this area contains the application start address. The bootloader can use this address to start the new application after the checksum is validated at power up. After the application and bootloader is deployed this area may be rewritten, but its location must not be modified. The characteristics of this area are similar to the checksum area described later in this section.
- The third area of ROM defined is the checksum area. This area contains important data that the bootloader software uses to download and verify the foreground application. The checksum area contains the start address and size in blocks of the foreground application. The first two bytes of the checksum block are a checksum of the checksum block itself, and the last two bytes are the checksum of the runtime application. The structure of the checksum block contains space for you to define your own data, in addition to that used by the bootloader. This structure is exposed as a C-structure definition, and may be modified as long as data used by the bootloader utility is not changed or repositioned within the block.
- The fourth of memory to be defined is the area containing the bootloader code itself. After the project or device containing the bootloader is deployed, this area is not reprogrammable and cannot be field upgraded.
- The fifth area is reserved for customer's data. This may contain configuration data that must persist through an upgrade via bootload. This area is optional.
- The sixth memory area is the application area. The application area contains application image. The starting address of this area is adjustable. The "Application\_Start\_Block" parameter (in properties window) allows users to set the application starting address accordingly. This area should occupy all remaining memory.

If your application has some code that must be always operational, including during a bootload process, the design of the Bootloader User Module can allow sufficient customization to accommodate this. This is accomplished by adding the code to the bootloader ROM area using the assembler AREA directive. Any RAM used by your code during the bootload process must be added to the RAM area defined for the bootloader.

## *Definition of Memory Areas in the User Module Parameters*

The “Application\_Start\_Block” parameter of the BootLdrUSBFSe User Module enables you to customize where major program elements are placed in ROM. The defaults in the user module give a working initial setup. Use these settings until a complete project is successfully compiled. After compiling a project, you can look at the program memory map and .hex output file to determine how to optimize your program structure. If you reconfigure the parameters and accidentally create memory area conflicts, it may be difficult to determine the correct locations without a valid memory map to look at.

## **Bootloader Utility**

The Bootloader User Module gives a complete utility that coexists with your foreground application. When the device is started or reset, the bootloader utility is always invoked. Once invoked at system startup the bootloader validates the foreground application by calculating a checksum on the foreground application ROM area. The calculated checksum is compared to the one stored in the checksum block (which is created with the application). If the two checksums are equal, the bootloader utility allows the foreground application to execute. If the two checksums are not equal, the bootloader enters a wait loop and waits for a host application to download a valid application. It also enables its own USB subsystem to allow the host to transmit data. When the host system observes this interface is enabled, it may choose to execute its own set of applications. Although a default USB descriptor is given that runs successfully with the examples given, you may choose to alter any of the parameters on the host or PSoC device. Source code for VisualStudio 2005 is included for the host application. An example application and source code is given in the installation directory for PSoC Programmer 3.

*[Install path]\Cypress\Programmer\3.xx\Bootloaders\BootLoaderUSBFS\Bootloader\_Host\_PSoC1\...*

## **Bootloader Tools**

Several tools are available from the shortcut menu and are accessed by right clicking on the user module icon.

Special versions of boot.tpl, custom.lkp and HTLinkOpts.lkp can be placed in the project or removed. From the main menu select Tools > Restore Default Boot files. If you remove the USBFSe Bootloader User Module, the option to restore the default boot files moves to the File menu in PSoC Designer.

Generate Checksum – After your project builds correctly you can use the bootloader tools to create and autovalidate checksums. Upon entry into the bootloader tools selection screen, project code is generated and a complete compile of the entire project is executed. Then a checksum calculation is performed on the resulting hex file which is compared to a checksum stored by the user module. If the checksums do not match, a message is displayed. You can recalculate and store a new checksum if you wish. If build or compile errors occur in the automated generate and build invoked by the Bootloader Tools, and no hex file is successfully created, an error is reported but no error debug information is displayed in the build dialog of PSoC Designer. Error reporting is suppressed when the generate and build is invoked from the automation interface. To debug build errors it is necessary to use the conventional build and generate process external to the bootloader tools menu.

Generate dld file – This tool item derives a download file from the hex project output file. This file contains only the hex blocks that are reprogrammed by the bootloader including the checksum block. The Host Demonstration application is capable of reading this file and downloading it to a working project incorporating a bootloader. This download file can be deployed to a field application to upgrade a PSoC device.

The dld download file is generated by Bootloader User Module tool and listed in “Output Files” in Workspace Explorer.

## Notes about Checksum Semiautomatic Generation

After your project is built and compiled without errors, the application checksum must be generated. The application checksum is created using one of the utilities available by right-clicking on the Bootloader User Module Icon in the Device Editor view and selecting **Bootloader Tools**. An application checksum (previously calculated or default) is stored as a hidden user module parameter. When the Bootloader Tools menu page is invoked, any previous checksum is validated against the one calculated on the current output\<prj\_name>.hex file. Necessarily, the checksum cannot be generated before a successful compile. After a checksum is created, it must be integrated into the compiled files. This requires a second compile.

### Pay attention to the following:

The device will enter the application after startup if it is programmed after the "Re-build Project with Valid Checksum" operation with the correct application checksum. No 'Generate' operation is allowed between "Re-build Project with Valid Checksum" and programming.

The device will enter the bootloader after startup if it is programmed with incorrect application checksum after Generate, or without the "Re-build Project with Valid Checksum" operations.

**Note** The user module uses checksums to verify the integrity of the .hex code. The checksums are calculated by the "Re-build Project with Valid Checksum" operation and cleared by Generate operation. **Therefore, it is not recommended to program the device after the Build operation when neither the Generate operation nor the "Re-build Project with Valid Checksum" operation was executed before it.**

The following situations are possible:

1. Generate was executed
2. Application code was changed
3. Build was performed
4. Device was programmed

If these occur, then the device will always enter the bootloader after programming.

The other possible situations are:

1. "Re-build Project with Valid Checksum" was executed
2. Application code was changed
3. Build (without Generate) was performed
4. Device was programmed

If these occur, then the device will always enter the application after programming. If the application code is not correct, a new application code can be downloaded by the bootloader through the Acquisition Window only.

## Special Files Given

You can access several important files by opening the **Bootloader Tools** menu and selecting **Get Files**. A device specific boot.tpl file is placed in the main project directory along with files called custom.lkp (ImageCraft), HTLinkOpts.lkp (Hi Tech) and a predefined flashsecurity.txt file. Each file is briefly described here (the original versions of these files are placed in the project backup directory):

Boot.tpl – This file contains a relocatable and nonrelocatable definition of interrupt vector tables and device specific boot setup that is specified in a relocatable area of ROM rather than the fixed location specified in the standard boot.tpl file.

Custom.lkp – When source generation takes place, the custom.lkp file is populated with autogenerated ROM areas for major code blocks as defined in the user module parameters. Do not modify the code blocks in the custom.lkp file, named:

- -bSSCParmBlk – Contains specified critical RAM used during flash operations.
- -bBootloader
- -bBLChecksum
- -bUserAPP – Changes to any of the last three lines result in an error dialog indicating the inability of the project to detect the correct custom.lkp file.

During code generation, each of the last three lines of the custom.lkp file are rewritten under control of the code generation software. Changes made within or below the last three lines either cause an error or are simply lost. You can make changes to the rest of the custom.lkp file. To debug the memory allocation of the project, you can comment out all three lines mentioned earlier by inserting a semicolon in the first space. This allows the linker to place code automatically and may be helpful in determining application code size requirements.

HTLinkOpts.lkp – When source generation takes place, the HTLinkOpts.lkp file is populated with auto-generated ROM areas for major code blocks as defined in the user module parameters. Do not modify the code blocks in the HTLinkOpts.lkp file.

- -L-ACODE... & -L-AROM... Lines contain data providing overall ROM size
- -L-PPD\_startup... contains linker directives to locate bootloader specific ROM areas
- -L-P
- -L-Pbss0= Changes to any of the last several lines result in an error dialog indicating the inability of the project to detect the correct HTLinkOpts.lkp file.

During code generation, several of the last lines of the HTLinkOpts.lkp file are rewritten under control of the code generation software. Changes made within or below the last three lines either cause an error or are simply lost.

Flashsecurity.example – This is a default file that is laid out according to the default memory map specified by the default user module parameters. For final project creation, you may have to manually modify this file according the final memory map and application size for the deployed device and firmware. Note that this file is NOT directly used by PSoC Designer. If for some reason the project is updated or tagged for out of data files, the flashsecurity file is not overwritten. You can edit and rename the given file flashsecurity.example.

Flashsecurity.txt – This is a default file given by PSoC Designer. The data in this file is added to the .hex file and instructs the device how to manage access to the internal ROM memory. If memory blocks are protected from write access, the bootloader does not work. Since read and write protection is built into the programmed PSoC, this file must be correctly configured before the first deployment of the bootloader.

## USB Descriptors

The standard USBFS User Module incorporates a tool to develop the USB descriptor used in the runtime application. The Bootloader adds an additional tool to allow development or modification of the default USB\_Bootloader descriptor. These two descriptors are stored in different areas of ROM. The descriptor for the foreground application may be upgraded with the application. The USB\_Bootloader descriptor is part of the bootloader ROM area and cannot be upgraded in the field. To maintain core functionality, key USB code is also placed in the bootloader ROM area. This is to overcome the problem of executing code that is being rewritten (which is not a good programming practice).

## USB Compliance for Self Powered Devices

In the *USB Compliance Checklist* there is a question that reads, “Is the device’s pull up active only when VBUS is high?”

The question lists Section 7.1.5 in the *Universal Serial Bus Specification Revision 2.0* as a reference. This section reads, in part, “The voltage source on the pull up resistor must be derived from or controlled by the power supplied on the USB cable such that when VBUS is removed, the pull up resistor does not supply current on the data line to which it is attached.”

If the device that you are creating is self powered, you must connect a GPIO pin to VBUS through a resistive network and write firmware to monitor the status of the GPIO. The application Note “*Monitoring the EZ-USB FX2LP VBUS*” [AN15813](#), explains the necessary hardware and software components required. Use the USB IO Control Register 1 (USBIO\_CR1) to control the pull up resistor on the D+ line.

## Bootloader VID and PID

For final deployment of a USB device, a Vendor ID and Product ID must be assigned. These are assigned by the USB standards organization upon request by USB developers. For development purposes, any VID and PID that does not conflict with existing VIDs and PIDs on a host may be used to debug a project. However, for the purposes of project release or deployment, you must not use VIDs and PIDs assigned to Cypress.

## Block Entry of Parameters

All memory parameters are entered in the bootloader in blocks numbered from 0x00 through 0xFF for most devices. Although this is not the most convenient format to enter memory addressees, it prevents accidental assignment of partial block addresses to different sections of the memory map. The PSoC devices in question are only capable of storing 64 byte flash blocks (128 byte for the 20x45) and this is a simple way to maintain the boundaries between different sections of the project code correctly.

## Host Application Debugging

An application with a bootloader built in may be difficult to debug. Because of this there are additional adjustments that can be made within the bootloader user module files. These are contained in the file BootLdrUSBFSe\_Bt\_loader.inc. There is a section containing the following equates:

```
; Boot Timeout constant. The timeout is based on an 8Hz Sleep interval.
; So for a timeout of 1 second, this value has to be 8
BOOT_TIMEOUT:      EQU      200 ; set to zero to make timeout infinite,
;                               ; default is 200(dec) = ~25 seconds
CHECKSUM_ON_CKSUMBLK: EQU      1  ; set to 1: Apply a checksum to the checksum block
;                               ; (adds compile steps and code to verify)
; set to 0: remove verification of checksum on Checksum block
```

The BOOT\_TIMEOUT equate allows you to lengthen, shorten, or make infinite code that timeouts if no communication is received from a host after a user command calls the bootloader. This may be useful when developing or debugging the host application.

The second equate controls the use of the checksum inside the checksum block. If this equate is set to 0, no verification is done on the checksum contained inside the checksum block. A checksum verification is still performed on the entire user application area as defined in the user module parameters.

## Timing

The BootLdrUSBFSe User Module supports USB 2.0 full speed operation.

## USBFS Setup Wizard

The BootLdrUSBFSe User Module does not use the PSoC Designer parameter grid display for personalization USB descriptors. Instead, it uses Wizards to define the USB descriptors for the application and bootloader. From the descriptors, the wizard personalizes the user module.

This wizard facilitates the construction of the USB descriptors and integrates the information generated into the driver firmware used for device enumeration. The BootLdrUSBFSe User Module does not function without first running the application and bootloader wizards, selecting the appropriate attributes, and generating code.

## Using Blocks Instead of Addresses

Any Bootloader needs to write to Flash, and PSoC can only write to flash “Block” by “Block”. So for bootloader applications it is more useful to think of memory as a group of “Blocks” to be written.

To translate from Blocks to absolute addresses multiply:  $\text{Abs\_addr} = \text{block\_number} \times \text{Block Size}$ . Block\_0 starts at addr 0, Block\_n starts at address  $n \times \text{Block\_size}$ . All blocks are delimited in hex for the bootloader parameters so a hex address can be obtained by multiplying by 0x40 (64-byte blocks) or 0x80 (128-byte blocks).

Hex output files contain an absolute address for each line. Regardless of the block size of the device in question (0x40/0x80), the hex output file breaks the code into lines of 64(d)/0x40 bytes per line. Therefore, for a 64byte block device each line represents a block of code. For a 128 byte block device, two lines from the hex file go into a block (since block 0 starts at address 0, 128 byte blocks must be **ALWAYS** considered to have an “even” half representing the lower (address) half and an “odd” half representing the upper (address) half).

See a hex file and become familiar with the flash block size for the part that you are working with.

## Common Problems

This section discusses the common issues that occur when creating bootloader projects, and gives advice on how to work around them.

## Updating Bootloader Projects, Service Pack Upgrades, and Compilers

Changes to the PSoC Developer environment should be avoided when using a bootloader application. This includes not updating PSoC Designer, the Bootloader User Module, and the compiler.

To understand the reasons for this, keep in mind that initially the bootloader and application are compiled together, but after a bootloadable system is deployed, only the application section is reprogrammed. A new or revised application must be compiled with the identical version of the Bootloader User Module so that the new application matches the bootloader from the original deployment. Ideally, all versions of the elements in the development environment are compatible. However, in the case of a bootloader, it is essential to maintain compatibility. By not changing the development environment compatibility risks can be eliminated.

The USB based bootloader exposes its USB subsystem to the application as APIs. This is done to reduce code size. Exposure of these functions is done through a redirected call table. The implication of this strategy is that the application makes indirect calls to specific addresses within the bootloader. Because the bootloader and application are compiled together, any change to the bootloader doesn't cause a change to addresses of the USB API functions.

Although multiple compilers are supported by PSoC Designer, do not assume that a bootloader compiled under one compiler is compatible with an application compiled under another. One critical difference

regards assumptions about RAM allocation. The implementation of RAM paging may be different from one compiler to another. An added difficulty is that because a bootloader and application are compiled together, it is not possible to debug a bootloader/application pair that had mismatches in the development tools used.

## Internal Use of the Watchdog Timer

Coordination with the watchdog timer is linked to the global parameter WATCHDOG\_ENABLE, contained in the file globalparams.inc. If your project uses a watchdog timer, it conditionally compiles code linked to the global parameter, and automatically sets the watchdog during bootload checksum and download operations. CPU clock speed affects how fast the watchdog timer is updated. A practical minimum setting for the watchdog timer is approximately 0.125 seconds.

## Improper Settings in Flashsecurity.txt

The default settings for this file are set when the project is created. An example configuration is given in the file "Flashsecurity.example". Flashsecurity.example is given with the BootLoader Tools - Get Files user module menu item. The map must allow flash write at all the locations that are eventually booted. One strategy is to make all blocks writeable. Another strategy is to take a moment to layout your memory map now and edit this file accordingly. No matter which strategy is chosen, taking action at the beginning of the project is quicker than debugging it later. It is your responsibility to write protect the areas of code used by the bootloader executable. Failure to correctly map flash security can be a contributing factor in a broken system and an extremely difficult debug task.

For development and debugging purposes, a flash security of 'U' (unprotected) is recommended for the application area. For final production, a flash security setting of 'R' (read protected) is recommended on the application area to prevent external reads and writes from occurring.

## Incorrect Relocatable Code Start Address (Linker Parameter ImageCraft Compiler Only)

Since the memory map for a bootloader project is considerably different than that for a conventional project, the relocatable code start address is adapted when Bootloader Tools window is invoked. This parameter can be viewed (changed) in the Relocate code start address field in the Project > Settings > Linker tab. This value is obtained by multiplying the parameters:

ApplicationCode\_Start\_Block X block size = Relocatable Code Start Address.

**Note** When unplacing the Bootloader UM, the Relocatable Code Start Address does not reset to its original value. The user needs to change it back manually to save ROM space.

## Power Stability

Power noise, glitches, brownout, slow power ramp, and poor connections can cause difficult to diagnose problems with flash programming. Program execution is rapid in comparison to power ramps, and in some cases, a part may still have changing power levels when flash programming is taking place. One example is some sort of status write to flash at power up. Evaluate your use model and the potential for changing power supply conditions during flash operations. Poor power stability may contribute to nonfunctional parts and may cause poor flash retention.

## Application or Interrupts Not Completely Stopped During Bootload Process

The application that is to be replaced by a new booted application must be completely terminated before a bootload operation can take place. It is especially important to turn application interrupts off. When the bootload process takes place, interrupt vector addresses are changed to zero before they are

rewritten to their new address. Running interrupts cause random resets (through a vector to 0) if they are not disabled. Note that this does NOT apply to the specific communication interrupts used by the bootloader.

There are two USB interfaces: one is used by the application and the other is used by the bootloader. A method to explicitly shut down the USB application interface and turn on the bootloader interface should be implemented, which also includes a complete shutdown of the running application. The example code given later in this datasheet contains an example of this procedure.

## Downloading a New File Causes the Device to Stop Working

It is possible to construct applications with no facility to enter the bootloader utility. It is easy to do this unintentionally. For example, a main() function with a simple while(1); loop never returns and enters the bootloader. As a result, it cannot be reprogrammed after it begins executing (as long as it has a correct checksum). There are multiple strategies to address this problem, but no default method is included in this user module. A few suggestions are:

1. Apply a reset condition that allows a period of time when the bootloader is enabled when the device first powers up. By setting timeout parameters, the device can be configured to enter the bootloader upon reset and exit to the foreground application when the timeout expires.
2. Set a test at some point in the code that causes the device to enter the bootloader. This can be a switch closure or holding a port pin low/high.
3. Using built in USB capabilities such as feature reports or a spare endpoint, define USB communication that can be sent to the device to instruct it to enter bootload mode. When this command is sent, the device drops off the USB bus briefly, and when it returns it should enumerate as a bootloader.
4. Use the watchdog timer to reset the device if it is not serviced regularly. This can be combined with one of the above strategies to allow a WDT interrupt to initiate a bootloadable state. Upon reset from a watchdog timer, monitor a status bit associated with the watchdog timer to determine if this is the cause of the reset condition. See the Technical Reference Manual for additional information.
5. Two projects have been developed and the bootloader in each project is different in some subtle way. Keep in mind that "bootloading" implies that programming part of a device is taking place. This implies that the implementation of the bootloader for each of two mutually reprogrammable applications must be identical. All bootloader parameters and relocatable code start addresses should be identical (this is different from first application block). Debug strategies for this problem include comparison of the two hex files in question paying particular attention to the areas of hex code used by the bootloader. Another method is to compare the <project>.lst files. The bootloader makes use of some redirect vectors to allow certain application address parameters to change. All of these jump vectors must match for an application and a bootloader. After a bootloader is deployed to a field application, there is no way to alter the code within it. A future application must still 'agree' about where mutually used jump vectors are stored.

## Parameters and Resources

The BootLdrUSBFSe User Module consists of a bootloader utility integrated with a fully functional USBFS User Module.

Parameters defined for the bootloader enable you to define where the major program areas are located when the program is compiled and linked.

## Renaming User Modules

Renaming the user module may require specific action on your part, because this user module requires a wizard to fill out and/or overwrite source files. Wizard generated variable names inside wizard generated

files may not be updated in all cases. You must open each wizard and select "OK" or "APPLY" to force the regeneration of internal variable names. If compile errors still occur because variable names are not updated, remove the problem file from the project, reopen the wizard, select "OK" or "APPLY", and rebuild the project. The file is replaced with the corrected variable names.

## Default Parameters

Default parameters are for informational purposes only. Defaults in your project may be tailored to the block size of the part in use, or may have been adjusted to give adequate sizes of code areas. After a project compiles and has been tested a developer may choose to adjust block sizes to optimize memory use.

Figure 3. Default Parameters for a Device with 0x80 (128 bytes) Blocks for HID Support Option

ApplicationCode_Start_Block	0x2C
BootLoaderKey	0001020304050607
Fixed Pulse Width	ENABLE
Flash_Program_Temperature_deg_C	-20C
ICE_Debug_FLASH_DISABLE	Flash_WRITE_ENABLE
Bootload_when_CKSUM_fails	ENABLE_(deployment)
AcquisitionWindow	10

Figure 4. Default Parameters for a Device with 0x40 (64 bytes) Blocks for HID Support Option

ApplicationCode_Start_Block	0x57
BootLoaderKey	0001020304050607
Fixed Pulse Width	ENABLE
Flash_Program_Temperature_deg_C	-20C
ICE_Debug_FLASH_DISABLE	Flash_WRITE_ENABLE
Bootload_when_CKSUM_fails	ENABLE_(deployment)
AcquisitionWindow	10

### ApplicationCode\_Start\_Block

This is the first block of code assigned to the user application. This code is bootloadable. This parameter is also used by the Bootloader Tools to determine what blocks of code to process for a .dld file and what blocks of code to calculate checksums on. This variable is propagated into the checksum block for use when the bootloader utility automatically verifies the application checksum.

### BootLoaderKey

This is the key value prepended to the transactions sent to the bootloader application. The key represents an extra verification step to ensure the bootloader upgrade utility is not started accidentally.

The default value "0001020304050607".

### Fixed Pulse Width

Enable this option to use a fixed pulse width based on the "Flash\_Program\_Temperature\_deg\_C". Disable this option to set program temperature at run time by calling the "BL\_SetTemp(BYTE bTemp)" function.

### Flash\_Program\_Temperature\_deg\_C

This is the typical programming temperature expected when the device is reprogrammed. Programming the device at a different temperature than that specified in this parameter may adversely effect program retention.

Matching the program temperature parameter to the actual temperature during bootload impacts memory retention and maximum number of write cycles. PSoC implements a stronger flash write at colder temperatures. Bootloading at significantly lower temperatures than the parameter setting may reduce memory retention. For this reason, take precautions to ensure that the bootloader is never operated more than 20C from the value in this parameter. Refer to the Cypress device specification for more information.

#### **ICE\_Debug\_Flash\_ENABLE**

This parameter is used to overcome an anomaly in the debug behavior of the ICE when executing an SSC while the USB resource is turned on and operating. Whenever an SSC operation is called (and it is during a flash write), the USB SIE is disabled. Disabling flash write allows an application to be completely tested without actually writing code to flash.

The default value is "Flash Write DISABLE".

#### **Bootload\_when\_CKSUM\_fails**

Normally if the application checksum is incorrect at reset time the bootloader becomes active and waits for a new application to be bootloaded. During code development with an ICE or debugger it may be inconvenient to take the extra step of correcting the checksum after each compile. This feature allows you to run and debug an application without considering bootloader operations. The checksum feature should be re-enabled for application field deployment.

#### **AcquisitionWindow**

This variable is the length of time that the PSoC device waits at startup for the Enter Bootloader command, before proceeding to the application code. This duration is measured in ms. The range is from 0 to 255 ticks (125 ms per tick).

## **Application Programming Interface**

The Application Programming Interface (API) routines in this section allow programmatic control of the BootLdrUSBFSe User Module. The following sections describe descriptor generation and integration. The sections also list the basic and device specific API functions. As a developer you need a basic understanding of the USB protocol and familiarity with the USB 2.0 specification, especially Chapter 9, USB Device Framework.

The BootLdrUSBFSe User Module supports control, interrupt, bulk, and isochronous transfers. Some or a group of functions, such as LoadInEP and EnableOutEP, are designed for use with bulk and interrupt endpoints. Other functions, such as BL\_USBFS\_LoadInISOCEP, are designed for use with isochronous endpoints. Refer to the Technical Reference Manual (TRM) for more information on how to do these transfer types.

#### **Note**

The API routines for the USB user modules are not re-entrant. Because they depend on internal global variables in RAM, executing these routines from an interrupt is not supported by the API support supplied with this user module. If this is a requirement for a design, contact the local Cypress Field Application Engineer.

For Large Memory Model devices, it is also the caller's responsibility to preserve any value in the CUR\_PP, IDX\_PP, MVR\_PP, and MVW\_PP registers. Even though some of these registers may not be modified now, there is no guarantee that will remain the case in future releases.

## Bootloader APIs

The Bootloader contains a very limited set of APIs, because the main purpose of the Bootloader is to completely remove and replace the user application.

### *ENTER\_BOOTLOADER()*

#### **Description:**

Enters the bootloader application and returns after timeout (if a timeout is defined) if no bootloader host begins to talk to the device. A generic parameter is defined that resides at a fixed address for the life of the deployed part. This function can also be implemented by a direct call to the known hex address of this function.

This function executes a ljmp to the GenericBootloaderEntry and resides at 0x7C.

#### **C Prototype:**

```
void ENTER_BOOTLOADER(void)
```

#### **Assembly:**

```
lcall ENTER_BOOTLOADER ; Call the Start Function
```

Alternately:

```
GenericHardDefinition: equ (0x7C)
lcall GenericHardDefinition           ; Call the Start Function
```

#### **Parameters:**

None

### *BL\_SetTemp (for devices with 64-byte Flash Block only)*

#### **Description:**

This function is used to dynamically update the bootloader with the latest die temperature measurement. In this case, the application obtains a die temperature measurement and passes it to the bootloader using this function. Then, when a bootload event occurs, the bootloader programs the flash optimally based on the temperature passed to it using this function.

It is recommended that you periodically measure (or otherwise determine) the device's die temperature during run time. Every time the die temperature is measured, it should be passed to the bootloader using this function. The bootloader uses the die temperature passed to it to optimally vary the flash programming erase and write periods during a bootload. This optimizes the flash's retention and endurance. As a result, the time it takes to execute a bootload varies depending on the temperature value passed to the bootloader.

The die temperature can be measured using a user module that measures the device's on-chip temperature sensor. Or, by reading or measuring the temperature from some other external device or temperature sensor.

This function rewrites the Die Temperature value that is set by the "Flash\_Program\_Temperature\_Deg\_C" user module parameter.

#### **C Prototype:**

```
void BL_SetTemp (CHAR cTemp);
```

**Assembler:**

```
mov A, cTemp
lcall BL_SetTemp
```

**Example Code:**

```
void main(void)
{
CHAR cDieTemp = -20; // Allocate a variable to hold the die temperature
// Use -20C as the default value
...
// Measure die temperature here and copy to cDieTemp variable
BL_SetTemp(cDieTemp); // Update Bootloader with real die temperature
ENTER_BOOTLOADER(); // Run the BootLoader
...
}
```

**Parameters:**

cTemp: Die Temperature in Celsius degrees.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the Large Memory Model (CY8C29xxx). When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions.

## USBFS APIs

The BootLdrUSBFSe User Module supports control, interrupt, bulk, and isochronous transfers. Some functions, or groups of functions, such as BL\_USBFS\_LoadInEP and BL\_USBFS\_EnableOutEP, are designed for use with bulk and interrupt endpoints. Other functions, such as BL\_USBFS\_LoadInISOEP, are designed for use with Isochronous endpoints. See the Technical Reference Manual (TRM) for more information on how to do these transfer types.

The following table lists the USBFS supplied API functions:

Function	Description
void BL_USBFS_Start(BYTE bDevice, BYTE bMode)	Activate the user module for use with the device and specific voltage mode.
void BL_USBFS_Stop(void)	Disable user module.
BYTE BL_USBFS_bCheckActivity(void)	Checks and clears the USB bus activity flag. Returns 1 if the USB was active since the last check, otherwise returns 0.
void BL_USBFS_SetPowerStatus(BYTE bPowerStatus)	Sets the device to self powered or bus powered
BYTE BL_USBFS_bGetConfiguration(void)	Returns the currently assigned configuration. Returns 0 if the device is not configured.

Function	Description
BYTE BL_USBFS_bGetEPState(BYTE bEPNumber)	Returns the current state of the specified USBFS endpoint. 2 = NO_EVENT_ALLOWED 1 = EVENT PENDING 0 = NO_EVENT_PENDING
BYTE BL_USBFS_bGetEPAckState(BYTE bEPNumber)	Identifies whether ACK was set by returning a nonzero value.
BYTE BL_USBFS_wGetEPCount(BYTE bEPNumber)	Returns the current byte count from the specified USBFS endpoint.
void BL_USBFS_LoadInEP(BYTE bEPNumber, BYTE *pData, WORD wLength, BYTE bToggle)	Loads and enables the specified USBFS endpoint for an IN transfer.
void BL_USBFS_LoadInISOCEP(BYTE bEPNumber, BYTE *pData, WORD wLength, BYTE bToggle)	
BYTE BL_USBFS_bReadOutEP(BYTE bEPNumber, BYTE *pData, WORD wLength)	Reads the specified number of bytes from the endpoint RAM and places it in the RAM array pointed to by pSrc. The function returns the number of bytes sent by the host.
void BL_USBFS_EnableOutEP(BYTE bEPNumber)	Enables the specified USB endpoint to accept OUT transfers.
void BL_USBFS_EnableOutISOCEP(BYTE bEPNumber)	
void BL_USBFS_DisableOutEP(BYTE bEPNumber)	Disables the specified USB endpoint to NAK OUT transfers.
BL_USBFS_Force(BYTE bState)	Forces a J, K, or SE0 State on the USB D+/D- pins. Normally used for remote wakeup. bState Parameters are: USB_FORCE_SE0 0xC0 USB_FORCE_J 0xA0 USB_FORCE_K 0x80 USB_FORCE_NONE 0x00  <b>Note.</b> When using this API Function and GPIO pins from Port 1 (P1.2-P1.7), the application uses the Port_1_Data_SHADE shadow register to ensure consistent data handling. From assembly language, access the Port_1_Data_SHADE RAM location directly. From C language, include an extern reference: extern BYTE Port_1_Data_SHADE;

Human Interface Device (HID) Class Support API:

Function	Description
BYTE BL_USBFS_UpdateHIDTimer(BYTE blInterface)	Updates the HID Report timer for the specified interface and returns 1 if the timer expired and 0 if not. If the timer expired, it reloads the timer.
BYTE BL_USBFS_bGetProtocol(BYTE blInterface)	Returns the protocol for the specified interface.

### *BL\_USBFS\_Start (user defined application device)*

#### **Description:**

Performs all required initialization for USBFS User Module. Either the foreground USB device or the bootloader specific USB device may be started using this command. Only one USB device configuration may be active at any time. To start the bootloader device set the value of bDevice to -1 (0xFF).

#### **C Prototype:**

```
void BL_USBFS_Start (BYTE bDevice, BYTE bMode)
```

#### **Assembly:**

```
mov A, 0xFF           ; The bootloader device descriptor
mov A, 0              ; Select application device descriptor
mov X, USB_5V_OPERATION ; Select the Voltage level
lcall BL_USBFS_Start    ; Call the Start Function
```

#### **Parameters:**

Register A: Contains the device number from the desired device descriptor set entered with the USBFS Setup Wizard.

Register X: Contains the operating voltage at which the chip runs. This determines whether the voltage regulator is enabled for 5V operation or the if pass through mode is used for 3.3V operation. Symbolic names are given in C and assembly, and their associated values are listed in the following table:

Mask	Value	Description
USB_3V_OPERATION	0x02	Disable voltage regulator and pass-through vcc for pull up
USB_5V_OPERATION	0x03	Enable voltage regulator and use regulator for pull up

#### **Return Value:**

None

#### **Side Effects:**

The A and X registers may be modified by this or future implementations of this function. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

### *BL\_USBFS\_Stop*

#### **Description:**

Performs all necessary shutdown task required for the USBFS User Module.

**C Prototype:**

```
void BL_USBFS_Stop(void)
```

**Assembly:**

```
lcall BL_USBFS_Stop
```

**Parameters:**

None

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. Currently only the CUR\_PP page pointer register is modified.

*BL\_USBFS\_bCheckActivity***Description:**

Checks for USBFS Bus Activity.

**C Prototype:**

```
BYTE BL_USBFS_bCheckActivity(void)
```

**Assembly:**

```
lcall BL_USBFS_bCheckActivity
```

**Parameters:**

None

**Return Value:**

Returns 1 in A if the USB was active since the last check, otherwise returns 0.

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function.

*BL\_USBFS\_bGetConfiguration***Description:**

Gets the current configuration of the USB device.

**C Prototype:**

```
BYTE BL_USBFS_bGetConfiguration(void)
```

**Assembly:**

```
lcall BL_USBFS_bGetConfiguration
```

**Parameters:**

None

**Return Value:**

Returns the currently assigned configuration in A. Returns 0 if the device is not configured.

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the large memory model. When necessary, it is the responsibility of the calling function to preserve the values across calls to fastcall16 functions. Currently only the CUR\_PP page pointer register is modified.

***BL\_USBFS\_bGetEPState***
**Description:**

Gets the endpoint state for the specified endpoint. The endpoint state describes, from the perspective of the foreground application, the endpoint status. The endpoint has one of three states, two of the states mean different things for IN and OUT endpoints. The following table outlines the possible states and their meaning for IN and OUT endpoints.

**C Prototype:**

```
BYTE BL_USBFS_bGetEPState (BYTE bEPNumber)
```

**Assembly:**

```
mov A, 1 ; Select endpoint 1
lcall BL_USBFS_bGetEPState
```

**Parameters:**

Register A contains the endpoint number.

**Return Value:**

Returns the current state of the specified USBFS endpoint. Symbolic names given in C and assembly, and their associated values are listed in the following table. Use these constants whenever you write code to change the state of the endpoints such as ISR code to handle data sent or received.

State	Value	Description
NO_EVENT_PENDING	0x00	Indicates that the endpoint is awaiting SIE action.
EVENT_PENDING	0x01	Indicates that the endpoint is awaiting CPU action.
NO_EVENT_ALLOWED	0x02	Indicates that the endpoint is locked from access.
IN_BUFFER_FULL	0x00	The IN endpoint is loaded and the mode is set to ACK IN.
IN_BUFFER_EMPTY	0x01	An IN transaction occurred and more data can be loaded.
OUT_BUFFER_EMPTY	0x00	The OUT endpoint is set to ACK OUT and is waiting for data.
OUT_BUFFER_FULL	0x01	An OUT transaction has occurred and data can be read.

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the large memory model. When necessary, it is the responsibility of the calling function to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP page pointer register is modified.

## *BL\_USBFS\_bGetEPAckState*

**Description:**

Determines whether or not an ACK transaction occurred on this endpoint by reading the ACK bit in the control register of the endpoint. This function does not clear the ACK bit.

**C Prototype:**

```
BYTE BL_USBFS_bGetEPAckState (BYTE bEPNumber)
```

**Assembly:**

```
mov A, 1 ; Select endpoint 1
lcall BL_USBFS_bGetEPAckState
```

**Parameters:**

Register A contains the endpoint number.

**Return Value:**

If an ACKed transaction occurred then this function returns a non-zero value. Otherwise, a zero is returned.

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the large memory model. When necessary, it is the responsibility of the calling function to preserve the values across calls to fastcall16 functions.

## *BL\_USBFS\_wGetEPCount*

**Description:**

This function returns the value of the endpoint count register. The Serial Interface Engine (SIE) includes two bytes of checksum data in the count. This function subtracts two from the count before returning the value. Call this function only for OUT endpoints after a call to *USB\_GetEPState* returns *EVENT\_PENDING*.

**C Prototype:**

```
WORD BL_USBFS_wGetEPCount (BYTE bEPNumber)
```

**Assembly:**

```
mov A, 1 ; Select endpoint 1
lcall BL_USBFS_wGetEPCount
```

**Parameters:**

Register A contains the endpoint number.

**Return Value:**

Returns the current byte count from the specified USBFS endpoint in A and X.

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the large memory model. When necessary, it is the responsibility of the calling function to preserve the values across calls to fastcall16 functions.

## *BL\_USBFS\_LoadInEP*

### **Description:**

Loads and enables the specified USB endpoint for an IN interrupt or bulk transfer (..\_LoadInEP) and isochronous transfer (...\_LoadInISOCEP).

### **C Prototype:**

```
void BL_USBFS_LoadInEP(BYTE bEPNumber, BYTE * pData, WORD wLength, BYTE bToggle)
void BL_USBFS_LoadInISOCEP(BYTE bEPNumber, BYTE * pData, WORD wLength, BYTE bToggle)
```

### **Assembly:**

```
mov A, USBFS_TOGGLE
push A
mov A, 0
push A
mov A, 32
push A
mov A, >pData
push A
mov A, <pData
push A
mov A, 1
push A
lcall BL_USBFS_LoadInEP
```

### **Parameters:**

bEPNumber – The endpoint Number between one and four.

pData – A pointer to a data array. Data for the endpoint is loaded from the data array specified by pData.

wLength – The number of bytes to transfer from the array as a result of an IN request. Valid values are between 0 and 256.

bToggle – A flag indicating whether or not the Data Toggle bit is toggled before setting it in the count register. For IN transactions toggle the data bit after every successful data transmission. This makes certain that the same packet is not repeated or lost. Symbolic names for the flag are given in C and assembly:

Mask	Value	Description
USB_NO_TOGGLE	0x00	The Data Toggle does not change
USB_TOGGLE	0x01	The Data bit is toggled before transmission

### **Return Value:**

None

### **Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the large memory model. When necessary, it is the responsibility of the calling function to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## *BL\_USBFS\_bReadOutEP*

### **Description:**

Moves the specified number of bytes from endpoint RAM to data RAM. The number of bytes actually transferred from endpoint RAM to data RAM is the lesser of the actual number of bytes sent by the host and the number of bytes requested by the wCount argument.

### **C Prototype:**

```
BYTE BL_USBFS_bReadOutEP(BYTE bEPNumber, BYTE * pData, WORD wLength)
```

### **Assembly:**

```
mov A, 0
push A
mov A, 32
push A
mov A, >pData
push A
mov A, <pData
push A
mov A, 1
push A
lcall BL_USBFS_bReadOutEP
```

### **Parameters:**

bEPNumber – The endpoint Number between one and four.

pData – The endpoint space is loaded from a data array specified by this pointer.

wLength – The number of bytes to transfer from the array and then send as a result of an IN request. Valid values are between 0 and 256. The function moves less than that if the number of bytes sent by the host are less requested.

### **Return Value:**

Returns the number of bytes sent by the host to the USB device. This can be more or less than the number of bytes requested.

### **Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the large memory model. When necessary, it is the responsibility of the calling function to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## *BL\_USBFS\_EnableOutEP*

### **Description:**

Enables the specified endpoint for OUT Bulk or Interrupt transfers (...\_EnableOutEP) and Isochronous transfers (...\_EnableOutISOCEP). Do not call these functions for IN endpoints.

### **C Prototype:**

```
void BL_USBFS_EnableOutEP(BYTE bEPNumber)
void BL_USBFS_EnableOutISOCEP(BYTE bEPNumber)
```

### **Assembly:**

```
mov A, 1
```

```
lcall BL_USBFS_EnableOutEP
```

**Parameters:**

Register A contains the endpoint number.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. Currently only the IDX\_PP page pointer register is modified.

***BL\_USBFS\_DisableOutEP*****Description:**

Disables the specified USBFS OUT endpoint. Do not call this function for IN endpoints.

**C Prototype:**

```
void BL_USBFS_DisableOutEP(BYTE bEPNumber)
```

**Assembly:**

```
mov A, 1                                ; Select endpoint 1
lcall BL_USBFS_DisableOutEP
```

**Parameters:**

Register A contains the endpoint number.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the large memory model. When necessary, it is the responsibility of the calling function to preserve the values across calls to fastcall16 functions.

***BL\_USBFS\_Force*****Description:**

Forces a USB J, K, or SE0 state on the D+/D- lines. This function gives the necessary mechanism for a USB device application to perform USB remote wakeup functionality. For more information, refer to the USB 2.0 Specification for details on Suspend and Resume functionality.

**C Prototype:**

```
void BL_USBFS_Force(BYTE bState)
```

**Assembly:**

```
mov A, BL_USB_FORCE_K
lcall BL_USBFS_Force
```

**Parameters:**

bState is byte indicating which among four bus states to enable. Symbolic names are given in C and assembly code, and their associated values are listed in the following table:

State	Value	Description
USB_FORCE_SE0	0xC0	Force a Single Ended 0 onto the D+/D- lines
USB_FORCE_J	0xA0	Force a J State onto the D+/D- lines
USB_FORCE_K	0x80	Force a K State onto the D+/D- lines
USB_FORCE_NONE	0x00	Return bus to SIE control

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the large memory model. When necessary, it is the responsibility of the calling function to preserve the values across calls to fastcall16 functions.

*BL\_USBFS\_UpdateHIDTimer*
**Description:**

Updates the HID Report Idle timer and returns the expiry status. Reloads the timer if it expires.

**C Prototype:**

```
BYTE BL_USBFS_UpdateHIDTimer (BYTE bInterface)
```

**Assembly:**

```
mov A, 1                                ; Select interface 1
lcall BL_USBFS_UpdateHIDTimer
```

**Parameters:**

Register A contains the interface number.

**Return Value:**

The state of the HID timer is returned in A. Symbolic names are given in C and assembly code, and their associated values are listed in the following table:

State	Value	Description
USB_IDLE_TIMER_EXPIRED	0x01	The timer expired.
USB_IDLE_TIMER_RUNNING	0x02	The timer is running.
USB_IDLE_TIMER_UNDEFINITE	0x00	Returned if the report is sent when data or state changes.

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function.

## *BL\_USBFS\_bGetProtocol*

**Description:**

Returns the HID protocol value for the selected interface.

**C Prototype:**

```
BYTE BL_USBFS_bGetProtocol(BYTE bInterface)
```

**Assembly:**

```
mov A, 1                                ; Select interface 1
lcall BL_USBFS_bGetProtocol
```

**Parameters:**

bInterface contains the interface number.

**Return Value:**

Register A contains the protocol value.

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the large memory model. When necessary, it is the responsibility of the calling function to preserve the values across calls to fastcall16 functions.

## *BL\_USBFS\_SetPowerStatus*

**Description:**

Sets the current power status. Set the power status to one for self powered or zero for bus powered. The device replies to USB GET\_STATUS requests based on this value. This allows the device to properly report its status for USB Chapter 9 compliance. Devices may change their power source from self powered to bus powered at any time and report their current power source as part of the device status. Call this function any time your device changes from self powered to bus powered or vice versa, and set the status appropriately.

**C Prototype:**

```
void BL_USBFS_SetPowerStatus(BYTE bPowerStaus);
```

**Assembly:**

```
mov A, 1                                ; Select self powered
lcall BL_USBFS_SetPowerStatus
```

**Parameters:**

bPowerStatus contains the desired power status, one for self powered or zero for bus powered. Symbolic names are given in C and assembly code, and their associated values are listed in the following table:

State	Value	Description
USB_DEVICE_STATUS_BUS_POWERED	0x00	Set the device to bus powered.
USB_DEVICE_STATUS_SELF_POWERED	0x01	Set the device to self powered.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. This is true for all RAM page pointer registers in the Large Memory Model. When necessary, it is the responsibility of the calling function to preserve the values across calls to fastcall16 functions.

## USB-UART APIs

Many embedded applications use the RS-232 interface to communicate with external systems such as PCs, especially when debugging. But in the PC world, the RS-232 COM port is about to disappear from most new computers, leaving USB as the replacement for serial communication. The simplest way to migrate a device to USB is to emulate RS-232 over the USB bus. The primary advantage of this method is that PC applications use the USB connection as an RS-232 COM connection, making it very simple to debug. This method uses a standard Windows® driver that is included with all versions Microsoft® Windows from Windows 98SE.

The USB Communication Device Class (CDC) specification defines many communication models, including an abstract control model for serial emulation over USB in Section 3.6.2.1. See the CDC specification version 1.1 for details. The Microsoft Windows USB modem driver, `usbser.sys`, conforms to this specification.

When a new device connects to a Windows PC the first time, Windows asks you to give a driver. An INF file is required to install drivers. Microsoft Windows does not give a standard INF file for the `usbser.sys` driver. In order to install a device that emulates RS-232 over USB, you must supply an INF file that maps the attached device to the Microsoft CDC drivers. The necessary INF file for USBUART projects is generated automatically and is located in the project LIB folder. After supplying the INF file, the driver allows the USB device to be enumerated as a COM port.

The settings in a terminal application (baud rate, data bits, parity, stop bits, and flow control) do not affect the performance of data transmissions because it is a USB device and the USB protocol is used to control data flow. However, the terminal settings with the exception of flow control can be retrieved with specific API calls to use with an RS-232 device if needed. The flow control setting cannot be retrieved because it is not supported by Microsoft's CDC driver, `usbser.sys`.

Use the following API calls to retrieve specific settings:

- `BL_UART_dwGetDTERate`
- `BL_UART_bGetCharFormat`
- `BL_UART_bGetParityType`
- `BL_UART_bGetDataBits`
- `BL_UART_bGetLineControlBitmap`

## Sending Packets of Length 64 Bytes or More

In this user module, the USB endpoint buffer size is set to 64 bytes for incoming and outgoing data. It means that all write and read APIs are limited to work with 64 byte buffer length.

In addition, a limitation exists for sending exactly 64 bytes of data. The PC side driver accepts a packet as fully received, if the payload size is less than 64 or transfers a zero-length packet. If all 64 bytes are received, the PC driver assumes that it has not received all the data and immediately asks for the next packet. The following code gives the successful transfer of data to PC immediately after function call:

```
while (!BL_UART_bTxIsReady());
BL_UART_Write(pData, 61); //Length is less than 64 data appear on
//terminal application after this function is executed.
```

The following code is an example that shows how to send exactly 64 bytes of data:

```
while (!BL_UART_bTxIsReady());
BL_UART_Write(pData, 64); //Length is equal to 64
while (!BL_UART_bTxIsReady());
BL_UART_Write(pData, 0); //No actual data transfer, but zero-length packet
// indicates PC driver that data is completely received.
// 64 bytes of data appears on terminal application
// after this function is executed.
```

Note that sending a 64 byte length packet with the following zero-length packet is faster than sending two packets of 32 bytes. This happens because a full 64 bytes-length packet forces the driver to continue the transfer.

The following code is an example that shows 150 bytes transfer:

```
while (!BL_UART_bTxIsReady());
BL_UART_Write(pData, 64); //Length is equal to 64
while (!BL_UART_bTxIsReady());
BL_UART_Write(pData, 64); //Length is equal to 64. 128 bytes is transferred to
// PC. No data appears on terminal application at the
// moment
while (!BL_UART_bTxIsReady());
BL_UART_Write(pData, 2); //Two bytes transferred. Full 130 bytes-length packet
//appears on terminal application after this function
// is executed.
```

The following table lists the USB-UART supplied API functions:

Function	Description
BOOL BL_UART_Init(void)	Initialize the USB-UART module. Returns a nonzero value if the USB-UART is successfully initialized.
void BL_UART_Write(BYTE * pData, BYTE bLength)	Sends bLength bytes from pData array to the PC.
void BL_UART_CWrite(const BYTE * pData, BYTE bLength)	Sends bLength bytes from constant (ROM) pData array to the PC.
void BL_UART_PutString(BYTE * pStr)	Sends a NULL terminated string pStr to the PC.
void BL_UART_CPutString(const BYTE * pStr)	Sends a constant (ROM) NULL terminated string pStr to the PC.

Function	Description
void BL_UART_PutChar(BYTE bChar)	Sends one character to the PC
void BL_UART_PutCRLF(void)	Sends a carriage return (0x0D) and a line feed (0x0A) to the PC.
void BL_UART_PutSHexByte(BYTE bValue)	Sends a two character hex representation of bValue to the PC.
void BL_UART_PutSHexInt(INT iValue)	Sends a four character hex representation of iValue to the PC.
BYTE BL_UART_bGetRxCount(void)	Returns the current byte count ready for read.
BYTE BL_UART_bTxIsReady(void)	Returns a nonzero value if USBUART is ready to send data.
BYTE BL_UART_Read(BYTE * pData, BYTE bLength)	Reads the specified number of bytes from the RX buffer and places it in the RAM array specified by pData. The function returns the number of bytes remaining in RX buffer and operation status.
void BL_UART_ReadAll(BYTE * pData)	Reads all available data from the RX buffer and places it in the RAM array specified by pData.
WORD BL_UART_ReadChar(void)	Returns one byte from the RX buffer in the LSB of the return value. The function also returns the operations status and number of bytes remaining in the RX buffer in the MSB of the return value.
DWORD *BL_UART_dwGetDTERate(DWORD * dwDTERate)	Returns the data terminal rate set for this port in bits per second.
BYTE BL_UART_bGetCharFormat(void)	Returns the number of stop bits.
BYTE BL_UART_bGetParityType(void)	Returns the parity type.
BYTE BL_UART_bGetDataBits(void)	Returns the number of data bits.
BYTE BL_UART_bGetLineControlBitmap(void)	Returns the DTE and RTS signal state.
void BL_UART_SendStateNotify(BYTE bState)	Sends notification about the current UART state to the PC.

## BL\_UART\_Init

### Description:

Try to initialize the USB-UART device and set up communication with the PC.

### C Prototype:

```
BOOL BL_UART_Init(void)
```

### Assembly:

```
lcall BL_UART_Init
```

### Parameters:

None

### Return Value:

Returns a nonzero value in the accumulator if the device initializes successfully. Returns a 0 if initialization failed. The user module can operate only after successful initialization.

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and CUR\_PP page pointer registers are modified.

**BL\_UART\_Write**
**Description:**

Sends bLength characters from the location specified by (RAM) pointer pData to the PC. Refer to [Sending Packets of Length 64 Bytes and More](#) when sending large packets.

**C Prototype:**

```
void BL_UART_Write(BYTE * pData, BYTE bLength)
```

**Assembly:**

```
mov A,20          ; Load array count
push A
mov A,>pData      ; Load MSB part of pointer to RAM string
push A
mov A,<pData      ; Load LSB part of pointer to RAM string
push A
lcall BL_UART_Write ; Make call to function
add SP,253        ; Reset stack pointer to original position
```

**Parameters:**

pData is a pointer to a data array. The maximum length of the data array is 64 bytes.

bLength is the number of bytes to be transferred from the array and sent to the PC. Valid values are between 0 and 64.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

**BL\_UART\_CWrite**
**Description:**

Sends bLength characters from the location specified by (ROM) pointer pData to the PC. Refer to [Sending Packets of Length 64 Bytes and More](#) when sending large packets.

**C Prototype:**

```
void BL_UART_CWrite(const BYTE * pData, BYTE bLength)
```

**Assembly:**

```
mov A,20          ; Load array count
push A
```

```

mov  A,>pData           ; Load MSB part of pointer to ROM string
push A
mov  A,<pData           ; Load LSB part of pointer to ROM string
push A
lcall BL_UART_CWrite   ; Make call to function
add  SP,253             ; Reset stack pointer to original position
  
```

**Parameters:**

pData is a pointer to a data array in ROM. Maximum length of the data array is 64 bytes.

bLength is the number of bytes to be transferred from the array and sent to the PC. Valid values are between 0 and 64.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## BL\_UART\_PutString

**Description:**

Sends a null terminated (RAM) string to the PC. Refer to [Sending Packets of Length 64 Bytes and More](#) when sending large packets.

**C Prototype:**

```
void BL_UART_PutString(BYTE * pStr)
```

**Assembler:**

```

mov  A,>pStr           ; Load MSB part of pointer to RAM based null
                           ; terminated string
mov  X,<pStr           ; Load LSB part of pointer to RAM based null
                           ; terminated string
lcall BL_UART_PutString ; Call function to send string out
  
```

**Parameters:**

pStr: Pointer to the string to be sent to PC. The MSB is passed in the Accumulator and the LSB is passed in the X register. The maximum string length is 64 bytes including the terminating null character.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## BL\_UART\_CPutString

**Description:**

Sends a null terminated (ROM) string to the PC. Refer to [Sending Packets of Length 64 Bytes and More](#) when sending large packets.

**C Prototype:**

```
void BL_UART_CPutString(const BYTE * pStr)
```

**Assembler:**

```
mov A,>pStr           ; Load MSB part of pointer to ROM based null
                        ; terminated string
mov X,<pStr           ; Load LSB part of pointer to ROM based null
                        ; terminated string
lcall BL_UART_PutString ; Call function to send string out
```

**Parameters:**

pStr: Pointer to the string to be sent to the PC. The MSB is passed in the Accumulator and the LSB is passed in the X register. The maximum string length is 64 bytes including the terminating null character.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## BL\_UART\_PutChar

**Description:**

Writes a single character to the PC.

**C Prototype:**

```
void BL_UART_PutChar(BYTE bChar)
```

**Assembler:**

```
mov A,0x33           ; Load ASCII character "3" in A
lcall BL_UART_PutChar ; Call function to send single character to PC
```

**Parameters:**

bChar: Character to be sent to the PC. Data is passed in the Accumulator.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## BL\_UART\_PutCRLF

**Description:**

Sends a carriage return (0x0D) and line feed (0x0A) to the PC.

**C Prototype:**

```
void BL_UART_PutCRLF(void)
```

**Assembler:**

```
lcall BL_UART_PutCRLF           ; Send a carriage return and line feed out
```

**Parameters:**

None

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## BL\_UART\_PutSHexByte

**Description:**

Sends a two byte ASCII Hex representation of the data to the PC.

**C Prototype:**

```
void BL_UART_PutSHexByte(BYTE bValue)
```

**Assembler:**

```
mov A,0x33           ; Load data to be sent
lcall BL_UART_PutSHexByte ; Call function to output hex representation of
                         ; data. The output for this value would be "33".
```

**Parameters:**

bValue: Byte to be converted to an ASCII string (hex representation). Data is passed in the Accumulator.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## BL\_UART\_PutSHexInt

**Description:**

Sends a four byte ASCII hex representation of the data to the PC.

**C Prototype:**

```
void BL_UART_PutSHexInt(INT iValue)
```

**Assembler:**

```
mov A,0x34          ; Load LSB in A
mov X,0x12          ; Load MSB in X
lcall BL_UART_PutSHexInt ; Call function to output hex representation of data.
                         ; The output for this value would be "1234".
```

**Parameters:**

iValue: Integer to be converted to ASCII string (hex representation). The MSB is passed in the X register and the LSB is passed in Accumulator.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## BL\_UART\_bGetRxCount

**Description:**

This function returns the number of bytes that were received from the PC and are waiting in the RX buffer.

**C Prototype:**

```
BYTE BL_UART_bGetRxCount(void)
```

**Assembly:**

```
lcall BL_UART_bGetRxCount
```

**Parameters:**

None

**Return Value:**

Returns the current byte count in A.

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP page pointer register are modified.

## BL\_UART\_bTxIsReady

### Description:

Returns a nonzero value if the TX buffer is ready to send more data. Otherwise it returns zero.

### C Prototype:

```
BYTE BL_UART_bTxIsReady(void)
```

### Assembly:

```
lcall BL_UART_bTxIsReady
```

### Parameters:

None

### Return Value:

If TX buffer can accept data then this function returns a nonzero value. Otherwise a zero is returned.

### Side Effects:

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions.

## BL\_UART\_Read

### Description:

Reads bLength bytes of received data from the RX Buffer and places it in a data array specified by pData.

### C Prototype:

```
BYTE BL_UART_Read(BYTE * pData, BYTE bLength)
```

### Assembly:

```
mov A, 25          ; Load count
push A
mov A, >pData      ; Load MSB part of pointer to RAM array
push A
mov A, <pData      ; Load LSB part of pointer to RAM array
push A
lcall BL_UART_Read
```

### Parameters:

pData is a pointer to a data array. Maximum length of the data array is 64 bytes.

bLength is the number of bytes to be read to the array. Valid values are between 0 and 64.

### Return Value:

Returns the number of bytes remaining in the RX buffer using bit 0..6 of the Accumulator and the MSb (bit 7) of the Accumulator indicates an error condition. Error conditions usually occur when you request more bytes than are available in the buffer. The data from the RX buffer is placed in the data array specified by pData.

### Side Effects:

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling

function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## **BL\_UART\_ReadAll**

### **Description:**

Reads all bytes of received data from the RX buffer and places it in a data array specified by pData.

### **C Prototype:**

```
void BL_UART_ReadAll(BYTE * pData)
```

### **Assembly:**

```
mov A,>pData           ; Load MSB part of pointer to RAM buffer
mov X,<pData           ; Load LSB part of pointer to RAM buffer
lcall BL_UART_ReadAll
```

### **Parameters:**

pData is a pointer to a data array. The MSB is passed in the Accumulator and the LSB is passed in the X register. The maximum size of the data array is 64 bytes.

### **Return Value:**

None

### **Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## **BL\_UART\_ReadChar**

### **Description:**

Reads one byte of received data from the RX Buffer.

### **C Prototype:**

```
WORD BL_UART_ReadChar(void)
```

### **Assembly:**

```
lcall BL_UART_ReadChar
```

### **Parameters:**

None

### **Return Value:**

The MSB of the returned value (Accumulator) contains the number of bytes remaining in the RX buffer using bits 0..6. Bit 7 indicates error status. Bit 7 is set to one if the buffer is empty when the function is called. The LSB of the returned value (X) contains a character from buffer.

### **Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## BL\_UART\_dwGetDTERate

### Description:

Returns the data terminal rate set for this port in bits per second. Pass the function a pointer to a DWORD. The function returns the DTE rate in the location referenced by the pointer.

### C Prototype:

```
DWORD * BL_UART_dwGetDTERate (DWORD * dwDTERate)
```

### Assembly:

```
mov A,>dwDTERate ; Load MSB part of pointer
mov X,<dwDTERate ; Load LSB part of pointer
lcall BL_UART_dwGetDTERate
```

### Parameters:

dwDTERate: A pointer to where the DTE rate is stored when the function returns.

### Return Value:

Stores the DTE rate DWORD value in the location referenced by the pointer it was passed, and then returns a pointer to that location.

### Side Effects:

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the IDX\_PP and the CUR\_PP page pointer registers are modified.

## BL\_UART\_bGetCharFormat

### Description:

Returns the number of stop bits.

### C Prototype:

```
BYTE BL_UART_bGetCharFormat (void)
```

### Assembly:

```
lcall BL_UART_bGetCharFormat
```

### Parameters:

None

### Return Value:

Returns number of stop bits in Accumulator. Symbolic names given in C and assembly, and their associated values are listed in the following table.

Mask	Value	Description
USBUART_1_STOPBITS	0x00	1 stop bit
USBUART_1_5_STOPBITS	0x01	1.5 stop bits
USBUART_2_STOPBITS	0x02	2 stop bits

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the CUR\_PP page pointer registers are modified.

**BL\_UART\_bGetParityType**
**Description:**

Returns the parity type.

**C Prototype:**

```
BYTE BL_UART_bGetParityType(void)
```

**Assembly:**

```
lcall BL_UART_bGetParityType
```

**Parameters:**

None

**Return Value:**

Returns the parity type in Accumulator. Symbolic names given in C and assembly, and their associated values are listed in the following table.

Mask	Value	Description
USBUART_PARITY_NONE	0x00	No parity
USBUART_PARITY_ODD	0x01	Parity odd
USBUART_PARITY_EVEN	0x02	Parity even
USBUART_PARITY_MARK	0x03	Mark parity
USBUART_PARITY_SPACE	0x04	Space parity

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the CUR\_PP page pointer registers are modified.

**BL\_UART\_bGetDataBits**
**Description:**

Returns the number of data bits.

**C Prototype:**

```
BYTE BL_UART_bGetDataBits(void)
```

**Assembly:**

```
lcall BL_UART_bGetDataBits
```

**Parameters:**

None

**Return Value:**

Returns the number of data bits in the Accumulator. The number can be 5, 6, 7, 8 or 16.

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the CUR\_PP page pointer registers are modified.

**BL\_UART\_bGetLineControlBitmap**
**Description:**

Returns a bitmap with the state of the RS-232 style control signal.

**C Prototype:**

```
BYTE BL_UART_bGetLineControlBitmap(void)
```

**Assembly:**

```
lcall BL_UART_bGetLineControlBitmap
```

**Parameters:**

None

**Return Value:**

Returns a bitmap with the state of the control signal in the Accumulator. Each bit of the bitmap can be treated individually. Bits D7..D2 are reserved. Symbolic names are given in C and assembly, and their associated values are listed in the following table.

Mask	Value	Description
USBUART_RTS	0x02	RTS (1 – activate carrier; 0 – deactivate carrier)
USBUART_DTR	0x01	DTR (1 – present; 0 – not present)

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the CUR\_PP page pointer registers are modified.

**BL\_UART\_SendStateNotify**
**Description:**

Sends notification to the PC about the UART status.

**Note** The Microsoft usbser.sys driver does not support these signals.

**C Prototype:**

```
void BL_UART_SendStateNotify(BYTE bState)
```

**Assembly:**

```
mov A, (USBUART_DCD + USBUART_DSR)
lcall BL_UART_SendStateNotify
```

**Parameters:**

bState bitmap with the state of the control signal in Accumulator. Each of the bits in the bitmap can be treated individually. Symbolic names given in C and Assembly, and their associated values are listed in the following table:

Mask	Value	Description
USBUART_DCD	0x01	RS-232 DCD signal
USBUART_DSR	0x02	RS-232 DSR signal
USBUART_BREAK	0x04	State of the break detection mechanism
USBUART_RING	0x08	State of the ring detection signal.
USBUART_FRAMING_ERR	0x10	A framing error has occurred.
USBUART_PARITY_ERR	0x20	A parity error has occurred.
USBUART_OVERRUN	0x40	Received data has been discarded due to an overrun.

**Return Value:**

None

**Side Effects:**

The A and X registers may be modified by this or future implementations of this function. The same is true for all RAM page pointer registers in the large memory model. When necessary, it is the calling function's responsibility to preserve the values across calls to fastcall16 functions. Currently only the CUR\_PP and IDX\_PP page pointer registers are modified.

## Sample Firmware Source Code

### HID Device

1. Create a new project with a base part supported by the BootLdrUSBFSe User Module (such as CY8C24894).
2. In the User Module Catalog click Protocols. Add the BootLdrUSBFSe User Module by double clicking the BootLdrUSBFSe icon or right clicking and choosing Place.
3. Select the Human Interface Device (HID) radio button and click OK.
4. Configure the BootLdrUSBFSe User Module as shown in the following figure. Defaults may be different, but still work for the given sample code.

ApplicationCode_Start_Block	0x57
BootLoaderKey	0001020304050607
Fixed Pulse Width	ENABLE
Flash_Program_Temperature_deg_C	-20C
ICE_Debug_FLASH_DISABLE	Flash_WRITE_ENABLE
Bootload_when_CKSUM_fails	ENABLE_(deployment)
AcquisitionWindow	10

5. Ensure the correct pin is configured as a pull down to recognize the switch closure to enter the bootloader. The example depends on a button that you can press. This button pulls Port1\_7 high and causes the program to re-enumerate as a bootloader. On some devices, the setting may be "pull down", and on other devices the correct setting may be "open-drain-low". You may need to consider the exact configuration of the test hardware used as a target for this example, and consult the relevant technical reference manual to correctly configure this project.

⊕ P1[6]	Port_1_6, StdCPU, High Z Analog, DisableInt, Normal, 0
⊖ P1[7]	Port_1_7, StdCPU, Pull Down, DisableInt, Normal, 0
Name	Port_1_7
Port	P1[7]
Select	StdCPU
Drive	Pull Down
Interrupt	DisableInt
AnalogMUXBus	Normal
InitialValue	0
⊕ P2[0]	Port_2_0, StdCPU, High Z Analog, DisableInt, Normal, 0

6. Right click on the user module icon. Select Boot Loader Tools. Select Get Files. When finished, the boot.tpl, custom.lkp, HTLinkOpts.lkp, and flashsecurity.example files must be in the project root directory.
7. Right click on the user module icon. Select **Device: Application USB Setup Wizard...**

- Click the Import HID Report Template operation and change the name to Import HID Report Template (*italics*) to show that it is a label.
- Select the 3 button mouse template.
- Click the Apply operation on the right side of the template.
- Select the Add String operation to add Manufacturer and Product strings.
- Edit the device attributes: Vendor ID, Product ID, and select strings.
- Edit the interface attributes: select HID for the Class field.
- Edit the HID class descriptor: select the 3 button mouse for the HID Report field.
- Click OK to save the USB descriptor information.

For details see the following table.

8. Right-click on the user module icon. Select **Device: BootLoader USB Setup Wizard...** Enter the correct VID (Vendor ID) and PID (Product ID) into the wizard. Note that the VID and PID for the application and the bootloader cannot be identical. Because the included Host PC example project has a VID of 04b4 and a PID of E006 (Cypress owned IDs) you may used it for local debug, but cannot be released for production. Click OK to save the USB BootLoader descriptor information.

**9.** Modify the flashsecurity.txt file to make the application, checksum, and relocatable interrupt vector areas writeable. The example flashsecurity.txt file shown in the following figure is an example. Some devices look slightly different, but all follow the same basic pattern.

```

; 0 40 80 C0 100 140 180 1C0 200 240 280 2C0 300 340 380 3C0 (+) Base Address

W W U U W W W W W W W W W W W ; Base Address 0
W W W W W W W W W W W W W W W ; Base Address 400
W W W W W W W W W W W W W W W ; Base Address 800
W W W W W W W W W W W W W W W ; Base Address C00
W W W W W W W W W W W W W W W ; Base Address 1000
W W W W W W U U U U U U U U U ; Base Address 1400
U U U U U U U U U U U U U U U ; Base Address 1800
U U U U U U U U U U U U U U U ; Base Address 1C00
U U U U U U U U U U U U U U U ; Base Address 2000
U U U U U U U U U U U U U U U ; Base Address 2400
U U U U U U U U U U U U U U U ; Base Address 2800
U U U U U U U U U U U U U U U ; Base Address 2C00
U U U U U U U U U U U U U U U ; Base Address 3000
U U U U U U U U U U U U U U U ; Base Address 3400
U U U U U U U U U U U U U U U ; Base Address 3800
U U U U U U U U U U U U U U U ; Base Address 3C00
; End 16K parts

```

**10.** Generate the Application.  
**11.** Copy the Sample code and paste it.  
**12.** Do a Rebuild all.

Descriptor	Data
USB user module descriptor root	Device name
Device descriptor	Device
Device attributes	
Vendor ID	Use company VID
Product ID	Use product PID
Device release (bcdDevice)	0000
Device class	Defined in interface descriptor
Subclass	No subclass
Manufacturer string	My company
Product string	My mouse
Serial number string	No string
Configuration descriptor	Configuration
Configuration attributes	
Configuration string	No string

Descriptor	Data
Max power	100
Device power	Bus powered
Remote wakeup	Disabled
Interface descriptor	Interface
Interface attributes	
Interface string	No string
Class	HID
Subclass	No subclass
HID class descriptor	
Descriptor type	Report
Country code	Not supported
HID report	3-button mouse
Endpoint descriptor	ENDPOINT_NAME
Endpoint attributes	
Endpoint number	1
Direction	IN
Transfer type	INT
Interval	10
Max packet size	8
String/LANGID	
String descriptors	USBFS
LANGID	
String	My company
String	My mouse
Descriptor	
HID report descriptor root	USBFS
HID report descriptor	USBFS

### Example code

The code illustrated here shows you how to use the BootLdrUSBFSe User Module in a simple HID application. When connected to a PC host, the device enumerates as a 3 button mouse. When the code is run the mouse cursor move in a square. This code illustrates how the BootLdrUSBFSe Setup Wizard configures the user module.

```
//
```

```

//emulate a mouse that causes the cursor to move in a square
//


#include <m8c.h>      // part specific constants and macros
#include "PSoCAPI.h"    // PSoC API definitions for all User Modules

signed char bXInc = 0; // X-Step Size
signed char bYInc = 0; // Y-Step Size

#define USB_INIT      0 // Initialized state
#define USB_UNCONFIG  1 // Unconfigured state
#define USB_CONFIG    2 // Configured state

// Mouse movement states
#define MOUSE_DOWN    0
#define MOUSE_LEFT    1
#define MOUSE_UP      2
#define MOUSE_RIGHT   3

#define POSMASK      0x03 // Mouse position state mask
#define BOX_SIZE      32 // Transfers per side of the box
#define bCursorStep   4 // Step size

BYTE bConfigState = 0; // Configuration state
BYTE bDirState = 0; // Mouse direction state

BYTE abMouseData[3] = {0,0,0}; // Endpoint 1, mouse packet array
BYTE boxLoop = 0; // Box loop counter

void main(void)
{
    M8C_EnableGInt; //Enable Global Interrupts
    BL_USBFS_Start(0, USB_5V_OPERATION); //Start USB Operation using device 0

    PRT1DR = 0;
    while(1) // Main loop
    {
        if (PRT1DR & 0x80)
        {
            BL_USBFS_Stop();
            while(PRT1DR & 0x80);
            ENTER_BOOTLOADER();
        }

        switch(bConfigState) // Check state
        {
        case USB_INIT: // Initialize state
            bConfigState = USB_UNCONFIG;
            break;
        case USB_UNCONFIG: // Unconfigured state
            if(BL_USBFS_bGetConfiguration() != 0)
            { // Check if configuration set
                bConfigState = USB_CONFIG;
                // Load a dummy mouse packet
                BL_USBFS_LoadInEP(1, abMouseData, 3, USB_NO_TOGGLE);
            }
        }
    }
}

```

```

        }
        break;
    case USB_CONFIG:           // Configured state time to move the mouse
        if(BL_USBFS_bGetEPAckState(1) != 0)
        {
            boxLoop++;
            if(boxLoop > BOX_SIZE)
            {
                // Change mouse direction every 32 packets
                boxLoop = 0;
                bDirState++; // Advance box state
                bDirState &= POSMASK;
            }
            switch(bDirState) // Determine current direction state
            {
                case MOUSE_DOWN:           // Down
                    bXInc = 0;
                    bYInc = bCursorStep;
                    break;
                case MOUSE_LEFT:           // Left
                    bXInc = -bCursorStep;
                    bYInc = 0;
                    break;
                case MOUSE_UP:              // up
                    bXInc = 0;
                    bYInc = -bCursorStep;
                    break;
                case MOUSE_RIGHT:          // Right
                    bXInc = bCursorStep;
                    bYInc = 0;
                    break;
            }
            abMouseData[1] = bXInc; // Load the packet array
            abMouseData[2] = bYInc;
            abMouseData[0] = 0;      // No buttons pressed
            BL_USBFS_LoadInEP(1, abMouseData, 3, USB_TOGGLE); // Load and toggle
        }
        Endpoint1
        } // End if Endpoint ready
        break;
    } // End Switch
} // End While
}

```

Here is Sample Code for the BootLdrUSBFSe User Module written in Assembly.

The assembly code illustrated here shows you how to use the BootLdrUSBFSe User Module in a simple HID application. When connected to a PC host, the device enumerates as a 3 button mouse. When the code is run the mouse cursor zigzags from right to left. This code illustrates how the BootLdrUSBFSe Setup Wizards configures the user module. This project is identical to the project in the USBFS User Module, except with the addition of a bootloader.

```

;-----
; Assembly main line
;-----
include "m8c.inc" ; part specific constants and macros

```

```

include "memory.inc" ; Constants & macros for SMM/LMM and Compiler
include "PSoCAPI.inc" ; PSoC API definitions for all User Modules

export _main

area bss(RAM) // inform assembler that variables follow
abMouseData: blk 3 // USBFS data variable
i: blk 1 // count variable

area text(ROM,REL) // inform assembler that program code follows

_main:
  M8C_EnableGInt
  ; Start USBFS Operation using device 0
  mov X, USB_5V_OPERATION
  mov A, 0
  lcall BL_USBFS_Start

  ; Wait for Device to enumerate
.no_device:
  lcall BL_USBFS_bGetConfiguration
  cmp A, 0
  jz .no_device
  ; Enumeration is completed load endpoint 1. Do not toggle the first time
  ; BL_USBFS_LoadInEP(1, abMouseData, 3, USB_NO_TOGGLE);
  mov A, USB_NO_TOGGLE
  push A
  mov A, 0
  push A
  mov A, 3
  push A
  mov A, >abMouseData
  push A
  mov A, <abMouseData
  push A
  mov A, 1
  push A
  lcall BL_USBFS_LoadInEP
  add SP, -6

.endless_loop:

;implement bootloader entry
  mov reg[PRT1DR], 0 ;load reg[PRT1DR] with 0
  mov A, reg[PRT1DR]
  and A, 0x80
  jz .Exit_BOOTLOAD_TEST
  lcall BL_USBFS_Stop
.wait_for_bit_low:
  tst reg[PRT1DR], 0x80
  jnz .wait_for_bit_low
  ; once it goes low enter the bootloader
  ljmp ENTER_BOOTLOADER ;;never returns
  halt
.Exit_BOOTLOAD_TEST:

```

```

;;; mouse operations

  mov A, 1
  lcall BL_USBFS_bGetEPACKState
  cmp A, 0
  jz .endless_loop
  ; ACK has occurred, load the endpoint and toggle the data bit
  ; BL_USBFS_LoadInEP(1, abMouseData, 3, USB_TOGGLE);
  mov A, USB_TOGGLE
  push A
  mov A, 0
  push A
  mov A, 3
  push A
  mov A, >abMouseData
  push A
  mov A, <abMouseData
  push A
  mov A, 1
  push A
  lcall BL_USBFS_LoadInEP
  add SP, -6

; When our count hits 128
  cmp [i], 128
  jnz .move_left
  ; Start moving the mouse to the right
  mov [abMouseData+1], 5
  jmp .increment_i
  ; When our counts hits 255
.move_left:
  cmp [i], 255
  jnz .increment_i
  ; Start moving the mouse to the left
  mov [abMouseData+1], 251

.increment_i:
  inc [i]

  jmp .endless_loop

.terminate:
  jmp .terminate

```

## USB-UART (CDC)

1. Create a new project with a base part supported by USBUART options in the BootLdrUSBFSe User Module (such as CY8C24894).
2. In the Device Editor, click **Protocols**. Add the BootLdrUSBFSe User Module by double clicking the BootLdrUSBFSe icon, or right clicking and choosing **Select**.
3. Select the USB-UART Device (CDC) radio button and click **OK**.

4. Configure the BootLdrUSBFSe User Module as shown in the following figure. Defaults may be different, but still work for the given sample code.


ApplicationCode_Start_Block	0x60
BootLoaderKey	0001020304050607
Fixed Pulse Width	ENABLE
Flash_Program_Temperature_deg_C	-20C
ICE_Debug_FLASH_DISABLE	Flash_WRITE_ENABLE
Bootload_when_CKSUM_fails	ENABLE_(deployment)
AcquisitionWindow	10

5. Ensure the correct pin is configured as a pull down to recognize the switch closure to enter the bootloader. The example depends on a button that you can press. This button pulls Port1\_7 high and causes the program to re-enumerate as a bootloader. On some devices, the setting may be "pull down", and on other devices the correct setting may be "open-drain-low". You may need to consider the exact configuration of the test hardware used as a target for this example, and consult the relevant technical reference manual to correctly configure this project.

⊕ P1[6]	Port_1_6, StdCPU, High Z Analog, DisableInt, Normal, 0
⊖ P1[7]	Port_1_7, StdCPU, Pull Down, DisableInt, Normal, 0
Name	Port_1_7
Port	P1[7]
Select	StdCPU
Drive	Pull Down
Interrupt	DisableInt
AnalogMUXBus	Normal
InitialValue	0
⊕ P2[0]	Port_2_0, StdCPU, High Z Analog, DisableInt, Normal, 0

6. Right click on the user module icon. Select Boot Loader Tools. Select Get Files. When finished, the boot.tpl, custom.lkp, HTLinkOpts.lkp, and flashsecurity.example files must be in the project root directory.

7. Right-click on the user module icon. Select **Device: Application USB Setup Wizard...** Configure the "Bootloader CDC properties" as shown in the following figure.



Click OK to save the CDC descriptor information.

8. Right click on the user module icon. Select **Device: BootLoader USB Setup Wizard...**. Enter the correct VID (Vendor ID) and PID (Product ID) into the wizard. Note that the VID and PID for the application and the bootloader cannot be identical. Because the included Host PC example project has a VID of 04b4 and a PID of E006 (Cypress owned IDs) you may used it for local debug, but cannot be released for production. Click OK to save the USB BootLoader descriptor information.
9. Modify the flashsecurity.txt file to make the application, checksum, and relocatable interrupt vector areas writeable. The example flashsecurity.txt file shown in the following figure is an example. Some devices look slightly different, but all follow the same basic pattern.

```

; 0 40 80 C0 100 140 180 1C0 200 240 280 2C0 300 340 380 3C0 (+) Base Address

W W U U W W W W W W W W W W W ; Base Address 0
W W W W W W W W W W W W W W W ; Base Address 400
W W W W W W W W W W W W W W W ; Base Address 800
W W W W W W W W W W W W W W W ; Base Address C00
W W W W W W W W W W W W W W W ; Base Address 1000
W W W W W W W W W W W W W W W ; Base Address 1400
U U U U U U U U U U U U U U U ; Base Address 1800
U U U U U U U U U U U U U U U ; Base Address 1C00
U U U U U U U U U U U U U U U ; Base Address 2000
U U U U U U U U U U U U U U U ; Base Address 2400
U U U U U U U U U U U U U U U ; Base Address 2800
U U U U U U U U U U U U U U U ; Base Address 2C00
U U U U U U U U U U U U U U U ; Base Address 3000
U U U U U U U U U U U U U U U ; Base Address 3400
U U U U U U U U U U U U U U U ; Base Address 3800
U U U U U U U U U U U U U U U ; Base Address 3C00
; End 16K parts

```

10. Generate the Application.
11. Copy the Sample code and paste it.
12. Do a Rebuild all.

### Example Code

The following code illustrates how to use the BootLdrUSBFS – USBUART User Module in a simple application.

```
#include <m8c.h>           // part specific constants and macros
#include "PSoCAPI.h"        // PSoC API definitions for all User Modules
BYTE Len;
BYTE pData[32];
void main(void)
{
    M8C_EnableGInt; //Enable Global Interrupts
    BL_USBFS_Start(0, USB_5V_OPERATION); //Start USBUART Operation usgin device 0
    while(!BL_UART_Init()); //Wait for Device to initialize
    while(1)
    {
        if(PRT1DR & 0x80)
        {
            BL_USBFS_Stop();
            while(PRT1DR & 0x80);
            ENTER_BOOTLOADER();
        }

        Len = BL_UART_bGetRxCount(); //Get count of ready data

        if (Len)
        {
            BL_UART_ReadAll(pData); //Read all data rom RX
            while (!BL_UART_bTxIsReady()); //If TX is ready
            BL_UART_Write(pData, Len); //Echo
        }
    }
}
```

The equivalent code written in Assembly is:

```
include "m8c.inc" ; part specific constants and macros
include "memory.inc" ; Constants & macros for SMM/LMM and Compiler
include "PSoCAPI.inc" ; PSoC API definitions for all User Modules

AREA bss (RAM, REL)

Len:    blk 1
pData: blk 32

export _main

AREA text (ROM, REL)
_main:
    M8C_EnableGInt          ; Enable Global Interrupts
    mov A, 0
```

```

  mov X, USB_5V_OPERATION
  lcall BL_USBFS_Start      ; Start USBUART 5V operation
deviceInit:                   ; Wait for Device to initialize
  lcall BL_UART_Init
  cmp A, 0
  jz deviceInit
mainLoop:
  ; implement bootloader entry
  mov A, reg[PRT1DR]
  and A, 0x80
  jz contLoop
  lcall BL_USBFS_Stop
wait:
  tst reg[PRT1DR], 0x80
  jnz wait
 ljmp ENTER_BOOTLOADER ; never returns
  halt

contLoop:
  lcall BL_UART_bGetRxCount
  RAM_SETPAGE_CUR >Len
  mov [Len], A ; Get count of ready data
  cmp [Len], 0 ; Check if Len is 0
  jz mainLoop
  mov A, >pData ; Load MSB part of pointer to RAM buffer
  mov X, <pData ; Load LSB part of pointer to RAM buffer
  lcall BL_UART_ReadAll ; Read all data rom RX
txReady:
  lcall BL_UART_bTxIsReady ; Check to see if TX is ready
  cmp A, 0
  jz txReady
  ; Echo data
  RAM_SETPAGE_CUR >Len
  mov A, [Len] ; Load array count
  push A
  mov A, >pData ; Load MSB part of pointer to RAM string
  push A
  mov A, <pData ; Load LSB part of pointer to RAM string
  push A
  lcall BL_UART_Write
  add SP, -3 ; Reset stack pointer to original position
  jmp mainLoop

```

## Appendix A – USBFS Topics

### USB Standard Device Requests

The following section describes the requests supported by the BootLdrUSBFSe User Module. If a request is not supported the BootLdrUSBFSe User Module normally responds with a STALL, indicating a Request Error.

Standard Device Request	BootLdrUSBFSe User Module Support Description	USB 2.0 Spec Section
CLEAR_FEATURE	Device:	9.4.1
	Interface: Not supported.	
	Endpoint	
GET_CONFIGURATION	Returns the current device configuration value.	9.4.2
GET_DESCRIPTOR	Returns the specified descriptor.	9.4.3
GET_INTERFACE	Returns the selected alternate interface setting for the specified interface.	9.4.4
GET_STATUS	Device:	9.4.5
	Interface:	
	Endpoint:	
SET_ADDRESS	Sets the device address for all future device accesses.	9.4.6
SET_CONFIGURATION	Sets the device configuration.	9.4.7
SET_DESCRIPTOR	This optional request is not supported.	9.4.8
SET_FEATURE	Device: DEVICE_REMOTE_WAKEUP support is selected by the bRemoteWakeUp User Module Parameter. TEST_MODE is not supported.	9.4.9
	Interface: Not supported.	
	Endpoint: The specified endpoint is halted.	
SET_INTERFACE	Not supported.	9.4.10
SYNCH_FRAME	Not supported. Future implementations of the user module adds support to this request to enable Isochronous transfers with repeating frame patterns.	9.4.11

## HID Class Request

Class Request	BootLdrUSBFSe User Module Support Description	Device Class Definition for HID - Section
GET_REPORT	Allows the host to receive a report by way of the Control pipe.	7.2.1
GET_IDLE	Reads the current idle rate for a particular Input report.	7.2.3
GET_PROTOCOL	Reads which protocol is currently active (either the boot or the report protocol).	7.2.5
SET_REPORT	Allows the host to send a report to the device, possibly setting the state of input, output, or feature controls.	7.2.2
SET_IDLE	Silences a particular report on the Interrupt In pipe until a new event occurs or the specified amount of time passes.	7.2.4
SET_PROTOCOL	Switches between the boot protocol and the report protocol (or vice versa).	7.2.6

## USB Setup Wizard

This section details all the USB descriptors given by the BootLdrUSBFSe User Module. The descriptions include the descriptor format and how user module parameters map into the descriptor data.

The USB Setup Wizard is a tool given by Cypress to assist engineers in designing USB devices. The setup wizard displays the device descriptor tree; when expanded, the following folders that are part of the standard USB descriptor definitions appear:

- Device attributes
- Configuration descriptor
- Interface descriptor
- HID Class descriptor
- Endpoint descriptor
- String/LANGID
- HID Descriptor

To access the setup wizard, right click the BootLdrUSBFSe User Module icon in the Workspace Explorer and click the **Device: Application USB Setup Wizard...** menu item.

When the device descriptor tree is fully expanded, all the setup wizard options are visible. The left side displays the name of the descriptor, the center displays the data, and the left displays the operation available for a particular descriptor. In some instances, a descriptor has a pull down menu that presents available options.

Descriptor	Data		Operations
USB User Module descriptor root	“Device Name”		Add device
Device descriptor	DEVICE_1		Remove Add configuration
Device attributes			
Vendor ID	FFFF		
Product ID	FFFF		
Device release (bcdDevice)	0000		
Device class	Undefined	pull down	
Subclass	No subclass	pull down	
Protocol	None	pull down	
Manufacturer string	No string	pull down	
Product string	No string	pull down	
Serial number string	No string	pull down	
Configuration descriptor	CONFIG_NAME		Remove Add interface
Configuration attributes			
Configuration string	No string	pull down	
Max power	100		
Device power	Bus powered	pull down	
Remote wakeup	Disabled	pull down	
Interface descriptor	INTERFACE_NAME		Remove Add endpoint
Interface attributes			
Interface string	No string	pull down	
Class	Vendor specific	pull down	
Subclass	No subclass	pull down	
HID class Descriptor			
Descriptor type	Report	pull down	
Country code	Not supported	pull down	
HID report	None	pull down	
Endpoint descriptor	ENDPOINT_NAME		Remove
Endpoint attributes			
Endpoint number	0		
Direction	IN	pull down	

Descriptor	Data		Operations
Transfer type	CNTRL	pull down	
Interval	10		
Max packet size	8		
String/LANGID			
String descriptors	Device name		Add string
LANGID		pull down	
String	Selected string name		Remove
Descriptor			
HID Descriptor	Device name		Import HID Report Template

## Understanding the USB Setup Wizard

The USB Setup Wizard window is a table that presents three major areas for programming. The first area is the USB Descriptor, the second is the String/LANGID, and the third is the Descriptor HID report. Use the two buttons below the table to perform the selected command.

The first section presents the Descriptor. The second section presents the String/LANGID; when a string ID is required, this area is used to input that string. To add a string for a USB device, click on the **Add String** operation. The software adds a row and prompts you to Edit your string here. Type the new string and click **Save/Generate**. After the string is saved, it is available for use in the Descriptor section from the pull down menus. If you close without saving, the string is lost.

The third area presents the HID Report Descriptor Root. From this area, you can add or import a HID Report for the selected device.

## USB User Module Descriptor Root

The first column displays folders to expand and collapse. For the purpose of this discussion, you must fully expand the tree that all options are visible. The setup wizard allows you to enter data into the middle Data column; if there is a pull down menu, use it to select a different option. If there is no pull down menu, but there is data, use the cursor to highlight and select the data, then overwrite that data with another value or text option. All the values must meet the USB 2.0 Chapter 9 Specifications.

The first folder displayed at the top is the *USB User Module Descriptor Root*. It has the user module name in the Data column (this is the user module name given to it by the software. This user module is the one placed in the Interconnect View. The Add Device operation on the right hand column adds another USB device complete with all the different fields required for describing it. The new USB device descriptor is listed at the bottom after the endpoint Descriptor. Click **OK** to save. If you do not save the newly added device, it is not available for use.

Device Descriptor has **DEVICE\_NUMBER** as the Data; it may be removed or a configuration added. All the information about a particular USB device may be entered by over writing the existing data or by using a pull down menu.

When the input of data is complete, either by using the pull down menus or by typing alphanumeric text in the appropriate spots, click **OK** to save.

## USB Suspend, Resume, Remote Wakeup and Monitoring USB Activity

The BootLdrUSBFSe User Module supports USB Suspend, Resume, and remote wakeup. Since these features are tightly coupled into the user application, the BootLdrUSBFSe User Module gives a set of API functions.

The BL\_USBFS\_bCheckActivity API function enables you to check if any USB bus activity has occurred. If the device supports remote wakeup, the application is able to determine if the host enabled remote wakeup with the BL\_USBFS\_bRWUEnabled API function. When the device is suspended and it determines the conditions to initiate a remote wakeup are met, the application uses the BL\_USBFS\_Force API function to force the appropriate J and K states onto the USB Bus, signaling a remote wakeup.

## Creating Vendor Specific Device Requests and Overriding Existing Requests

The BootLdrUSBFSe User Module supports vendor specific device requests by providing a dispatch routine for handling setup packet requests. You can also write your own routines that override any of the supplied standard and class specific routines, or enable unsupported request types.

## Processing USB Device Requests

All control transfers, including vendor specific and overridden device requests, are composed of:

- A setup stage where request information is moved from host to device.
- A data stage consisting of zero or more data transactions with data send in the direction specified in the setup stage.
- A status stage that concludes the transfer.

In the BootLdrUSBFSe User Module, all control transfers are handled by the endpoint 0 Interrupt Service Routine (BootLdrUSBFSe\_EP0\_ISR).

The endpoint 0 Interrupt Service Routine transfers control of all setup packets to the dispatch routine, which routes the request to the appropriate handler based upon the bmRequestType field. The handler initializes specific user module data structures and transfers control back to the endpoint 0 ISR. A handler for vendor specific or override device request is given by the application. The user module handles the data and status stages of the transfer without involving your application. After the transfer is completed, the user module updates a completion status block. The status block is monitored by the application to determine if the vendor specific device request is complete.

All setup packets enter the BootLdrUSBFSe\_EP0\_ISR, which routes the setup packet to the BootLdrUSBFSe\_bmRequestType\_Dispatch routine. From here all the standard device requests and vendor specific device requests are dispatched. The device request handlers must prepare the application to receive data for control writes or prepare the data for transmission to the host for control reads. For no-data control transfers, the handler extracts information from the setup packet itself.

The BootLdrUSBFSe User Module processes the data and status stages exactly the same way for all requests. For data stages, the data is copied to or from the control endpoint buffer (registers EP0DATA0-EP0DATA7) depending upon the direction of the transaction.

## Vendor Specific Device Request Dispatch Routines

Depending upon the application requirements, the USBFS User Module dispatches up to eight types of vendor specific device requests based upon the bmRequestType field of the setup packet. Refer to section 9.3 of the USB 2.0 specification for a discussion of USB device requests and the bmRequestType field. The eight types of vendor specific device requests the USBFS User Module dispatches are listed in the Table 1:

Table 1. Vendor Specific Request Dispatch Routine Names

Direction	Recipient	Dispatch Routine Entry Point	Enable Flag
Host to Device (Control Write)	Device	USB_DT_h2d_vnd_dev_Dispatch	USB_CB_h2d_vnd_dev
	Interface	USB_DT_h2d_vnd_ifc_Dispatch	USB_CB_h2d_vnd_ifc
	Endpoint	USB_DT_h2d_vnd_ep_Dispatch	USB_CB_h2d_vnd_ep
	Other	USB_DT_h2d_vnd_oth_Dispatch	USB_CB_h2d_vnd_oth
Device to Host (Control Read)	Device	USB_DT_d2h_vnd_dev_Dispatch	USB_CB_d2h_vnd_dev
	Interface	USB_DT_d2h_vnd_ifc_Dispatch	USB_CB_d2h_vnd_ifc
	Endpoint	USB_DT_d2h_vnd_ep_Dispatch	USB_CB_d2h_vnd_ep
	Other	USB_DT_d2h_vnd_oth_Dispatch	USB_CB_d2h_vnd_oth

You must follow these steps for an application to give an assembly language dispatch routine for the vendor specific device request.

1. In the *BootLdrUSBFSe.inc* file, enable support for the vendor specific dispatch routine. Find the dispatch routine enable flag and set EQU to 1.
2. Write an appropriately named assembly language routine to handle the device request. Use the entry points listed in Table 1.

## Override Existing Request Routines

To override a standard or class specific device request, or enable an unsupported device request, you must do the following:

1. In the *BootLdrUSBFSe.inc* file, redefine the specific device request as USB\_APP\_SUPPLIED.
2. Write an appropriately named assembly language function to handle the device request. The name of the assembly language function is APP\_ plus the device name.

For example, to override the supplied HID class Set Report request, USB\_CB\_SRC\_h2d\_cls\_ifc\_09, enable the routine with these changes to *BootLdrUSBFSe.inc*:

```

;@PSoCUserCode_BODY_1@ (Do not change this line.)
;-----
; Insert your custom code below this banner
;-----
; NOTE: interrupt service routines must preserve
; the values of the A and X CPU registers.

; Enable an override of the HID class Set Report request.
USB_CB_SRC_h2d_cls_ifc_09: EQU USB_APP_SUPPLIED

;-----
; Insert your custom code above this banner
;-----
;@PSoCUserCode_END@ (Do not change this line.)

```

Then, write an assembly language routine named APP\_USB\_CB\_SRC\_h2d\_cls\_ifc\_09. Device request names are derived from the USB bmRequestType and bRequest values (USB specification Table 9-2).

This code is a stub for the assembly routine for the previous example:

```
export APP_USB_CB_SRC_h2d_cls_ifc_09
APP_USB_CB_SRC_h2d_cls_ifc_09:
; Add your code here.

; Long jump to the appropriate return entry point for your application.
LJMP BootLdrUSBFSe_InitControlWrite
```

## Appendix B – Bootloader Topics

The following section contains additional information that you may find useful when creating a USB bootloader.

### Dispatch and Override Routine Requirements

At a minimum, the dispatch or override routine must return control back to the endpoint 0 ISR by a LJMP to one of the endpoint 0 ISR Return Points listed in Table 2. The routine may destroy the A and X registers, but the Stack Pointer (SP) and any other relevant context must be restored before returning control to the ISR.

Table 2. Endpoint 0 ISR Return Points

Return Entry Point	Required Data Items	Description
BootLdrUSBFSe_Not_Supported	Use this return point when the request is not supported. It STALLs the request.	
	Data Items: None	
BootLdrUSBFSe_InitControlRead	This return point is used to initiate a Control Read transfer.	
	BootLdrUSBFSe_DataSource (BYTE)	The data source is RAM or ROM (USB_DS_RAM or USB_DS_ROM). This is necessary since different instructions are used to move the data from the source ROMX or MOV.
	BootLdrUSBFSe_TransferSize (WORD)	The number of data bytes to transfer.
	BootLdrUSBFSe_DataPtr (WORD)	RAM or ROM address of the data.
	BootLdrUSBFSe_StatusBlockPtr (WORD) optional	Address of a status block allocated with the USB_XFER_STATUS_BLOCK macro.
BootLdrUSBFSe_InitControlWrite	This return point is used to initiate a Control Write transfer.	
	BootLdrUSBFSe_DataSource (BYTE)	USB_DS_RAM (the destination for control writes must RAM).
	BootLdrUSBFSe_TransferSize (WORD)	Size of the application buffer to receive the data

Return Entry Point	Required Data Items	Description
	BootLdrUSBFSe_DataPtr (WORD)	RAM address of the application buffer to receive the data
	BootLdrUSBFSe_StatusBlockPtr (WORD) optional	Address of a status block allocated with the USB_XFER_STATUS_BLOCK macro.
BootLdrUSBFSe_InitNoDataControlTransfer	This return point is used to initiate a No Data Control transfer.	
	BootLdrUSBFSe_StatusBlockPtr (WORD) optional	Address of a status block allocated with the USB_XFER_STATUS_BLOCK macro.

## Update USB Application Requests Routines through USB Bootloader

The BootLdrUSBFSe User Module allows you to override an existing USB application or to add a new USB application (other than another bootloader).

To enable the feature, redefine the UPDATE\_USB\_APP\_HANDLERS constant value to USB UM\_SUPPLIED in the BootLdrUSBFSe.inc file. Note that you must enable this feature before the bootloader is deployed. The code that calls custom request routines should be located between the UserDispatchCode andUMDispatchCode labels in the BootLdrUSBFSe.asm file. Values returned through the <UM\_Name>\_ReqReturnInstruction variable are used to control the next action of the Bootloader and are described in Table 3.

Table 3. Actions Performed by Bootloader after UserDispatchCode Code Execution

Value	Description
USB_UM_DISPATCH	Dispatch the request by User Module
USB_NO_DATA_STAGE_CONTROL_TRANSFER	Prepare status stage of no data control write
USB_GET_TABLE_ENTRY	Transfer data structures
USB_INIT_CONTROL_READ	Initialize control read
USB_INIT_CONTROL_WRITE	Initialize control write
USB_NOT_SUPPORTED_REQUEST	Process the request as Not Supported

**Note** Direct jump to these bootloader routines from the UserDispatchCode section is not allowed. If you need to jump from the routine to any place in the bootloader code that is not defined in Table 3, you must add the jump location to the BootLdrUSBFSe\_DT\_App\_Req dispatch table in the BootLdrUSBFSe\_drv.asm file. You may then jump to the location you have defined. Again, note that these changes must be made before the USB bootloader is deployed.

## Status Completion Block

The status completion block contains two data items, a one byte completion status code and a two byte transfer length. The "main" application monitors the completion status to determine how to proceed. Completion status codes are found in the following table. The transfer length is the actual number of data bytes transferred.

Table 4. USBFS Transfer Completion Codes

Completion Code	Description
USB_XFER_IDLE (0x00)	USB_XFER_IDLE indicates that the associated data buffer does not have valid data and the application should not use the buffer. The actual data transfer takes place while the completion code is USB_XFER_IDLE, although it does not indicate a transfer is in progress.
USB_XFER_STATUS_ACK (0x01)	USB_XFER_STATUS_ACK indicates the control transfer status stage completed successfully. At this time, the application uses the associated data buffer and its contents.
USB_XFER_PREMATURE (0x02)	USB_XFER_PREMATURE indicates that the control transfer was interrupted by the SETUP of a subsequent control transfer. For control writes, the contents of the associated data buffer contains the data up to the premature completion.
USB_XFER_ERROR (0x03)	USB_XFER_ERROR indicates that the expected status stage token was not received.

## Customizing HID Class Report Storage Area

If you enable optional HID class support, the Setup Wizard creates a fixed-size report storage area for data reports from the HID class device. It creates separate report areas for IN, OUT, and FEATURE reports. This area is sufficient for the case where no Report ID item tags are present in the Report descriptor and therefore only one Input, Output, and Feature report structure exists. If you want better control over the report storage size or want to support multiple report IDs, you must do the following:

1. Use the wizard to specify your device description, endpoints, and HID reports then generate the application.
2. Disable the wizard defined report storage area in *USB\_descr.asm*.
3. Copy the wizard created code that defines the report storage area.
4. Paste it into the protected user code area in *USB\_descr.asm* or a separate assembly language file.
5. Customize the code to define the report storage area.

## Specify Your Device and Generate Application

Use the USB setup wizard to specify your device description, endpoints, and HID reports. Click the **Generate Application** button in PSoC Designer.

## Disable Wizard Defined Report Storage Area

In the *USB\_descr.asm* file, disable the wizard defined storage area by uncommenting the **WIZARD\_DEFINED\_REPORT\_STORAGE** line in the custom code area, as shown in the following code:

```

WIZARD: equ 1
WIZARD_DEFINED_REPORT_STORAGE: equ 1
;-----
;@PSoC_UserCode_BODY_1@ (Do not change this line.)
;-----
; Insert your custom code below this banner
;-----
; Redefine the WIZARD equate to 0 below by
; uncommenting the WIZARD: equ 0 line

```

```

; to allow your custom descriptor to take effect
;-----

; WIZARD: equ 0
WIZARD_DEFINED_REPORT_STORAGE: equ 0
;-----
; Insert your custom code above this banner
;-----
;@PSoCUserCode-END@ (Do not change this line.)

```

## Copy the Wizard Created Code

Find this code in *USB\_descr.asm*.

```

;-----
; HID IN Report Transfer Descriptor Table for ()
;-----

IF WIZARD_DEFINED_REPORT_STORAGE
AREA lit (ROM,REL,CON)
.LITERAL
USB_D0_C1_I0_IN_RPTS:
  TD_START_TABLE 1 ; Only 1 Transfer Descriptor
  TD_ENTRY USB_DS_RAM, USB_HID_RPT_3_IN_RPT_SIZE, USB_INTERFACE_0_IN_RPT_DATA,
NULL_PTR
.ENDLITERAL
ENDIF ; WIZARD_DEFINED_REPORT_STORAGE

```

There are three sections, one each for the IN, OUT, and FEATURE reports. Copy all three sections.

## Paste Code Into Protected User Code Area

You can paste the code into the protected user code area of *USB\_descr.asm* shown or a separate assembly language file:

```

;-----
;@PSoCUserCode_BODY_2@ (Do not change this line.)
;-----
; Redefine your descriptor table below. You might
; cut and paste code from the WIZARD descriptor
; above and then make your changes.
;-----

;-----
; Insert your custom code above this banner
;-----
;@PSoCUserCode-END@ (Do not change this line.)
; End of File USB_descr.asm

```

## Customize Code to Define Report Storage Area

To define the report storage area, you need to write your own transfer descriptor table entries. The table contains entries to define storage space for the required data items. Each transfer descriptor entry in the table creates a new Report ID. IDs are numbered consecutively, starting with zero. Report ID 0 is reserved

in the USB spec; you cannot use Report ID of 0, but the transfer descriptor entry specified for the ID 0 is used when no Report IDs are present in the Report descriptor. For code efficiency, you must use Report IDs in order starting with ID 1.

Table 5. Transfer Descriptor Table Entries

Table Entry	Required Data Items	Description
TD_START_TABLE	USB_NumberOfTableEntries	Number of Report IDs defined. IDs are numbered consecutively from 0. Report ID 0 is not used.
TD_ENTRY		
	USB_DataSource	The data source is RAM or ROM (USB_DS_RAM or USB_DS_ROM).
	USB_TransferSize	Size of the data transfer in bytes. The first byte is the Report ID.
	USB_DataPtr	RAM or ROM address of the data transfer.
	USB_StatusBlockPtr	Address of a status block allocated with the USB_XFER_STATUS_BLOCK macro.

The following example sets up the unused Report ID 0, and two other IN reports with different sizes. Note Conditional assembly statements are only necessary if you place the code in the protected user code area of *USB\_descr.asm*.

```

;-----
; HID IN Report Transfer Descriptor Table for ()
;-----
IF WIZARD_DEFINED_REPORT_STORAGE
ELSE

_ID0_RPT_SIZE: EQU 0          ; 7 data bytes + report ID = 8 bytes (unused)
_SM_RPT_SIZE:  EQU 3          ; 2 data bytes + report ID = 3 bytes
_LG_RPT_SIZE:  EQU 5          ; 4 data bytes + report ID = 5 bytes

AREA data (RAM, REL, CON)

EXPORT _ID0_RPT_PTR
_ID0_RPT_PTR: BLK 0          ; Allocates space for report ID0 (unused)
EXPORT _SM_RPT_PTR
_SM_RPT_PTR:  BLK 3          ; Allocates space for report ID1
EXPORT _LG_RPT_PTR
_LG_RPT_PTR:  BLK 5          ; Allocates space for report ID2

AREA bss (RAM, REL, CON)

EXPORT _SM_RPT_STS_PTR

```

```

__SM_RPT_STS_PTR: USB_XFER_STATUS_BLOCK
EXPORT __LG_RPT_STS_PTR
__LG_RPT_STS_PTR: USB_XFER_STATUS_BLOCK

AREA lit      (ROM,REL,CON)
.LITERAL
EXPORT USB_D0_C1_IO_IN_RPTS:
    TD_START_TABLE 3
    TD_ENTRY USB_DS_RAM, _ID0_RPT_SIZE, _ID0_RPT_PTR, NULL_PTR ; ID0 unused
    TD_ENTRY USB_DS_RAM, _SM_RPT_SIZE, _SM_RPT_PTR, _SM_RPT_STS_PTR ; ID1
    TD_ENTRY USB_DS_RAM, _LG_RPT_SIZE, _LG_RPT_PTR, _LG_RPT_STS_PTR ; ID2
.ENDLITERAL

ENDIF ; WIZARD_DEFINED_REPORT_STORAGE

```

## Bootloader USB Download Protocol

Each command to the bootloader is followed by a response from the bootloader. The following figure shows the format of the Enter Bootloader command:

Enter Bootloader Packet	
Packet data (BULK OUT):	
0000	FF 38 00 01 02 03 04 05 06 07 00 00 00 00 00 00
0010	00 80 01 00 01 40 15 40 00 AB 3F FF 01 00 15 40
0020	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0030	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Status data (BULK IN):	
0000	01 00 00 00 04 00 00 00 00 00 00 00 00 00 00 00
0010	00 80 01 00 01 40 15 40 00 AB 3F FF 01 00 15 40
0020	00 00 00 00 00 00 00 00 00 00 40 00 3B 20 81 01
0030	FF 01 00 00 00 00 00 00 00 00 01 00 00 00 00 00
BootLoader Commands	
BootLoader Key	
Status Byte	
Error Byte	
BootLoader Configuration Data (from did file)	
BootLoader Configuration Data (from Bootloader code)	

The BootLoader Configuration data has the following format:

Byte Number	Description	Verified during Bootload Process
0x10-0x11	Address of relocatable interrupt table	+
0x12-0x13	Address of Checksum block	+
0x14-0x15	Address of Bootloader area	+
0x16-0x17	Address of Application area	-

Byte Number	Description	Verified during Bootload Process
0x18-0x19	Application area size in flash blocks	-
0x2A-0x2B	Max ROM address	+
0x2C-0x2D	User module version, for example, 0x0100, 0x0200	+
0x2E-0x2F	Address of Application area using ImageCraft compilerAddress of Bootloader area using HI-TECH compiler	-

The first line begins with the bootloader command FF38, enter bootloader. This command is followed by the bootloader key. All bootloader commands must be sent with the bootloader key. The bootloader ignores commands that are not sent with the proper key. You can set the bootloader key with the `Bootloader_Key` parameter. Other bootloader commands are:

Command	Meaning
FF38	Enter bootloader
FF39	Write block
FF3A	Verify flash
FF3B	Exit bootloader

The command is followed by a status response from the bootloader. In the status response, the first byte is the status byte and the second byte is the error flag. Following is the definition of each bit of the status byte:

Code	Meaning
0x01	Bootloading in progress
0x02	Boot Complete OK
0x04	Wait for Enter Bootloader Command

The following table describes each bit in the error byte. For details, see the flowcharts at the end of the document.

Code	Meaning
0x01	Timeout error. If read or write timeout occurred because of a long period of inactivity from the host, the flag is set and software reset is executed. The timeout verification executes only when <code>BOOT_TIMEOUT</code> constant is greater than zero.
0x02	Received 'Exit bootloader' command. The checksum of application and relocatable interrupt vector areas calculated by bootloader does not match the checksum received from Host.
0x04	Flash checksum error. Flash block content does not match the data received from Host.
0x08	Flash protection error. Flash block cannot be rewritten because its flash protection level does not allow this.
0x10	Comm checksum error. Received a packet with incorrect checksum.
0x20	Config Data error. Received 'Enter bootLoader' command, but the data packet contained incorrect Configuration data.
0x40	Invalid bootloader key. Received a packet with incorrect bootLoaderKey value.
0x80	Invalid command error. Received unknown command.

### Bootloader Write Block Command

Most of the commands sent to the bootloader are write block commands. The format of each of the write block commands is identical. Each 64-byte block is broken up into two 32-byte packets. Each command requires a status response from the slave. The transmission of a 64-byte block is shown in the following figure:

**First Download Packet**

Packet data (BULK OUT):	0000 FF 39 00 01 02 03 04 05 06 07 00 02 00 7F 30 30
	0010 30 30 7E 30 30 7E 30 30 30 7E 30 30 30 7E 30 30
	0020 30 7F 30 30 30 7F 30 30 30 7E 30 30 30 C9 00 00
	0030 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Status data (BULK IN):	0000 01 00 00 00 02 20 00 00 00 00 00 00 00 00 00 00 00
	0010 00 80 01 00 01 40 15 40 00 AB 3F FF 01 00 15 40
	0020 00 00 00 00 00 00 00 00 00 40 00 3B 20 81 01
	0030 FF 01 00 00 00 00 00 00 00 00 00 01 00 00 00 00 00
Packet data (BULK OUT):	0000 FF 39 00 01 02 03 04 05 06 07 00 02 01 7E 30 30
	0010 30 7E 30 30 30 7E 30 30 30 7E 30 30 30 7F 30 30
	0020 30 7F 30 30 30 7F 30 30 30 7F 30 30 30 CB 00 00
	0030 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Status data (BULK IN):	0000 01 00 01 00 02 40 00 00 00 00 00 00 00 00 00 00 00
	0010 00 80 01 00 01 40 15 40 00 AB 3F FF 01 00 15 40
	0020 00 00 00 00 00 00 00 03 00 40 80 3B 00 00 01
	0030 FF 01 00 00 00 00 00 00 00 00 00 00 01 00 00 00 00

Blue	BootLoader Commands
Magenta	BootLoader Key
Red	Block Number
Grey	Block Segment
Yellow	Status Byte
Orange	Error Byte
Light Green	64 bytes of data
Light Blue	Segment Checksum for 32 bytes of data

The first line of the first packet consists of a write block command and the bootloader key followed by the block number being transmitted. Since each block is broken in two, the block number is followed by the block segment number, either 0x00 for the first segment or 0x01 for the second. The last three bytes of the first line, all sixteen bytes of the second line, and the first 13 bytes of the third line represent the 32 bytes of valid data, followed by a checksum for the segment data. The remainder of the block is empty data to pad the segment to 64 bytes.

The status response consists of the status byte, error byte, and 62 bytes of empty data to pad the segment to 64 bytes.

The format of the second segment of the block is exactly the same as the first. All transmitted data blocks follow this format, except the checksum block. The checksum block contains checksums and other necessary data for bootloader operation. The format of the checksum data block is shown in the following figure:

**Checksum Block Packet**

Packet data (BULK OUT):																	
0000	FF	39	00	01	02	03	04	05	06	07	00	04	00	0D	34	B2	
0010	3F	00	00	00	80	01	00	01	40	15	40	00	AB	3F	FF	01	
0020	00	15	40	30	30	30	30	30	30	30	30	30	30	30	8F	00	00
0030	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	
Status data (BULK IN):																	
0000	01	00	00	00	04	20	00	00	00	00	00	00	00	00	00	00	
0010	00	80	01	00	01	40	15	40	00	AB	3F	FF	01	00	15	40	
0020	00	00	00	00	00	00	00	03	00	40	80	3B	00	00	01		
0030	FF	01	00	00	00	00	00	00	00	00	01	00	00	00	00		

Packet data (BULK OUT):

0000	FF	39	00	01	02	03	04	05	06	07	00	04	01	30	30	30	
0010	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	
0020	30	30	30	30	30	30	30	30	30	30	30	30	30	4D	C0	B2	3F
0030	00	00	00	00	00	00	00	00	00	00	00	00	00	97	00	00	

Status data (BULK IN):

0000	01	00	01	00	04	40	00	00	00	00	00	00	00	00	00	00
0010	00	80	01	00	01	40	15	40	00	AB	3F	FF	01	00	15	40
0020	00	00	00	00	00	00	00	03	00	40	80	3B	00	00	01	

Blue	Checksum of the remainder of 58 bytes of data
Magenta	Reloc Int Vecs address
Red	Checksum block address
Grey	Bootloader start address
Yellow	Application start address
Orange	Application size (in blocks)
Light Green	Device memory size
Cyan	Bootloader version number
Green	Reloc code start address (for Image Craft only)
Light Blue	Application checksum 2's complement
Purple	Application checksum

Depending on device family, checksum block is located at either block 0x0004 or 0x0002 (for this example, block number is 0x0004).

The first line contains the bootloader write block command, the bootloader key, the block number, and block segment just as the other records did. The next two bytes contain the checksum for the last 58 bytes of the block, 0x0D34 in this case. The last byte of the first line and the first byte of the second line contain auxiliary application checksum. If application code is correct then auxiliary application checksum is equal to application checksum, otherwise application code is incorrect.

The next lines contain two-byte values that represent the hex addresses of the Relocatable Interrupt Vectors, Checksum Block, Bootloader Start, Application Start, Application Size, Device Max Memory, Bootloader version number, and Reloc code start address.

Most of the next lines are empty data space. The checksum for the segment occupies the same place in the packet that it did for the other packets. The remainder of the packet is empty space. The second packet of the checksum block begins as all other packets but the only data that it contains is the application checksum and the segment checksum in line three.

The last download packet is the Bootloader Exit command:

**Last Download Packet**

Packet data (BULK OUT):	
0000	FF 38 00 01 02 03 04 05 06 07 00 00 00 00 00 00
0010	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0020	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0030	00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Status data (BULK IN):	
0000	02 00 01 00 00 40 01 00 80 00 00 00 00 00 00 00
0010	00 80 01 00 01 40 15 40 00 AB 3F FF 01 00 15 40
0020	00 00 00 00 00 00 00 00 03 00 40 80 3B 00 00 01
0030	FF 01 00 00 00 00 00 00 00 00 00 01 00 00 00 00

	BootLoader Exit Commands
	BootLoader Key
	Status Byte
	Error Byte
	BootLoader Configuration Data (from Bootloader code)

The bootloader exit command consists of the bootloader exit command 0xFF3B, and the bootloader key.

The final status response consists of a status byte with value 0x02 (Boot Complete OK) and error byte with value 0x00 (no errors). If status and error byte have other values then the bootloading process must have failed.

Figure 5. BootLdrUSBFSe User Module Operations Flowchart (64-byte Flash Block Devices)





Figure 6. BootLdrUSBFSe User Module Operations Flowchart (128-byte Flash Block Devices)



## BootLdrUSBFSe and E2PROM User Module Coexistence

When placing an E2PROM UM in a Bootloader project, allocate E2PROM blocks in Customer Reserved Blocks area. This area is between Bootloader Code Area and Application Code Area (see Bootloader Memory Organization for information). That way E2PROM blocks are not part of the Application Code Area, and will not be calculated as part of Application checksum.

## Version History

Version	Originator	Description
1.0	DHA	Initial version
1.10	DHA	<ol style="list-style-type: none"> <li>1. Removed .Literal/.Endliteral directives around jmp instructions.</li> <li>2. Removed Directives .SECTION and .ENDSECTION for USBFS_bGetProtocol and USBFS_UpdateHIDTimer functions in the USB_cls_hid.asm.</li> </ol>
1.20	DHA	<ol style="list-style-type: none"> <li>1. Added verification of the writing EP0_CR.</li> <li>2. Added verification of the SIE MODEs and ACK bit into the EP0 ISR.</li> <li>3. Increased Bootloader area.</li> <li>4. Added help file to wizard.</li> <li>5. Replaced .Literal and .EndLiteral statements with .nocc around SSC call.</li> <li>6. Removed export `@INSTANCE_NAME`_EnterBootloader statement.</li> </ol>
1.30	DHA	<ol style="list-style-type: none"> <li>1. Moved Application Descriptors from "AREA UserModules" to "AREA lit".</li> <li>2. Added initialization of USB_Protocol variable to comply with HID specification.</li> <li>3. Added support to display bootloader output files in Workspace Explorer.</li> <li>4. Corrected the Large Memory Model mode directives to address compile errors.</li> <li>5. Added the automatic frequency locking of the internal oscillator to the USB traffic into bootResetIsr() function for Encore III devices.</li> <li>6. Added description in the "Improper Settings in Flashsecurity.txt" section.</li> </ol>
1.40	DHA	<ol style="list-style-type: none"> <li>1. Updated Figure 3 and Figure 4.</li> </ol>
1.50	DHA	<ol style="list-style-type: none"> <li>1. Fixed `@INSTANCE_NAME`_bCheckActivity API function to prevent missed activity.</li> <li>2. Added CYRF89235 device support.</li> <li>3. Limited BootLoaderKey parameter to 16 symbols.</li> </ol>

Version	Originator	Description
2.00	HPHA	<ol style="list-style-type: none"> <li>1. Added the capability to override USB Application requests routines through the USB bootloader.</li> <li>2. Added the capability to override routines for Not_Supported requests.</li> <li>3. The checksum verification was moved from startup to bootload complete stage to accelerate application startup and met USB compliance</li> </ol>
3.00	MYKZ	<ol style="list-style-type: none"> <li>1. Corrected BL_USBFS_bReadOutEP function to eliminate changes of CPU clock in CY8C20xx6 family.</li> <li>2. Added CY8C24x93 and CY7C69000 support.</li> <li>3. Added a warning message to notify the user when the user module is removed from a project.</li> <li>4. Fixed memory overlap problem: variables used by both Bootloader and Application were locked at the end of RAM page 0.</li> </ol>
3.00.b	HPHA	Improved the algorithm that sets the "Relocatable code start address" parameter of the ImageCraft compiler.

**Note** PSoC Designer 5.1 introduces a Version History in all user module datasheets. This section documents high level descriptions of the differences between the current and previous user module versions.

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Cypress Semiconductor](#):

[CY8CTMG200A-48LTXIT](#) [CY8CTMG201A-48LTXIT](#) [CY8CTMG120-56LTXIT](#) [CY8CTMG201A-48LTXI](#)  
[CY8CTMG120-56LTXI](#) [CY8CTMG200A-48LTXI](#)