



# **GLK12232A-25-SM/GLT12232A-SM**

---

Including GLK12232A-25-SM-USB and GLT12232A-SM-USB

## **Technical Manual**

**Revision 3.4**

**PCB Revision: 3.0 or Higher**

**Firmware Revision: 8.4 or Higher**

## Revision History

Revision	Date	Description	Author
3.4	October 19, 2015	Minor command updates	Clark
3.3	September 21, 2015	Updated commands for Firmware Revision 8.6	Clark
3.2	January 30, 2015	Updated Drawings	Clark
3.1	May 21, 2014	Added Commands for Firmware Revision 8.5	Martino
3.0	March 13, 2013	Initial Release	Clark

## Contents

1 Introduction .....	1
2 Quick Connect Guide.....	2
2.1 Available Headers .....	2
2.2 Standard Module .....	3
Recommended Parts.....	3
Serial Connections.....	3
I <sup>2</sup> C Connections.....	4
2.3 USB Module .....	4
Recommended Parts.....	4
USB Connections.....	5
3 Software .....	6
3.1 MOGD# .....	6
3.2 Firmware Upgrade .....	7
3.3 Application Notes.....	7
4 Hardware.....	8
4.1 Standard Model .....	8
Extended Communication/Power Header .....	8
I <sup>2</sup> C Communication/Power Header.....	8
Protocol Select Jumpers.....	8
4.2 USB Model.....	9
USB Connector .....	9
Alternate Power Connector .....	9
4.3 Common Features.....	10
General Purpose Outputs .....	10
Hardware Lock .....	10
4.4 GLK Model.....	10
Keypad Header.....	10
4.5 GLT Model.....	11
Touch Screen.....	11
Coordinate Mode .....	11

Region Mode.....	11
5 Troubleshooting.....	12
5.1 Power .....	12
5.2 Display.....	12
5.3 Communication.....	12
5.4 Manual Override .....	13
6 Commands .....	14
6.1 Communication.....	14
6.2 Text.....	16
6.3 Drawing.....	19
6.4 Fonts.....	24
Font File Creation.....	25
6.5 Bitmaps .....	26
Bitmap File Creation.....	27
Bitmap Masking .....	28
6.6 9-Slices .....	28
9-Slice File Creation.....	30
6.7 Animations .....	30
Animation File Creation .....	32
6.8 General Purpose Output.....	32
6.9 Piezo Buzzer .....	32
6.10 Keypad.....	33
6.11 Touchpad .....	35
6.12 Display Functions .....	37
6.13 Scripting .....	38
6.14 Filesystem .....	39
File Upload Protocol.....	42
XModem Upload Protocol .....	43
6.15 Data Security.....	45
6.16 Miscellaneous .....	45
7 Appendix .....	47
7.1 Command Summary .....	47

7.1 Block Diagram .....	52
7.2 Data Types.....	52
7.3 Environmental Specifications.....	53
7.4 Electrical Tolerances .....	53
7.1 Optical Characteristics .....	53
7.2 Dimensional Drawings .....	54
8 Ordering .....	56
8.1 Part Numbering Scheme .....	56
8.2 Options.....	56
8.3 Accessories.....	57
9 Definitions.....	58
10 Contact.....	58



## 1 Introduction



Figure 1: GLK12232A-25-SM/GLT12232A-SM Display

The GLK12232A-25-SM/GLT12232A-SM is an intelligent graphic liquid crystal display engineered to quickly and easily add an elegant creativity to any application. In addition to the RS232, TTL, and I<sup>2</sup>C protocols available in the standard model, the USB communication model allows the GLK12232A-25-SM-USB/GLT12232A-SM-USB to be connected to a wide variety of host controllers. Communication speeds of up to 115.2 kbps in serial modes and 400 kHz in I<sup>2</sup>C ensure lightning fast text and graphic updates.

The simple command structure permits easy software control of many settings including backlight brightness, screen contrast, and baud rate. On board memory provides a whopping 256KB of customizable fonts and bitmaps to enhance the graphical user experience.

User input on the GLK12232A-25-SM is available through a five by five matrix style keypad or a resistive touch overlay on the GLT12232A-SM. In addition, two general purpose outputs provide simple switchable five volt sources on each model, while a small piezo speaker offers audio feedback for a completely interactive experience.

The versatile GLK12232A-25-SM/GLT12232A-SM, with all the features mentioned above, is available in a variety of colour, voltage, and temperature options to suit almost any application.



## 2 Quick Connect Guide

### 2.1 Available Headers




Figure 2: GLK12232A-25-SM/GLT12232A-SM Standard Module Header Locations




Figure 3: GLK12232A-25-SM/GLT12232A-SM USB Module Header Locations

Table 1: List of Available Headers

#	Header	Mate	Population
1	GPO Header	None Offered	All Models
2	Keypad	KPP4x4	GLK Model Only
3	Touchpad	Touch Panel	GLT Model Only
4	USB Connector	EXTUSB6FT	USB Model Only
5	Alternate Power Header	PCS	USB Model Only
6	Communication Header	ESCCPC5V	Standard Model Only
7	I2C Communication/Power Header	None Offered	Standard Model Only



## 2.2 Standard Module

The standard version of the GLK12232A-25-SM/GLT12232A-SM allows for user configuration of two common serial levels. The unit can communicate using serial protocol at either RS323 or TTL voltage levels. Connections for each serial protocol can be accessed through the six pin Communication/Power Header as outlined in the Serial Connections section below.

### Recommended Parts



Figure 4: Extended Communication/Power Cable (ESCCPC5V)

The most common cable choice for any standard Matrix Orbital graphic display, the Extended Communication/ Power Cable offers a simple connection to the unit with familiar interfaces. DB9 and floppy power headers provide all necessary input to drive your display.



Figure 5: Breadboard Cable (BBC)

For a more flexible interface to the GLK12232A-25-SM/GLT12232A-SM, a Breadboard Cable may be used. This provides a simple four wire connection that is popular among developers for its ease of use in a breadboard environment.

### Serial Connections

Serial protocol provides a classic connection to the GLK12232A-25-SM/GLT12232A-SM. The Communication/Power Cable is most commonly used for this set up as it provides connections for DB9 serial and floppy power cables. To place your board in Serial mode, adhere to the steps laid out below.

1. Set the Protocol Select jumpers.
  - RS232: Connect the five jumpers\* in the 232 protocol box with the zero ohm jumper resistors provided or an alternate wire or solder solution.
  - TTL: Connect the four jumpers\* in the TTL protocol box.

**\*Note:** Jumpers must be removed from all protocol boxes save for the one in use.

2. Make the connections.
  - a. Connect the six pin female header of the Communication/Power Cable to the Communication/Power Header of your GLK12232A-25-SM/GLT12232A-SM.
  - b. Insert the male end of your serial cable to the corresponding DB9 header of the Communication/Power Cable and the mate the female connector with the desired communication port of your computer.
  - c. Select an unmodified floppy cable from a PC power supply and connect it to the power header of the Communication/Power Cable.



### 3. Create.

- MOGD# or a terminal program will serve to get you started, and then you can move on with your own development. Instructions for the former can be found below and a variety of application notes are available for the latter at [www.matrixorbital.ca/appnotes](http://www.matrixorbital.ca/appnotes).

### I<sup>2</sup>C Connections

A more advanced connection to the GLK12232A-25-SM/GLT12232A-SM is provided by the I<sup>2</sup>C protocol setting. This is best accomplished using a breadboard and the Breadboard Cable. Power must be supplied from your breadboard or another external source. To dive right into your application and use the GLK12232A-25-SM/GLT12232A-SM in I<sup>2</sup>C mode, get started with the guidelines below.

#### 1. Set the Protocol Select switches.

- I<sup>2</sup>C: Ensure that the two I<sup>2</sup>C jumpers in the corresponding protocol box are connected while all others are open.

#### 2. Make the connections.

- a. Connect the Breadboard Cable to the Communication/Power Header on your GLK12232A-25-SM/GLT12232A-SM and plug the four leads into your breadboard. The red lead will require power, while the black should be connected to ground, and the green and yellow should be connected to your controller clock and data lines respectively.
- b. Pull up the clock and data lines to five volts using a resistance between one and ten kilohms on your breadboard.

#### 3. Create.

- This time you're on your own. While there are many examples within the Matrix Orbital AppNote section, [www.matrixorbital.ca/appnotes](http://www.matrixorbital.ca/appnotes), too many controllers and languages exist to cover them all. If you get stuck in development, it is possible to switch over to another protocol on the standard board, and fellow developers are always on our forums for additional support.

## 2.3 USB Module

The GLK12232A-25-SM-USB/GLT12232A-SM-USB offers a single USB protocol for easy connection to a host computer. The simple and widely available protocol can be accessed using the on board 4pin friction-lock style connector as outlined in the USB Connections section.

### Recommended Parts



The External 4pin USB cable is recommended for the GLK12232A-25-SM-USB/GLT12232A-SM-USB display. It will connect to the friction-locking header on the unit and provide a connection to a regular A style USB connector, up to six feet away.

Figure 6: 4pin USB Cable  
(EXT4PUSB3FT)



## USB Connections

The USB connection is the quickest, easiest solution for PC development. After driver installation, the GLK12232A-25-SM-USB/GLT12232A-SM-USB will be accessible through a virtual serial port, providing the same result as a serial setup without the cable hassle. To connect to your GLK12232A-25-SM-USB/GLT12232A-SM-USB please follow the steps below.

1. Set the Protocol Select jumpers.
  - USB: The GLK12232A-25-SM-USB/GLT12232A-SM-USB offers USB protocol only. Model specific hardware prevents this unit from operating in any other protocol, and does not allow other models to operate in USB. Protocol Select jumpers on the USB model cannot be moved.
2. Make the connections.
  - Plug the friction lock header of your External 4pin USB cable into your GLK12232A-25-SM-USB/GLT12232A-SM-USB and the regular USB header into your computer USB jack.
3. Install the drivers.
  - a. Download the latest drivers at [www.matrixorbital.ca/drivers](http://www.matrixorbital.ca/drivers), and save them to a known location.
  - b. When prompted, install the USB bus controller driver automatically
  - c. If asked, continue anyway, even though the driver is not signed
  - d. When the driver install is complete, your display will turn on, but communication will not yet be possible.
  - e. At the second driver prompt, install the serial port driver automatically
  - f. Again, if asked, continue anyway
4. Create.
  - Use MOGD# or a terminal program to get started, and then move on with your own development. Instructions for the former can be found below and a number of application notes are available for the latter at [www.matrixorbital.ca/appnotes](http://www.matrixorbital.ca/appnotes).



### 3 Software

The communication protocol available and simple command structure of the GLK12232A-25-SM/GLT12232A-SM means that a variety of applications can be used to communicate with the display. Text is sent to the display as a character string, for example, sending the decimal value 41 will result in an 'A' appearing on the screen. A single control character is also available. Commands are merely values prefixed with a special command byte, 254 in decimal.

*Table 2: Reserved Control Characters*

Control Characters	
7	Bell / Sound Buzzer

10	Line feed / New line
----	----------------------

Once the correct communication port is identified, the following communication settings can be applied to communicate correctly with the GLK12232A-25-SM/GLT12232A-SM.

*Table 3: Communication Settings*

BPS	Data Bits	Parity	Stop Bits	Flow Control
19200	8	None	1	None

Finally, with a communication port identified and correctly setup simple text strings or even command bytes can easily be transmitted to control your display.

#### 3.1 MOGD#

The Matrix Orbital Graphic Display interface, MOGD#, is offered as a free download from [www.matrixorbital.ca/software/software\\_graphic](http://www.matrixorbital.ca/software/software_graphic). It provides a simple graphical interface that allows settings, fonts, and bitmaps to be easily customised for any application.

While monochromatic bitmaps can easily be created in virtually any image editing program, MOGD# provides an extensive font generation suite to stylize your display to any project design. In addition to standard font wide modifications, character ranges can be specified by start and end values to eliminate unused symbols, and individual glyphs can be modified with a double click. Finally, text spacing can be tailored and a complete font library built with your Matrix Orbital graphic display.

MOGD# offers a scripting capability that provides the ability to stack, run, and save a series of commands. The most basic function is the Send Numeric tool which is used to transmit a string of values to the display to write text or execute a command.






Figure 7: MOGD# Command Example

Again, the clear screen command is sent to a connected display, this time using the MOGD# Send Numeric function command style. Scripts can be run as a whole using the Play button from the toolbar or as single commands by selecting Step; once executed it must be Reset. Before issuing commands, it is a good idea to ensure communication with a display is successful using the autodetect button.

This program provides both a staging areas for your graphics display and a proving ground that will prepare it for any application environment.

### 3.2 Firmware Upgrade

The firmware of the GLK12232A-25-SM/GLT12232A-SM can be upgraded in the field. All firmware revisions can be installed using software found at [www.matrixorbital.ca/software/GLT Series](http://www.matrixorbital.ca/software/GLT Series).

### 3.3 Application Notes

Full demonstration programs and code are available for Matrix Orbital displays in the C# language from Simple C# AppNote Pack in the Application Note section at [www.matrixorbital.ca/appnotes](http://www.matrixorbital.ca/appnotes).

Many additional applications are available in a number of different programming languages. These programs are meant to showcase the capability of the display and are not intended to be integrated into a final design. For additional information regarding code, please read the On Code document also found on the support site.



## 4 Hardware

### 4.1 Standard Model

#### Extended Communication/Power Header




Table 4: Extended Communication/Power Pinout

Pin	Function
1	Vcc
2	Rx
3	Tx
4	Gnd
5	CTS
6	RTS

Figure 8: Extended Communication/Power Header

The Extended Communication/Power Header provides a standard connector for interfacing to the GLK12232A-25-SM/GLT12232A-SM. Voltage is applied through pins one and four of the six pin Extended Communication/Power Header. Please ensure the correct voltage input for your display by referencing the Voltage Specifications before connecting power. Pins two and three are reserved for serial transmission, using either the RS-232/TTL, depending on what has been selected by the Protocol Select Jumpers. Pins five and six can be used for serial transmission hardware flow control. The Molex 22-04-1061 style header used can be mated to a number of connectors, a 22-01-1062 for example.

#### I<sup>2</sup>C Communication/Power Header




Table 5: I<sup>2</sup>C Communication/Power Pinout

Pin	Function
1	Vcc
2	SCL
3	SDA
4	Gnd

Figure 9: I<sup>2</sup>C Communication/Power Header

Voltage is applied through pins one and four of the header, please reference the electrical specifications before applying power. Pins two and three are reserved for I<sup>2</sup>C clock and data signals respectively, both of which should be pulled up to five volts using a resistance between one and ten kilohms. The Tyco 640456-4-LF style header used can be mated to a number of connectors, including Molex 22-01-3047.

#### Protocol Select Jumpers

The Protocol Select Jumpers provide the means necessary to toggle the GLK12232A-25-SM/GLT12232A-SM between RS-232 and TTL protocols. As a default, the jumpers are set to RS-232 mode with solder jumps on the RS232 jumpers. In order to change the display to TTL mode, simply remove the zero ohm resistors from the RS232 jumpers and solder them to the TTL jumpers.



## 4.2 USB Model

### USB Connector




Figure 10: USB Connector

Table 6: USB Pinout

Pin	Function
1	Gnd
2	D+
3	D-
4	Vcc

The GLK12232A-25-SM-USB/GLT12232A-SM-USB comes with a friction-locking straight pin Connector to fulfill both communication and power needs. Most commonly used with a PC, this connection creates a virtual com port that offers a simple power solution with a familiar communication scheme. The Molex 22-04-1061 style header used can be mated to a number of connectors, a 22-01-1062 for example.

### Alternate Power Connector



Figure 11: Alternate Power Connector

Table 7: Alternate Power Pinout

Pin	Function
1	Vcc
2	Gnd
3	Gnd
4	NC/Vcc

The Alternate Power Connector provides the ability to power the GLK12232A-25-SM-USB/GLT12232A-SM-USB using a second cable. The Tyco 171825-4 style header is particularly useful for connecting to an unmodified floppy power cable, a 171822-4 for example, from a PC power supply for a simple bench power solution.



## 4.3 Common Features

### General Purpose Outputs



Figure 12: GPO Header

Table 8: GPO Pinout

Pin	Function
1	GPO 1
2	Gnd
3	GPO 2
4	Gnd

A unique feature of the GLK12232A-25-SM/GLT12232A-SM is the ability to control relays\* and other external devices using one of two General Purpose Outputs. Each can source up to 3mA of current at three volts when on or sink 3mA at zero volts when off. The four pin header can be interfaced to a number of female connectors to provide control to any peripheral devices required.

**\*Note:** If connecting a relay, be sure that it is fully clamped using a diode and capacitor in order to absorb any electro-motive force (EMF) which will be generated.

### Hardware Lock

The Hardware Lock allows fonts, bitmaps, and settings to be saved, unaltered by any commands. By connecting the two pads near the memory chip, designated Resistor, with a zero ohm resistor, the display will be locked. This supersedes the data lock command and cannot be circumvented by any software means. To unlock the display and make changes simply remove the jumper.

## 4.4 GLK Model

### Keypad Header



Figure 13: Keypad Header

Table 9: Keypad Pinout

Pin	Function	Pin	Function
1	Gnd	7	Column 1
2	Row 1	8	Column 2
3	Row 2	9	Column 3
4	Row 3	10	Column 4
5	Row 4	11	Column 5
6	Row 5	12	Gnd/Vcc*

To facilitate user input, the GLK12232A-25-SM provides a Keypad Interface Connector which allows a matrix style keypad of up to twenty-five keys to be directly connected to the display module. Key presses are generated when a short is detected between a row and a column. When a key press is generated, a character specific to that key press is automatically sent on the Tx communication line. The character that is associated with each key press may be altered using the “Assign Key Codes” command. The straight twelve pin header of the Keypad Interface Connector will interface to a variety of different devices including the Matrix Orbital KPP4x4 keypad.

**\*Note:** The Ground / +3.3V pin is toggled by the jumper to the right of the keypad connector. Jump pads 1 & 2 for +3.3V or 2 & 3 for GND.




## 4.5 GLT Model

### Touch Screen

The GLT12232A-SM facilitates user touch input in one of two distinct ways. Coordinate mode will report events by supplying their exact position on the screen. Region mode will report events within defined boundaries on the screen. Both modes are outlined below.

#### Coordinate Mode




In coordinate mode all touch events are reported using three single byte values. First, the type of event is transmitted, followed by the x and y coordinates of its position. Pressure and drag thresholds must be exceeded for an event to be registered. A low drag threshold will result in greater tracking accuracy but transmits much more data to the host. Care should be taken to find balance. This mode offers a great degree of flexibility and creativity.

Table 10: Coordinate Mode Event Prefixes

Return Value	1	2	4
Touch Event	Press	Release	Drag

#### Region Mode



A simpler, keypad style alternative to coordinate mode, region mode offers only a single byte for each touch event. Unique regions are created by specifying a position, size, and return values. A value corresponding to a specific region is returned when an event occurs within its bounds. Events outside of regions result in transmission of the value 255. Regions can be deleted individually or collectively when no longer needed. This mode allows quick and easy set up.

Table 11: Region Mode Event Responses

Return Value	Key Down	Key Up	Key Down	255
Touch Event	Press	Release	Drag	Out of Region



## 5 Troubleshooting

### 5.1 Power

In order for your Matrix Orbital display to function correctly, it must be supplied with the appropriate power. If the power LED near the top right corner of the board is not illuminated, power is not applied correctly. Try following the tips below.

- First, check the power cable which you are using for continuity. If you don't have an ohm meter, try using a different power cable, if this does not help try using a different power supply.
- Check the interface connector in use on your display. If the power connections have become loose, or you are unable to resolve the issue, please Contact Matrix Orbital.

### 5.2 Display

If your display is powered successfully, the Matrix Orbital logo, or user created screen should display on start up. If this is not the case, check out these tips.

- Ensure the contrast is not too high or too low. This can result in a darkened or blank screen respectively. See the Manual Override section to reset to default.
- Make sure that the start screen is not blank. It is possible to overwrite the Matrix Orbital logo start screen, if this happens the screen may be blank. Try writing to the display to ensure it is functional, after checking the contrast above.

### 5.3 Communication

When communication of either text or commands is interrupted, try the steps below.

- First, check the communication cable for continuity. If you don't have an ohm meter, try using a different communication cable. If you are using a PC try using a different USB Port.
- In USB protocol, ensure that the host system and display module are both communicating on the same baud rate. The default rate for the display module is 19200 bps.
- Unlock the display. See the Set and Save Data Lock command for more info.
- Finally, you may reset the display to its default settings using the Manual Override procedure outlined below.



## 5.4 Manual Override

Should the settings of your display become altered in a way that dramatically impacts usability, the default settings can be temporarily restored. To override the display, please follow the steps below.

1. Disconnect power from your display.
2. Place a jumper on the two manual override pins, for the GLK model these are the middle two keypad pins, for the GLT these are the only two pins on the keypad header.
3. Reconnect power to your unit, and wait for the start screen before removing the jumper. Please note the jumper will adversely affect GLT12232A-SM performance if left in place during use.
4. Settings will be temporarily\* overridden to the defaults listed in the Manual Override Settings table. At this point any important settings, such as contrast, backlight, or baud rate, should not only be set but saved so they remain when the override is removed.

Parameter	Value
Backlight	255
Contrast	128
Baud Rate	19200

*Table 12: Manual Override Settings*

**\*Note:** The display module will revert back to the old settings once turned off, unless desired settings are saved.



## 6 Commands

### 6.1 Communication

1.1 Change Baud Rate	Dec Hex ASCII	254 57 FE 39 ■ 9	Speed Speed Speed	v8.0
Immediately changes the baud rate. Baud rate can be temporarily forced to 19200 by a manual override.				
<b>Speed</b> <b>Byte</b> Valid settings shown below.				

Table 13: Accepted Baud Rate Values

Rate	9600	14400	19200	28800	38400	57600	76800	115200
Speed	207	138	103	68	51	34	25	16

1.2 Change I2C Slave Address	Dec Hex ASCII	254 51 FE 33 ■ 3	Address Address Address	v8.0
Immediately changes the I2C write address. Only even values are permitted as the next odd address will become the read address. Default is 80.				
<b>Address</b> <b>Byte</b> Even value.				

1.3 Transmission Protocol Select	Dec Hex ■ á	254 160 FE A0 Protocol	v8.0	
Selects the protocol used for data transmission from the display. Data transmission to the display is not affected. Must be set to the protocol in use to receive data correctly.				
<b>Protocol</b> <b>Byte</b> 1 for Serial (RS232/RS422/TTL/USB) or 0 for I2C.				

1.4 Set a Non-Standard Baud Rate	Dec Hex ASCII	254 164 FE A4 ■ ñ	Speed Speed Speed	v5.0
Immediately changes the baud rate to a non-standard value. Speed must be a whole number between 977 and 153800. Due to rounding, error increases with baud rate, actual baud must be within 3% of desired baud to ensure accurate communication. Not available in I2C. Can be temporarily forced to 19200 by a manual override.				
<b>Speed</b> <b>Short</b> Calculations shown below, standard crystal speed is 16MHz.				

$$Speed = \frac{CrystalSpeed}{(8 \times DesiredBaud)} - 1 \quad ActualBaud = \frac{CrystalSpeed}{(8 \times (Speed + 1))}$$

Equation 1: Speed Byte Calculation

Equation 2: Actual Baud Rate Calculation

$$\frac{|DesiredBaud - ActualBaud|}{DesiredBaud} < 0.03$$

Equation 3: Baud Rate Error Calculation



1.5 Set Flow Control Mode	Dec <b>254 63</b>	Mode	<b>v8.0</b>
	Hex <b>FE 3F</b>	Mode	
	ASCII <b>■ ?</b>	Mode	

Toggles flow control between hardware, software and off settings. Software and Hardware control can be further tuned using the settings above. Default is Off, or 0.

**Mode** **Byte** Flow control setting as below.

Table 14: Hardware Flow Control Trigger Levels

Bytes	1	4	8	14
Level	0	1	2	3

Flow Control	None	Software	Hardware
Mode	0	1	2

Table 15: Flow Control Settings

1.6 Set Hardware Flow Control Trigger Level	Dec <b>254 62</b>	Level	<b>v8.0</b>
	Hex <b>FE 3E</b>	Level	
	ASCII <b>■ &gt;</b>	Level	

Sets the hardware flow control trigger level. The Clear To Send signal will be deactivated once the number of characters in the display buffer reaches the level set; it will be reactivated once all data in the buffer is handled.

**Level** **Byte** Trigger level as above.

1.7 Turn Software Flow Control On	Dec <b>254 58</b>	Almost Full	Almost Empty	<b>v8.0</b>
	Hex <b>FE 3A</b>	Almost Full	Almost Empty	
	ASCII <b>■ :</b>	Almost Full	Almost Empty	

Enables simple flow control. The display will return a single, Xoff, byte to the host when the display buffer is almost full and a different, Xon, byte when the buffer is almost empty. Full value should provide enough room for the largest data packet to be received without buffer overflow. No data should be sent to the display between full and empty responses to permit processing. Buffer size is 256\* bytes. Not available in I<sup>2</sup>C. Default off.

**Almost Full** **Byte** Number of bytes remaining before buffer is completely full, 0 < Full < Empty < 256\*.

**Almost Empty** **Byte** Number of bytes before buffer can be considered empty enough to accept data.

**\*Note:** Buffer size was increased to 256 bytes from 128 bytes at firmware revision 8.3.

1.8 Turn Software Flow Control Off	Dec <b>254 59</b>	<b>v8.0</b>
	Hex <b>FE 3B</b>	
	ASCII <b>■ ;</b>	

Disables flow control. Bytes sent to the display may be permitted to overflow the buffer resulting in data loss.

1.9 Set Software Flow Control Response	Dec <b>254 60</b>	Xon	Xoff	<b>v8.0</b>
	Hex <b>FE 3C</b>	Xon	Xoff	
	ASCII <b>■ &lt;</b>	Xon	Xoff	

Sets the values returned for almost full and almost empty messages when in flow control mode. This command permits the display to utilize standard flow control values of 0x11 and 0x13, note that defaults are 0xFF and 0xFE.

**Xon** **Byte** Value returned when display buffer is almost empty, permitting transmission to resume.

**Xoff** **Byte** Value returned when display buffer is almost full, signaling transmission to halt.



1.10 Echo	Dec	<b>254 255</b>	Length Data	v8.3
	Hex	<b>FE FF</b>	Length Data	
	ASCII	■	Length Data	

Send data to the display that it will echo. Useful to confirm communication or return information from scripts.

Length	Word	Length of data array to be echoed.
Data	Byte(s)	An arbitrary array of data that the module will return.
Response	Byte(s)	The same arbitrary array of data originally sent.

1.11 Delay	Dec	<b>254 251</b>	Time	v8.3
	Hex	<b>FE FB</b>	Time	
	ASCII	■ V	Time	

Pause command execution to and responses from the display for the specified length of time.

Time	Word	Length of delay in ms, maximum 2000.
------	------	--------------------------------------

1.12 Software	Dec	<b>254 253 77 79 117 110</b>	v8.4
Reset	Hex	<b>FE FD 4D 4F 75 6E</b>	
	ASCII	■ ² M O u n	

Reset the display as if power had been cycled via a software command. No commands should be sent while the unit is in the process of resetting; a response will be returned to indicate the unit has successfully been reset.

Response	Word	Successful reset response, 254 214.
----------	------	-------------------------------------

## 6.2 Text

2.1 Clear	Dec	<b>254 88</b>	v8.0
Screen	Hex	<b>FE 58</b>	
	ASCII	■ X	

Clears the contents of the screen.

2.2 Go	Dec	<b>254 72</b>	v8.0
Home	Hex	<b>FE 48</b>	
	ASCII	■ H	

Returns the cursor to the top left of the screen.

2.3 Set Cursor	Dec	<b>254 71</b>	Column Row	v8.0
Position	Hex	<b>FE 47</b>	Column Row	
	ASCII	■ G	Column Row	

Sets the cursor to a specific cursor position where the next transmitted character is printed.

Column	Byte	Value between 1 and number of character columns.
Row	Byte	Value between 1 and number of character rows.



2.4 Set Cursor Coordinate	Dec <b>254 121</b>	X Y	<b>v8.0</b>
	Hex <b>FE 79</b>	X Y	
	ASCII <b>■ y</b>	X Y	

Sets the cursor to an exact pixel position where the next transmitted character is printed.

**X** **Byte** Value between 1 and screen width, represents leftmost character position.

**Y** **Byte** Value between 1 and screen height, represents topmost character position.

2.5 Get String Extents	Dec <b>254 41</b>	Text	<b>v8.6</b>
	Hex <b>FE 29</b>	Text	
	ASCII <b>■ )</b>	Text	

Read the size of the rectangle that the specified string would occupy if it was rendered with the current font.

**Text** **String** String on which to preform extents calculation. A single line of text is assumed.

**Response** **Byte(s)** Width and height of the string in pixels. A width greater than the screen will return 0.

2.6 Initialize Text Window	Dec <b>254 43</b>	ID X1 Y1 X2 Y2 Font CharSpace LineSpace Scroll	<b>v8.3</b>
	Hex <b>FE 2B</b>	ID X1 Y1 X2 Y2 Font CharSpace LineSpace Scroll	
	ASCII <b>■ +</b>	ID X1 Y1 X2 Y2 Font CharSpace LineSpace Scroll	

Designates a portion of the screen to which text can be confined. Font commands affect only the current window, default (entire screen) is window 0.

<b>ID</b>	<b>Byte</b>	Unique text window identification number, value between 0 and 15.
<b>X1</b>	<b>Byte</b>	Leftmost coordinate.
<b>Y1</b>	<b>Byte</b>	Topmost coordinate.
<b>X2</b>	<b>Byte</b>	Rightmost coordinate.
<b>Y2</b>	<b>Byte</b>	Bottommost coordinate.
<b>*Font</b>	<b>Short</b>	Unique font ID to use for this window, value between 0 and 1023.
<b>CharSpace</b>	<b>Byte</b>	Spacing between characters to use for this window.
<b>LineSpace</b>	<b>Byte</b>	Spacing between lines to use for this window.
<b>Scroll</b>	<b>Byte</b>	Number of pixel rows to write to before scrolling text.

**\*Note:** Font was changed from a Byte length at firmware revision 8.5

2.7 Set Text Window	Dec <b>254 42</b>	ID	<b>v8.3</b>
	Hex <b>FE 2A</b>	ID	
	ASCII <b>■ *</b>	ID	

Sets the text window to which subsequent text and commands will apply. Default (entire screen) is window 0.

**ID** **Byte** Unique text window to use.

2.8 Clear Text Window	Dec <b>254 44</b>	ID	<b>v8.3</b>
	Hex <b>FE 2C</b>	ID	
	ASCII <b>■ ,</b>	ID	

Clears the contents of a specific text window, similar to the clear screen command.

**ID** **Byte** Unique text window to clear.



2.9 Initialize Label	Dec <b>254 45</b>	ID X1 Y1 X2 Y2 Vert Hor Font Background CharSpace	<b>v8.3</b>
	Hex <b>FE 2D</b>	ID X1 Y1 X2 Y2 Vert Hor Font Background CharSpace	
	ASCII      ■ -	ID X1 Y1 X2 Y2 Vert Hor Font Background CharSpace	

Designates a portion of the screen that can be easily updated with one line of text, often used to display variables.

<b>ID</b>	<b>Byte</b>	Unique label identification number, value between 0 and 15.
<b>X1</b>	<b>Byte</b>	Leftmost coordinate.
<b>Y1</b>	<b>Byte</b>	Topmost coordinate.
<b>X2</b>	<b>Byte</b>	Rightmost coordinate.
<b>Y2</b>	<b>Byte</b>	Bottommost coordinate.
<b>Vert</b>	<b>Byte</b>	Vertical justification of the label text; 0 for top, 1 for middle, or 2 for bottom.
<b>Hor</b>	<b>Byte</b>	Horizontal justification of the label text; 0 for left, 1 for centre, or 2 for right.
<b>Font</b>	<b>Short</b>	Unique font ID to use for this label, value between 0 and 1023.
<b>Background</b>	<b>Byte</b>	State of the pixels in the label region that is not occupied by text; 0 for off or 1 for on.
<b>CharSpace</b>	<b>Byte</b>	Spacing between characters to use for this label.

**\*Note:** Font was changed from a Byte length at firmware revision 8.5

2.10 Initialize Scrolling Label	Dec <b>254 47</b>	ID X1 Y1 X2 Y2 Vert Dir Font Background CharSpace Delay	<b>v8.6</b>
	Hex <b>FE 2F</b>	ID X1 Y1 X2 Y2 Vert Dir Font Background CharSpace Delay	
	ASCII      ■ /	ID X1 Y1 X2 Y2 Vert Dir Font Background CharSpace Delay	

Designates a portion of the screen that can be easily updated with one line of text, often used to display variables.

<b>ID</b>	<b>Byte</b>	Unique label identification number, value between 0 and 15.
<b>X1</b>	<b>Byte</b>	Leftmost coordinate.
<b>Y1</b>	<b>Byte</b>	Topmost coordinate.
<b>X2</b>	<b>Byte</b>	Rightmost coordinate.
<b>Y2</b>	<b>Byte</b>	Bottommost coordinate.
<b>Vert</b>	<b>Byte</b>	Vertical justification of the label text; 0 for top, 1 for middle, or 2 for bottom.
<b>Dir</b>	<b>Byte</b>	Direction of the scrolling behavior; 0 for left, 1 for right, or 2 for bounce.
<b>Font</b>	<b>Short</b>	Unique font ID to use for this label, value between 0 and 1023.
<b>Background</b>	<b>Byte</b>	State of the pixels in the label region that is not occupied by text; 0 for off or 1 for on.
<b>CharSpace</b>	<b>Byte</b>	Spacing between characters to use for this label.
<b>Delay</b>	<b>Short</b>	Time in milliseconds to elapse between characters printed.

2.11 Update Label	Dec <b>254 46</b>	ID Data	<b>v8.3</b>
	Hex <b>FE 2E</b>	ID Data	
	ASCII      ■ .	ID Data	

Update a previously created label with new text. Send a null character (empty string) to clear a label.

<b>ID</b>	<b>Byte</b>	Unique label to update, between 0 and 15.
<b>Data</b>	<b>String</b>	Information to display in the label, must be terminated with a null (value of zero) byte.

2.12 Auto Scroll On	Dec <b>254 81</b>		<b>v8.0</b>
	Hex <b>FE 51</b>		
	ASCII      ■ Q		

The entire contents of screen are shifted up one line when the end of the screen is reached. Display default is on.



2.13 Auto Scroll Off	Dec <b>254 82</b> Hex <b>FE 52</b> ASCII     ■ R	<b>v8.0</b>
-------------------------	--	-------------

New text is written over the top line when the end of the screen is reached. Display default is Auto Scroll on.

### 6.3 Drawing

3.1 Set Drawing Colour	Dec <b>254 99</b> Colour Hex <b>FE 63</b> Colour ASCII     ■ c   Colour	<b>v8.0</b>
---------------------------	---	-------------

Set the monochrome colour to be used for all future drawing commands that do not implicitly specify colour.

**Colour**   **Byte**   0 for inactive (background) colour or any other value for active (text) colour.

3.2 Draw Pixel	Dec <b>254 112</b> X Y Hex <b>FE 70</b> X Y ASCII     ■ p   X Y	<b>v8.0</b>
-------------------	---	-------------

Draw a single pixel at the specified coordinate using the current drawing colour.

**X**   **Byte**   Horizontal position of pixel to be drawn.

**Y**   **Byte**   Vertical position of pixel to be drawn.

3.3 Draw a Line	Dec <b>254 108</b> X1 Y1 X2 Y2 Hex <b>FE 6C</b> X1 Y1 X2 Y2 ASCII     ■ l   X1 Y1 X2 Y2	<b>v8.0</b>
--------------------	---	-------------

Draw a line connecting two termini. Lines may be rendered differently when drawn right to left versus left to right.

**X1**   **Byte**   Horizontal coordinate of first terminus.

**Y1**   **Byte**   Vertical coordinate of first terminus.

**X2**   **Byte**   Horizontal coordinate of second terminus.

**Y2**   **Byte**   Vertical coordinate of second terminus.

3.4 Continue a Line	Dec <b>254 101</b> X Y Hex <b>FE 65</b> X Y ASCII     ■ e   X Y	<b>v8.0</b>
------------------------	---	-------------

Draw a line from the last point drawn to the coordinate specified using the current drawing colour.

**X**   **Byte**   Left coordinate of terminus.

**Y**   **Byte**   Top coordinate of terminus.



3.5 Draw a Rectangle	Dec <b>254 114</b>	Colour X1 Y1 X2 Y2	<b>v8.0</b>
	Hex <b>FE 72</b>	Colour X1 Y1 X2 Y2	
	ASCII <b>■ r</b>	Colour X1 Y1 X2 Y2	

Draw a rectangular frame one pixel wide using the colour specified; current drawing colour is ignored.

Colour	Byte	0 for background or any other value for text colour.
X1	Byte	Leftmost coordinate.
Y1	Byte	Topmost coordinate.
X2	Byte	Rightmost coordinate.
Y2	Byte	Bottommost coordinate.

3.6 Draw a Filled Rectangle	Dec <b>254 120</b>	Colour X1 Y1 X2 Y2	<b>v8.0</b>
	Hex <b>FE 78</b>	Colour X1 Y1 X2 Y2	
	ASCII <b>■ x</b>	Colour X1 Y1 X2 Y2	

Draw a filled rectangle using the colour specified; current drawing colour is ignored.

Colour	Byte	0 for background or any other value for text colour.
X1	Byte	Leftmost coordinate.
Y1	Byte	Topmost coordinate.
X2	Byte	Rightmost coordinate.
Y2	Byte	Bottommost coordinate.

3.7 Draw a Rounded Rectangle	Dec <b>254 128</b>	X1 Y1 X2 Y2 Radius	<b>v8.3</b>
	Hex <b>FE 80</b>	X1 Y1 X2 Y2 Radius	
	ASCII <b>■ ¢</b>	X1 Y1 X2 Y2 Radius	

Draw a rounded rectangular frame one pixel wide using the current drawing colour.

X1	Byte	Leftmost coordinate of the rectangle.
Y1	Byte	Topmost coordinate of the rectangle.
X2	Byte	Rightmost coordinate.
Y2	Byte	Bottommost coordinate.
Radius	Byte	Radius of curvature of the rectangle corners.

3.8 Draw a Filled Rounded Rectangle	Dec <b>254 129</b>	X1 Y1 X2 Y2 Radius	<b>v8.3</b>
	Hex <b>FE 81</b>	X1 Y1 X2 Y2 Radius	
	ASCII <b>■ ü</b>	X1 Y1 X2 Y2 Radius	

Draw a filled rounded rectangle using the current drawing colour.

X1	Byte	Leftmost coordinate of the rectangle.
Y1	Byte	Topmost coordinate of the rectangle.
X2	Byte	Rightmost coordinate.
Y2	Byte	Bottommost coordinate.
Radius	Byte	Radius of curvature of the rectangle corners.



3.9 Draw a Circle	Dec <b>254 123</b> X Y Radius Hex <b>FE 7B</b> X Y Radius ASCII <b>■ {</b> X Y Radius	<b>v8.3</b>
Draw a circular frame one pixel wide using the current drawing colour.		
X	Byte	Horizontal coordinate of the circle centre.
Y	Byte	Vertical coordinate of the circle centre.
Radius	Byte	Distance between the circle perimeter and centre.

3.10 Draw a Filled Circle	Dec <b>254 124</b> X Y Radius Hex <b>FE 7C</b> X Y Radius ASCII <b>■  </b> X Y Radius	<b>v8.3</b>
Draw a filled circle using the current drawing colour.		
X	Byte	Horizontal coordinate of the circle centre.
Y	Byte	Vertical coordinate of the circle centre.
Radius	Byte	Distance between the circle perimeter and centre.

3.11 Draw an Ellipse	Dec <b>254 125</b> X Y XRadius XRadius Hex <b>FE 7D</b> X Y XRadius XRadius ASCII <b>■ }</b> X Y XRadius XRadius	<b>v8.3</b>
Draw an elliptical frame one pixel wide using the current drawing colour.		
X	Byte	Horizontal coordinate of the ellipse centre.
Y	Byte	Vertical coordinate of the ellipse centre.
XRadius	Byte	Distance between the furthest horizontal point on the ellipse perimeter and centre.
YRadius	Byte	Distance between the furthest vertical point on the ellipse perimeter and centre.

3.12 Draw a Filled Ellipse	Dec <b>254 127</b> X Y XRadius XRadius Hex <b>FE 7F</b> X Y XRadius XRadius ASCII <b>■ DEL</b> X Y XRadius XRadius	<b>v8.3</b>
Draw an ellipse using the current drawing colour.		
X	Byte	Horizontal coordinate of the ellipse centre.
Y	Byte	Vertical coordinate of the ellipse centre.
XRadius	Byte	Distance between the furthest horizontal point on the ellipse perimeter and centre.
YRadius	Byte	Distance between the furthest vertical point on the ellipse perimeter and centre.

3.13 Scroll Screen	Dec <b>254 89</b> X1 Y1 X2 Y2 MoveX MoveY Hex <b>FE 59</b> X1 Y1 X2 Y2 MoveX MoveY ASCII <b>■ Y</b> X1 Y1 X2 Y2 MoveX MoveY	<b>v8.3</b>
Define and scroll the contents of a portion of the screen.		
X1	Byte	Leftmost coordinate of the scroll window.
Y1	Byte	Topmost coordinate of the scroll window.
X2	Byte	Rightmost coordinate of the scroll window.
Y2	Byte	Bottommost coordinate of the scroll window.
MoveX	Signed Word	Number of pixels to scroll horizontally.
MoveY	Signed Word	Number of pixels to scroll vertically.



3.14 Initialize a Bar Graph	Dec <b>254 103</b>	ID Type X1 Y1 X2 Y2	<b>v8.3</b>
	Hex <b>FE 67</b>	ID Type X1 Y1 X2 Y2	
	ASCII      ■ g	ID Type X1 Y1 X2 Y2	

Initialize a bar graph in memory for later implementation. Graphs can be located anywhere on the screen, but overlapping may cause distortion. Graph should be filled using the Draw a Bar Graph command.

<b>ID</b>	<b>Byte</b>	Unique bar identification number, between 0 and 255.
<b>Type</b>	<b>Byte</b>	Graph style, see Bar Graph Types.
<b>X1</b>	<b>Byte</b>	Leftmost coordinate.
<b>Y1</b>	<b>Byte</b>	Topmost coordinate.
<b>X2</b>	<b>Byte</b>	Rightmost coordinate.
<b>Y2</b>	<b>Byte</b>	Bottommost coordinate.

Table 16: Bar Graph Types

	<b>Direction</b>	<b>Base</b>
<b>0</b>	Vertical	Bottom
<b>1</b>	Horizontal	Left
<b>2</b>	Vertical	Top
<b>3</b>	Horizontal	Right

3.15 Initialize 9-Slice Bar Graph	Dec <b>254 115</b>	ID Type X1 Y1 X2 Y2 Fore 9Slice Back 9Slice	<b>v8.3</b>
	Hex <b>FE 73</b>	ID Type X1 Y1 X2 Y2 Fore 9Slice Back 9Slice	
	ASCII      ■ s	ID Type X1 Y1 X2 Y2 Fore 9Slice Back 9Slice	

Initialize a 9-slice bar graph in memory for later implementation. 9-slice graphs are also be filled using the Draw a Bar Graph command and are allocated to the same memory as regular bitmaps.

<b>ID</b>	<b>Byte</b>	Unique bar identification number, between 0 and 255.
<b>Type</b>	<b>Byte</b>	Graph style, see Bar Graph Types.
<b>X1</b>	<b>Byte</b>	Leftmost coordinate.
<b>Y1</b>	<b>Byte</b>	Topmost coordinate.
<b>X2</b>	<b>Byte</b>	Rightmost coordinate.
<b>Y2</b>	<b>Byte</b>	Bottommost coordinate.
<b>Fore 9Slice</b>	<b>Word</b>	9-slice used for the foreground.
<b>Back 9Slice</b>	<b>Word</b>	9-slice used for the background.

3.16 Draw a Bar Graph	Dec <b>254 105</b>	ID Value	<b>v8.3</b>
	Hex <b>FE 69</b>	ID Value	
	ASCII      ■ i	ID Value	

Fill in a portion of a bar graph after initialization. Any old value will be overwritten by the new. Setting a value of zero before setting a new value will restore a graph should it become corrupted.

<b>ID</b>	<b>Byte</b>	Unique bar identification number, between 0 and 255.
<b>Value</b>	<b>Byte</b>	Portion of graph to fill in pixels, will not exceed display bounds.



3.17 Initialize a Strip Chart	Dec <b>254 110</b>	ID X1 Y1 X2 Y2 Min Max Step Style ID	<b>v8.3</b>
	Hex <b>FE 6E</b>	ID X1 Y1 X2 Y2 Min Max Step Style ID	
	ASCII <b>■ n</b>	ID X1 Y1 X2 Y2 Min Max Step Style ID	

Designate a portion of the screen for a chart. Visual changes will occur when the update command is issued.

<b>ID</b>	<b>Byte</b>	Unique chart identification number, value between 0 and 7.
<b>X1</b>	<b>Byte</b>	Leftmost coordinate of the strip chart, zero indexed from left.
<b>Y1</b>	<b>Byte</b>	Topmost coordinate of the strip chart, zero indexed from top.
<b>X2</b>	<b>Byte</b>	Rightmost coordinate of the strip chart, zero indexed from left.
<b>Y2</b>	<b>Byte</b>	Bottommost coordinate of the strip chart, zero indexed from top.
<b>Min</b>	<b>Short</b>	Minimum chart value.
<b>Max</b>	<b>Short</b>	Maximum chart value. For line styles, make max-min at least one pixel less than chart height.
<b>Step</b>	<b>Byte</b>	Scroll distance between updates, in pixels.
<b>Style</b>	<b>Byte</b>	Chart style value which is an OR'd combination of type and direction, as per the tables below.
<b>ID</b>	<b>Short</b>	9-slice file ID, if a 9-slice style strip chart is not desired send any value for this parameter.

Table 17: Strip Chart Directions (Bytes 7-4)

Direction	Description
0	Bottom origin, left shift
32	Left origin, upward shift
64	Top origin, right shift
96	Right origin, downward shift
128	Bottom origin, right shift
160	Left origin, downward shift
192	Top origin, left shift
224	Right origin, upward shift

Table 18: Strip Chart Types (Bytes 3-0)

Type	Description
0	Bar
1	Line
2	Step
3	Box
4	9-slice
5	Separated Bar
6	Separated Box

3.18 Update a Strip Chart	Dec <b>254 111</b>	ID Value	<b>v8.3</b>
	Hex <b>FE 6F</b>	ID Value	
	ASCII <b>■ o</b>	ID Value	
Shift the specified strip chart and draw a new value.			
<b>ID</b>	<b>Byte</b>	Chart identification number, between 0 and 7.	
<b>Value</b>	<b>Word</b>	Value to add to the chart.	



## 6.4 Fonts

4.1 Upload a Font File	Dec <b>254 36</b>	ID      Size Data	<b>v8.1</b>
	Hex <b>FE 24</b>	ID      Size Data	
	ASCII      ■ \$	ID      Size Data	

Upload a font to a graphic display. To create a font see the Font File Creation section, for upload protocol see the File Upload Protocol or XModem Upload Protocol entries. Default font is ID 1.

<b>ID</b>	<b>Short</b>	Unique font identification number, value between 0 and 1023.
<b>Size</b>	<b>Integer</b>	Size of the entire font file.
<b>Data</b>	<b>Byte(s)</b>	Font file data, see the Font File Creation example.

4.2 Set the Current Font	Dec <b>254 49</b>	ID	<b>v8.0</b>
	Hex <b>FE 31</b>	ID	
	ASCII      ■ 1	ID	

Set the font in use by specifying a unique identification number. Characters sent after the command will appear in the font specified; previous text will not be affected. Default is 1.

<b>*ID</b>	<b>Short</b>	Unique font identification number, value between 0 and 1023.
------------	--------------	--

**\*Note:** ID was changed from a Byte length at firmware revision 8.5

4.3 Set Font Metrics	Dec <b>254 50</b>	LineMargin TopMargin CharSpace LineSpace Scroll	<b>v8.0</b>
	Hex <b>FE 32</b>	LineMargin TopMargin CharSpace LineSpace Scroll	
	ASCII      ■ 2	LineMargin TopMargin CharSpace LineSpace Scroll	

Set the font spacing, or metrics, used with the current font. Changes only appear in text sent after command.

<b>LineMargin</b>	<b>Byte</b>	Space between left of display and first column of text. Default 0.
<b>TopMargin</b>	<b>Byte</b>	Space between top of display area and first row of text. Default 0.
<b>CharSpace</b>	<b>Byte</b>	Space between characters. Default 0.
<b>Line Space</b>	<b>Byte</b>	Space between character rows. Default 1.
<b>Scroll</b>	<b>Byte</b>	Point at which text scrolls up screen to display additional rows. Default 1.

4.4 Set Box Space Mode	Dec <b>254 172</b>	Switch	<b>v8.0</b>
	Hex <b>FE AC</b>	Switch	
	ASCII      ■ ¼	Switch	

Toggle box space on or off. When on, a character sized box is cleared from the screen before a character is written. This eliminates any text or bitmap remnants behind the character. Default is on.

<b>Switch</b>	<b>Byte</b>	1 for on or 0 for off.
---------------	-------------	------------------------



## Font File Creation

Matrix Orbital graphic displays are capable of displaying text in a wide variety of styles customizable to suit any project design. Front files alter the style of text and appearance of the display.

By default, a Matrix Orbital graphic display is loaded with a small filled font in slot one and a future bk bt 16 style in slot two. Both are available at [www.matrixorbital.ca/software/graphic\\_fonts](http://www.matrixorbital.ca/software/graphic_fonts).

The easiest way to create, add, or modify the fonts of any graphic display is through the MOGD# tool. This provides a simple graphic interface that hides the more complex intricacies of the font file.

Table 19: Example Font File Header

Maximum Width	Character Height	ASCII Start Value	ASCII End Value
5	7	104	106

The font file header contains four bytes: First, the number of columns in the widest character; usually 'w', second, the pixel height of each character, and finally, the start and end values of the character range. The range represents the values that must be sent to the display to trigger the characters to appear on the screen. In the example, the decimal values corresponding to the lowercase letters 'h' through 'j' will be used resulting in the range shown.

Table 20: Example Character Table

	MSB	LSB	Width
h	0	13	5
i	0	18	3
j	0	21	4

The character table contains information that allows the display to locate each individual character in a mass of character data. Each character has three bytes; two indicating it's offset in the character data and one indicating its width. The offset takes into account the header and table bytes to point to the first byte of the character data it references. The first byte of the file, maximum width, has an offset of zero. The width byte of each character can be identical as in a fixed width font, or in our case, variable. The character table will become clearer after analyzing the final part of the font file, character data.

Table 21: Character 'h'

Bitmap

1	0	0	0	0
1	0	0	0	0
1	0	1	1	0
1	1	0	0	1
1	0	0	0	1
1	0	0	0	1
1	0	0	0	1

Table 22: Character 'h' Data

1	0	0	0	0	0	1	0	0	84	132
0	0	1	0	1	1	0	1	2D	45	
1	0	0	1	1	0	0	0	98	152	
1	1	0	0	0	1	1	0	C6	198	
0	0	1	0	0	0	0	0	20	32	



The character data is a binary graphical representation of each glyph in a font. Each character is drawn on a grid containing as many rows as the height specified in the header and as many columns as the width specified in the character table. Cells are drawn by writing a one in their location and cleared by setting a value of zero. Starting at the top left, moving right, then down, eight of these cells form a character data byte. When all cells are accounted for, zeroes may be added to the last byte to complete it. A sample of an 'h' glyph is shown above. The data for the 'i' and 'j' characters will follow to complete the custom font file displayed below.

Table 23: Example Font File

Header	5 7 104 106
Character Table	0 13 5
	0 18 3
	0 21 4
Character Data	132 45 152 198 32
	67 36 184
	16 49 25 96

## 6.5 Bitmaps

5.1 Upload a Bitmap File	Dec <b>254 94</b>	ID	Size Data	<b>v8.1</b>
	Hex <b>FE 5E</b>	ID	Size Data	
	ASCII <b>■ ^</b>	ID	Size Data	

Upload a bitmap to a graphic display. To create a bitmap see the Bitmap File Creation section, for upload protocol see the File Upload Protocol or XModem Upload Protocol entries. Start screen is ID 1.

ID	Short	Unique bitmap identification number, value between 0 and 1023.
Size	Integer	Size of the entire bitmap file.
Data	Byte(s)	Bitmap file data, see the Bitmap File Creation example.

5.2 Upload a Bitmap Mask	Dec <b>254 92 5</b>	ID	Size Data	<b>v8.3</b>
	Hex <b>FE 5C 05</b>	ID	Size Data	
	ASCII <b>■ \ ENQ</b>	ID	Size Data	

Upload a bitmap mask that can clear areas of the screen before a bitmap is drawn. Programmatically, (bitmap&mask) | (screen&~mask) is shown when a bitmap is drawn. To create a mask see the Bitmap File Creation section, for upload protocol see the File Upload Protocol or XModem Upload Protocol entries.

ID	Word	Unique bitmap mask identification number.
Size	Double Word	Size of the entire mask file.
Data	Byte(s)	Bitmap mask file data, see the Bitmap File Creation example.

5.3 Draw a Bitmap from Memory	Dec <b>254 98</b>	ID	X Y	<b>v8.1</b>
	Hex <b>FE 62</b>	ID	X Y	
	ASCII <b>■ b</b>	ID	X Y	

Draw a previously uploaded bitmap from memory. Top left corner must be specified for drawing.

ID	Short	Unique bitmap identification number, value between 0 and 1023.
X	Byte	Leftmost coordinate of bitmap.
Y	Byte	Topmost coordinate of bitmap.



5.4 Draw a Partial Bitmap	Dec <b>254 192</b>	ID X Y Left Top Width Height	<b>v8.6</b>
	Hex <b>FE C0</b>	ID X Y Left Top Width Height	
	ASCII <b>■ L</b>	ID X Y Left Top Width Height	

Draw a portion of a previously uploaded bitmap defined by the left, top, width, and height specified.

<b>ID</b>	<b>Short</b>	Unique bitmap identification number, value between 0 and 1023.
<b>X</b>	<b>Byte</b>	Leftmost coordinate of bitmap placement.
<b>Y</b>	<b>Byte</b>	Topmost coordinate of bitmap placement.
<b>Left</b>	<b>Byte</b>	Leftmost coordinate of the partial bitmap area to be drawn.
<b>Top</b>	<b>Byte</b>	Topmost coordinate of the partial bitmap area to be drawn.
<b>Width</b>	<b>Byte</b>	Width of the partial bitmap area to be drawn.
<b>Height</b>	<b>Byte</b>	Height of the partial bitmap area to be drawn.

5.5 Draw a Bitmap Directly	Dec <b>254 100</b>	X1 Y1 X2 Y2 Data	<b>v8.0</b>
	Hex <b>FE 64</b>	X1 Y1 X2 Y2 Data	
	ASCII <b>■ d</b>	X1 Y1 X2 Y2 Data	

Draw a bitmap directly to the graphic display without saving to memory.

<b>X1</b>	<b>Byte</b>	Leftmost coordinate of bitmap.
<b>Y1</b>	<b>Byte</b>	Topmost coordinate of bitmap.
<b>X2</b>	<b>Byte</b>	Rightmost coordinate of bitmap.
<b>Y2</b>	<b>Byte</b>	Bottommost coordinate of bitmap.
<b>Data</b>	<b>Byte(s)</b>	Bitmap file data, see the Bitmap File Creation example.

### Bitmap File Creation

In addition to fonts, Matrix Orbital graphic displays can also hold a number of customizable bitmaps to provide further stylistic product integration. Like font files, bitmap files are most easily uploaded to a display using MOGD#. However, the critical data component of the bitmap upload command is detailed below for reference.

The bitmap data block is similar to that of a font. However, as a bitmap is a single glyph, only a simple two byte header is required. First, one byte representing the bitmap width is sent, then one byte for the height. Each bitmap is merely encoded in binary fashion using a series of ones and zeroes. Again a grid can be created using the width and height specified in the upload command, populated in the manner above, and converted into byte values. A smiley face example is shown below to indicate the ultimate effect of the Matrix Orbital graphic stylization ability.

Table 24: Smiley Face Bitmap

0	1	0	1	0
0	0	0	0	0
1	0	0	0	1
0	1	1	1	0

Table 25:Smiley Face Data

0	1	0	1	0	0	0	0	50	80
0	0	1	0	0	0	1	0	22	34
1	1	1	0	0	0	0	0	E0	224

Table 26: Example Bitmap File

Header	5 4
Bitmap Data	80 34 224



## Bitmap Masking

Like a regular bitmap, a mask can be loaded to the display and used to create a more polished result when drawing in populated areas. When defining a mask, all active values will clear any background information, while any inactive values will leave it untouched. This is best described with an example.




Figure 14: Drawing without a Mask




Figure 15: Drawing with a Mask

## 6.6 9-Slices

6.1 Upload a 9-Slice File	Dec Hex ASCII	<b>254 92 3</b> <b>FE 5C 03</b> ■ \ ETX	ID Size Data ID Size Data ID Size Data	<b>v8.3</b>
---------------------------	---------------------	---	--	-------------

Upload a 9-slice file to a graphic display. To create a 9-slice see the

9-Slice File Creation section, for upload protocol see the File Upload Protocol or XModem Upload Protocol entries.

ID	Word	Unique 9-slice identification number.
Size	Double Word	Size of the 9-slice file.
Data	Byte(s)	9-slice file data, see the 9-Slice File Creation example.

6.2 Upload a 9-Slice Mask	Dec Hex ASCII	<b>254 92 6</b> <b>FE 5C 06</b> ■ \ ACK	ID Size Data ID Size Data ID Size Data	<b>v8.3</b>
---------------------------	---------------------	---	--	-------------

Upload a 9-slice mask that can clear areas of the screen before a 9-slice is drawn. Programmatically, (9slice&mask) | (screen&~mask) is shown when a bitmap is drawn. To create a mask see the

9-Slice File Creation section, for upload protocol see the File Upload Protocol or XModem Upload Protocol entries.

ID	Word	Unique 9-slice mask identification number.
Size	Double Word	Size of the entire mask file.
Data	Byte(s)	9-slice mask file data, see the 9-Slice File Creation example.

6.3 Display a 9-Slice	Dec Hex ASCII	<b>254 91</b> <b>FE 5B</b> ■ [	ID X1 Y1 X2 Y2 ID X1 Y1 X2 Y2 ID X1 Y1 X2 Y2	<b>v8.3</b>
-----------------------	---------------------	--------------------------------------	--	-------------

Displays a previously loaded 9-slice at the specified location.

ID	Word	Unique 9-slice identification number.
X1	Byte	Leftmost coordinate of the 9-slice.
Y1	Byte	Topmost coordinate of the 9-slice.



X2	Byte	Rightmost coordinate of the 9-slice.
Y2	Byte	Bottommost coordinate of the 9-slice.



## 9-Slice File Creation

A 9-slice file is a scalable graphic composed of nine different bitmap sections as shown below.




Figure 16: Adobe 9-slice Representation

The 9-slice file format requires that the bitmap dimensions and the locations of divisions be defined before a graphic is uploaded normally as shown in the Bitmap File Creation example.

Table 27: 9-slice file format

<b>Width</b>	One byte representing the width of the entire bitmap.
<b>Height</b>	One byte representing the height of the entire bitmap.
<b>Top</b>	One byte specifying the height of the top row section of the 9-slice.
<b>Bottom</b>	One byte specifying the height of the bottom row section of the 9-slice.
<b>Left</b>	One byte specifying the width of the left column section of the 9-slice.
<b>Right</b>	One byte specifying the width of the right column section of the 9-slice.
<b>Bitmap Data</b>	Data outlining the entire bitmap, as per the Bitmap File Creation example.

## 6.7 Animations

7.1 Upload an Animation File	Dec Hex ASCII	<b>254 92 4</b> <b>FE 5C 04</b> <b>■ \ EOT</b>	File ID Size Data File ID Size Data File ID Size Data	<b>v8.3</b>
Upload an animation file to a graphic display. To create an animation see the Animation File Creation section, for upload protocol see the File Upload Protocol or XModem Upload Protocol entries. Up to 16 animations can be displayed on the screen at one time, using the Display Animation command, but up to 1024 can be stored in memory for later use. Please note the total graphic memory size is 256KB.				
<b>File ID</b>	<b>Short</b>	Unique animation file identification number, value between 0 and 1023.		
<b>Size</b>	<b>Integer</b>	Size of the animation file.		
<b>Data</b>	<b>Byte(s)</b>	Animation file data, see the Animation File Creation example.		



7.2 Display Animation	Dec <b>254 193</b>	ID File ID* X Y	<b>v8.4</b>
	Hex <b>FE C1</b>	ID File ID* X Y	
	ASCII      ■ ┴	ID File ID* X Y	

Load the first frame of the specified animation in its stopped state at the specified location. If an animation is already in use at that index it will be overwritten. Use the start animation command to play the displayed file.

<b>ID</b>	<b>Byte</b>	Unique animation identification number, value between 0 and 15.
<b>*File ID</b>	<b>Short</b>	Unique animation file identification number, value between 0 and 1023.
<b>X</b>	<b>Byte</b>	Leftmost coordinate of animation.
<b>Y</b>	<b>Byte</b>	Topmost coordinate of animation.

**\*Note:** File ID short length variables were introduced at firmware v8.5.

7.3 Delete Animation	Dec <b>254 199</b>	ID	<b>v8.3</b>
	Hex <b>FE C7</b>	ID	
	ASCII      ■	ID	
Stop and delete the displayed animation specified.			
<b>ID</b>	<b>Byte</b>	Animation number to delete, value between 0 and 15.	

7.4 Start/Stop Animation	Dec <b>254 194</b>	ID Start	<b>v8.3</b>
	Hex <b>FE C2</b>	ID Start	
	ASCII      ■ T	ID Start	
Start or stop an animation that has been displayed.			
<b>ID</b>	<b>Byte</b>	Animation number to start/stop, , value between 0 and 15.	
<b>Start</b>	<b>Byte</b>	Any non-zero value will start the specified animation, 0 will stop it.	

7.5 Set Animation Frame	Dec <b>254 197</b>	ID Frame	<b>v8.3</b>
	Hex <b>FE C5</b>	ID Frame	
	ASCII      ■ +	ID Frame	
Set the current frame of a displayed animation. If the frame exceeds the total number present, the animation will be set to the first frame.			
<b>ID</b>	<b>Byte</b>	Animation number to control, value between 0 and 15.	
<b>Frame</b>	<b>Byte</b>	Number of the frame to be displayed, value between 0 and 31.	

7.6 Get Animation Frame	Dec <b>254 196</b>	ID	<b>v8.3</b>
	Hex <b>FE C4</b>	ID	
	ASCII      ■ -	ID	
Get the current frame of a displayed animation.			
<b>ID</b>	<b>Byte</b>	Animation number to request frame number, value between 0 and 15.	
<b>Response</b>	<b>Byte</b>	Current frame number of the animation specified, value between 0 and 31.	



## Animation File Creation

An animation file is a series of bitmaps, each displayed for a specified length of time within a continuous rotation. The file begins by specifying the number of frames, the offset of each block of bitmap information, and the time to display each frame. After which bitmap headers and data are transmitted for each frame, in the same manner as the Bitmap File Creation example.

Table 28: Animation file format

<b>Total Frames</b>	One bytes representing the total number of frames in the animation
<b>Offsets</b>	One entry for each frame, 4 bytes indicating the start of the bitmap file. Maximum 32 frames
<b>Times</b>	Two bytes for each frame representing the length of time (100ms) for which it is displayed.
<b>Header 1</b>	Two bytes, one representing the width and one the height of the first bitmap.
<b>Bitmap 1 Data</b>	The first bitmap data, as per the Bitmap File Creation example.
...	...
<b>Header 9</b>	Two bytes, one representing the width and one the height of the last bitmap.
<b>Bitmap 9 Data</b>	The last bitmap data, as per the Bitmap File Creation example.

## 6.8 General Purpose Output

8.1 General Purpose Output On	Dec <b>254 87</b> Number Hex <b>FE 57</b> Number ASCII <b>■ W</b> Number	<b>v8.0</b>
Turns the specified GPO on, sourcing current from an output of three volts.		
Number	Byte	GPO to be turned on.

8.2 General Purpose Output Off	Dec <b>254 86</b> Number Hex <b>FE 56</b> Number ASCII <b>■ V</b> Number	<b>v8.0</b>
Turns the specified GPO off, sinking current to an output of zero volts.		
Number	Byte	GPO to be turned off.

8.3 Set Start Up GPO State	Dec <b>254 195</b> Number State Hex <b>FE C3</b> Number State ASCII <b>■ +</b> Number State	<b>v8.0</b>
Sets and saves the start up state of the specified GPO in non-volatile memory. Changes will be seen on start up.		
Number	Byte	GPO to be controlled.
State	Byte	1 for on or 0 for off.

## 6.9 Piezo Buzzer

9.1 Activate Piezo Buzzer	Dec <b>254 187</b> Frequency Time Hex <b>FE BB</b> Frequency Time ASCII <b>■ 7</b> Frequency Time	<b>v8.0</b>
Activates a buzz of specific frequency from the onboard piezo buzzer for a specified length of time.		
Frequency	Word	Frequency of the buzzer beep in Hertz.
Time	Word	*Duration of the buzzer beep in milliseconds.



9.2 Set Default Buzzer Beep	Dec <b>254 188</b>	Frequency Duration	<b>v8.3</b>
	Hex <b>FE BC</b>	Frequency Duration	
	ASCII      ■ ▴	Frequency Duration	

Set the frequency and duration of the default beep transmitted when the bell character is transmitted.

**Frequency** **Word** Frequency of the beep in Hertz, default 440Hz.

**Duration** **Word** \*Duration of the beep in milliseconds, default 100ms.

**\*Note:** When a beep precedes a delay command, the duration of the beep must be shorter than that of the delay.

9.3 **Set Keypad Buzzer Beep	Dec <b>254 182</b>	Frequency Duration	<b>v8.4</b>
	Hex <b>FE B6</b>	Frequency Duration	
	ASCII      ■ ▴	Frequency Duration	

Set the frequency and duration of the default beep transmitted when a key is pressed.

**Frequency** **Short** Frequency of the beep in Hertz, default is 0 or off.

**Duration** **Short** Duration of the beep in milliseconds, default is 0 or off.

**\*\*Note:** Keypad model only.

9.4 *Set Touch Buzzer Beep	Dec <b>254 182</b>	Down Freq Up Freq	<b>v8.4</b>
	Hex <b>FE B6</b>	Down Freq Up Freq	
	ASCII      ■ ▴	Down Freq Up Freq	

Set the frequency of the default beep transmitted when a touch event occurs. Duration of each is 50ms.

**Down Freq** **Short** Frequency of the down event beep in Hertz, default is 0 or off.

**Up Freq** **Short** Frequency of the up event beep in Hertz, default is 0 or off.

**\*Note:** Touchpad model only.

## 6.10 Keypad

10.1 Auto Transmit Key Presses On	Dec <b>254 65</b>		<b>v8.0</b>
	Hex <b>FE 41</b>		
	ASCII      ■ A		

Key presses are automatically sent to the host when received by the display. Default is Auto Transmit on.

10.2 Auto Transmit Key Presses Off	Dec <b>254 79</b>		<b>v8.0</b>
	Hex <b>FE 4F</b>		
	ASCII      ■ O		

Key presses are held in the 10 key buffer to be polled by the host using the Poll Key Press command. Use this mode for I2C transactions. Default is Auto Transmit on.

10.3 Poll Key Press	Dec <b>254 38</b>		<b>v8.0</b>
	Hex <b>FE 26</b>		
	ASCII      ■ &		

Reads the last unread key press from the 10 key display buffer. If another key is stored in the buffer the MSB will be 1, the MSB will be 0 when the last key press is read. If there are no stored key presses a value of 0 will be returned. Auto transmit key presses must be turned off for this command to be successful.

<b>Response</b>	<b>Byte</b>	Value of key pressed (MSb determines additional keys to be read).
-----------------	-------------	---



10.4 Clear Key Buffer	Dec <b>254 69</b> Hex <b>FE 45</b> ASCII <b>■ E</b>	<b>v8.0</b>
-----------------------	---	-------------

Clears all key presses from the key buffer.

10.5 Set Debounce Time	Dec <b>254 85</b> Time Hex <b>FE 55</b> Time ASCII <b>■ U</b> Time	<b>v8.0</b>
------------------------	--	-------------

Sets the time between a key press and a key read by the display. Most switches will bounce when pressed; the debounce time allows the switch to settle for an accurate read. Default is 8 representing approximately 52ms.

**Time** **Byte** Debounce increment (debounce time = **Time** \* 6.554ms).

10.6 Set Auto Repeat Mode	Dec <b>254 126</b> Mode Hex <b>FE 7E</b> Mode ASCII <b>■ DEL</b> Mode	<b>v8.0</b>
---------------------------	---	-------------

Sets key press repeat mode to typematic or hold. In typematic mode if a key press is held, by default the key value is transmitted immediately, then 5 times a second after a 1 second delay. In hold mode, the key down value is transmitted once when pressed, and then the key up value is sent when the key is released. Default is typematic.

**Mode** **Byte** 1 for hold mode or 0 for typematic.

10.7 Auto Repeat Mode Off	Dec <b>254 96</b> Hex <b>FE 60</b> ASCII <b>■ `</b>	<b>v8.0</b>
---------------------------	---	-------------

Turns auto repeat mode off. Default is on (typematic).

10.8 Assign Keypad Codes	Dec <b>254 213</b> Key Down Key Up Hex <b>FE D5</b> Key Down Key Up ASCII <b>■ F</b> Key Down Key Up	<b>v8.0</b>
--------------------------	--	-------------

Assigns the key down and key up values sent to the host when a key press is detected. A key up and key down value must be sent for every key, a value of 255 will leave the key unaltered. Defaults are shown below.

**Key Down** **Bytes [25]** Key down values, beginning at row one column one moving right then down.

**Key Up** **Bytes [25]** Key up values, beginning at row one column one moving right then down.

Table 29: Default Key Down Values

Key Down				
A(65)	B(66)	C(67)	D(68)	E(69)
F(70)	G(71)	H(72)	I(73)	J(74)
K(75)	L(76)	M(77)	N(78)	O(79)
P(80)	Q(81)	R(82)	S(83)	T(84)
U(85)	V(86)	W(87)	X(88)	Y(89)

Table 30: Default Key Up Values

Key Up				
a(97)	b(98)	c(99)	d(100)	e(101)
f(102)	g(103)	h(104)	i(105)	j(106)
k(107)	l(108)	m(109)	n(110)	o(111)
p(112)	q(113)	r(114)	s(115)	t(116)
u(117)	v(118)	w(119)	x(120)	y(121)



10.9 Set Typematic Delay	Dec <b>254 159</b>	Delay	<b>v8.4</b>
	Hex <b>FE 9F</b>	Delay	
	ASCII <b>■ f</b>	Delay	

Sets the delay between the first key press and first typematic report when a key is held in typematic mode.

**Delay** **Byte** Time key must be held to trigger typematic reports, specified in 100ms, default is 10 (1s).

10.10 Set Typematic Interval	Dec <b>254 158</b>	Interval	<b>v8.4</b>
	Hex <b>FE 9E</b>	Interval	
	ASCII <b>■ Pts</b>	Interval	

Sets the interval between reported key presses when a key is held and the display is in typematic mode.

**Interval** **Byte** Time between key reports, specified in 100ms increments, default is 2 (200ms).

## 6.11 Touchpad

11.1 Set Touch Mode	Dec <b>254 135</b>	Mode	<b>v8.0</b>
	Hex <b>FE 87</b>	Mode	
	ASCII <b>■ ¢</b>	Mode	

Sets the method used to return touch events. Region mode will return a single value for events in defined areas.

Coordinate mode will return event, x position, and y position bytes for each press, drag, or release.

**Mode** **Byte** Touch reporting mode, 0 for region or 1 for coordinate mode. Default is coordinate.

11.2 Set Region Reporting Mode	Dec <b>254 136</b>	Mode	<b>v8.0</b>
	Hex <b>FE 88</b>	Mode	
	ASCII <b>■ ê</b>	Mode	

Defines the events transmitted in region mode. Allows only events specified to return a value to the host. Key down values are transmitted for press and drag events, key up for release, and the value 255 for out of region.

**Mode** **Byte** Defines the events reported, see Region Reporting Mode. Default reporting returns all events.

Table 31: Region Reporting Mode

Byte	7-4	3	2	1	0
Event	Reserved	Out of Region	Drag	Release	Press

11.3 Set Touch Region	Dec <b>254 132</b>	ID X Y Width Height Key Down Key Up	<b>v8.0</b>
	Hex <b>FE 84</b>	ID X Y Width Height Key Down Key Up	
	ASCII <b>■ ä</b>	ID X Y Width Height Key Down Key Up	

Creates a region of the screen that responds when pressed and released with a defined single byte.

**ID** **Byte** Unique region identification number, maximum 32 regions. Value between 0 and 31.

**X** **Byte** Leftmost coordinate.

**Y** **Byte** Topmost coordinate.

**Width** **Byte** Width of region, must be within screen bounds.

**Height** **Byte** Height of region, must be within screen bounds.

**Key Down** **Byte** Value returned when region is pressed.

**Key Up** **Byte** Value returned when region is released.



11.4 Delete a Touch Region	Dec <b>254 133</b>	ID	<b>v8.0</b>
	Hex <b>FE 85</b>	ID	
	ASCII      ■ à	ID	

Deletes a previously created touch region. Events from undefined regions return the value 255 by default.

**ID** **Byte** Unique region identification number.

11.5 Delete All Touch Regions	Dec <b>254 134</b>	<b>v8.0</b>
	Hex <b>FE 86</b>	
	ASCII      ■ å	

Deletes all previously created touch regions. Recommended for use before dividing the screen into new regions.

11.6 Create a Slider	Dec <b>254 186</b>	ID	Type	X	Y	Width	Height	Control	Width	Min	Max	<b>v8.3</b>
	Hex <b>FE BA</b>	ID	Type	X	Y	Width	Height	Control	Width	Min	Max	
	ASCII      ■	ID	Type	X	Y	Width	Height	Control	Width	Min	Max	

Draw a slider on the screen that responds visually and numerically when tapped or slid. Slider regions respond with a value of 83, their ID, then two byte length current X and Y coordinates when activated.

<b>ID</b>	<b>Byte</b>	Unique slider identification number, max 32 regions/sliders. Value between 0 and 31.
<b>Type</b>	<b>Byte</b>	Defines slider direction and starting point for the control, as below.
<b>X</b>	<b>Byte</b>	Leftmost coordinate.
<b>Y</b>	<b>Byte</b>	Topmost coordinate.
<b>Width</b>	<b>Short</b>	Width of slider.
<b>Height</b>	<b>Short</b>	Height of slider.
<b>Control Width</b>	<b>Byte</b>	Width of the slider control.
<b>Min</b>	<b>Short</b>	Minimum slider value.
<b>Max</b>	<b>Short</b>	Maximum slider value.

Table 32: Slider Definition

Value	Description
16	Horizontal slider, starting at minimum position
17	Vertical slider, starting at minimum position
32	Horizontal slider, starting at maximum position
33	Vertical slider, starting at maximum position
64	Horizontal slider, starting at middle position
65	Vertical slider, starting at middle position

11.7 Delete a Slider	Dec <b>254 189</b>	ID	<b>v8.3</b>
	Hex <b>FE BD</b>	ID	
	ASCII      ■ ↴	ID	

Deletes a previously created slider. Memory is shared with touch regions, this command will free space.

**ID** **Byte** Unique region identification number.



11.8 Delete All Sliders	Dec <b>254 190</b>	Hex <b>FE BE</b>	ASCII <b>■ =</b>	v8.3
-------------------------	--------------------	------------------	------------------	------

Deletes all previously created sliders. Does not remove touch regions.

11.9 Set Dragging Threshold	Dec <b>254 137</b>	Threshold	v8.0
	Hex <b>FE 89</b>	Threshold	
	ASCII <b>■ è</b>	Threshold	

Sets the distance a press is required to travel before a drag event is reported. Precision will vary inversely to data transmitted; care should be taken to find a suitable balance. Distance is calculated as  $\Delta x^2 + \Delta y^2 = d^2$ .

**Threshold** **Byte** Dragging threshold value. Default is 8.

11.10 Set Pressure Threshold	Dec <b>254 138</b>	Threshold	v8.0
	Hex <b>FE 8A</b>	Threshold	
	ASCII <b>■ è</b>	Threshold	

Sets the pressure required to trigger a touch event.

**Threshold** **Word** Pressure threshold value. Default is 1000.

11.11 Run Touchpad Calibration	Dec <b>254 139</b>	v8.0
	Hex <b>FE 8B</b>	
	ASCII <b>■ ï</b>	

Triggers an interactive calibration of the touchpad. User will be required to touch various points on the screen during calibration. This command is recommended for use when environmental or user conditions change to ensure correct operation.

**Response** **Word** Command byte 254, then 21 for success or 20 for failure.

## 6.12 Display Functions

12.1 Backlight On	Dec <b>254 66</b>	Minutes	v8.0
	Hex <b>FE 42</b>	Minutes	
	ASCII <b>■ B</b>	Minutes	

Turns the display backlight on for a specified length of time. If an inverse display color is used this command will essentially turn on the text.

**Minutes** **Byte** Number of minutes to leave backlight on, a value of 0 leaves the display on indefinitely.

12.2 Backlight Off	Dec <b>254 70</b>	v8.0
	Hex <b>FE 46</b>	
	ASCII <b>■ F</b>	

Turns the display backlight off. If an inverse display colour is used this command will turn off the text.



12.3 Set Brightness	Dec <b>254 153</b>	Brightness	<b>v8.0</b>
	Hex <b>FE 99</b>	Brightness	
	ASCII <b>■ Ö</b>	Brightness	

Immediately sets the backlight brightness. If an inverse display color is used this represents the text colour intensity instead. Default is 255.

**Brightness** **Byte** Brightness level from 0(Dim) to 255(Bright).

12.4 Set and Save Brightness	Dec <b>254 152</b>	Brightness	<b>v8.0</b>
	Hex <b>FE 98</b>	Brightness	
	ASCII <b>■ ÿ</b>	Brightness	

Immediately sets and saves the backlight brightness. Although brightness can be changed using the set command, it is reset to this saved value on start up. Default is 255.

**Brightness** **Byte** Brightness level from 0(Dim) to 255(Bright).

12.5 Set Backlight Colour	Dec <b>254 130</b>	Red Green Blue	<b>v8.0</b>
	Hex <b>FE 82</b>	Red Green Blue	
	ASCII <b>■ é</b>	Red Green Blue	

Set the colour of a tri-colour backlight. Only for tri-colour displays. Default is white (255, 255, 255).

**Red** **Byte** Brightness level of Red from 0(Dim) to 255(Bright).

**Green** **Byte** Brightness level of Green from 0(Dim) to 255(Bright).

**Blue** **Byte** Brightness level of Blue from 0(Dim) to 255(Bright).

12.6 Set Contrast	Dec <b>254 80</b>	Contrast	<b>v8.0</b>
	Hex <b>FE 50</b>	Contrast	
	ASCII <b>■ P</b>	Contrast	

Immediately sets the contrast between background and text. If an inverse display color is used this also represents the text brightness. Default is 128.

**Contrast** **Byte** Contrast level from 0(Light) to 255(Dark).

12.7 Set and Save Contrast	Dec <b>254 145</b>	Contrast	<b>v8.0</b>
	Hex <b>FE 91</b>	Contrast	
	ASCII <b>■ æ</b>	Contrast	

Immediately sets and saves the contrast between background and text. Although contrast can be changed using the set command, it is reset to this saved value on start up. Default is 128.

**Contrast** **Byte** Contrast level from 0(Light) to 255(Dark).

## 6.13 Scripting

13.1 Upload a Script File	Dec <b>254 92 2</b>	ID Length Data	<b>v8.3</b>
	Hex <b>FE 5C 02</b>	ID Length Data	
	ASCII <b>■ \ STX</b>	ID Length Data	

Save a list of commands to be executed at a later time. Bytes are saved as if they are being sent by the host.

**ID** **Word** Unique identification number of the script.

**Length** **Double** Length of the script in bytes.

**Data** **Byte(s)** Data to be sent to the display when the script executes.



13.2 *Set Scripted Button	Dec <b>254 142</b>	ID X Y Width Height Type Down Script Up Script	<b>v8.3</b>
	Hex <b>FE 8E</b>	ID X Y Width Height Type Down Script Up Script	
	ASCII      ■ Ä	ID X Y Width Height Type Down Script Up Script	

Create a button region that responds to a touch event by executing an uploaded script.

<b>ID</b>	<b>Byte</b>	Identification number of the touch region, value between 0 and 31
<b>X</b>	<b>Byte</b>	Leftmost coordinate.
<b>Y</b>	<b>Byte</b>	Topmost coordinate.
<b>Width</b>	<b>Byte</b>	Width of touch region.
<b>Height</b>	<b>Byte</b>	Height of touch region.
<b>Type</b>	<b>Byte</b>	Type of touch region. Must be 1.
<b>Down Script</b>	<b>Short</b>	Identification number of the script to run on a down event, value between 0 and 1023.
<b>Up Script</b>	<b>Short</b>	Identification number of the script to run on an up event, value between 0 and 1023.

**\*Note:** Touch screen model only.

13.3 *Set Scripted Key	Dec <b>254 142</b>	ID Row Column Down Script Up Script	<b>v8.4</b>
	Hex <b>FE 8E</b>	ID Row Column Down Script Up Script	
	ASCII      ■ Ä	ID Row Column Down Script Up Script	

Select a previously loaded script to be run when the specified key is pressed.

<b>ID</b>	<b>Byte</b>	Unique key identification number, maximum based on number of keys available.
<b>Row</b>	<b>Byte</b>	The row value of the key to be linked to the specified scripts.
<b>Column</b>	<b>Byte</b>	The column value of the key to be linked to the specified scripts.
<b>Down Script</b>	<b>Word</b>	Identification number of the script to run on a down event.
<b>Up Script</b>	<b>Word</b>	Identification number of the script to run on an up event.

**\*Note:** Keypad model only.

13.4 Run Script File	Dec <b>254 93</b>	ID	<b>v8.3</b>
	Hex <b>FE 5D</b>	ID	
	ASCII      ■ ]	ID	

Execute a previously loaded script. Script 0 is loaded automatically on startup, unless in override mode.

**ID** **Word** Identification number of the script to run.

## 6.14 Filesystem

14.1 Delete Filesystem	Dec <b>254 33 89 33</b>		<b>v8.0</b>
	Hex <b>FE 21 59 21</b>		
	ASCII      ■ ! Y !		

Completely erase all fonts and bitmaps from a graphic display. Extended length of the command is intended to prevent accidental execution. To ensure filesystem integrity, cycle power to the display after erasure.

14.2 Delete a File	Dec <b>254 173</b>	Type ID	<b>v8.1</b>
	Hex <b>FE AD</b>	Type ID	
	ASCII      ■ i	Type ID	

Removes a single font or bitmap file given the type and unique identification number. Cycle power after deletion.

<b>Type</b>	<b>Byte</b>	0 for font or 1 for bitmap.
<b>ID</b>	<b>Short</b>	Unique identification number of font or bitmap to be deleted, value between 0 and 1023.



14.3 Get Filesystem Space	Dec <b>254 175</b>	Hex <b>FE AF</b>	ASCII <b>■ »</b>	v8.0
------------------------------	--------------------	------------------	------------------	------

Returns the amount of space remaining in the display for font or bitmap uploads.

**Response** **Integer** Number of bytes remaining in memory.

14.4 Get Filesystem Directory	Dec <b>254 179</b>	Hex <b>FE B3</b>	ASCII <b>■  </b>	v8.1
----------------------------------	--------------------	------------------	------------------	------

Returns a directory to the contents of the filesystem. The total number and type of each entry will be provided.

<b>Response</b>	<b>Short</b>	Number of entries.
	<b>Byte(s) [8]</b>	8 identification bytes for each entry.

Table 33: Filesystem Identification Bytes

Byte	7	6	5	4	3	2	1	0
Description	Size(MSB)	Size	Size	Size(LSB)	Type(4)/ID(4)	ID (LSB)	Start Page (MSB)	Start Page (LSB)

Table 34: Extended Byte Descriptions

<b>Size</b>	The complete file size.	
<b>Type/ID</b>	First four bits designate file type, 0 for font or 1 for bitmap, remaining 12 bits indicate ID number.	
<b>Start Page</b>	Memory start page, a value of 0 indicates entry is not in use.	

14.5 Filesystem Upload	Dec <b>254 176</b>	Size Data	v8.0
	Hex <b>FE B0</b>	Size Data	
	ASCII <b>■ ■■■</b>	Size Data	

This command will upload a filesystem image to the display. The size used is almost always the entire memory.

Filesystem data can be uploaded LSB to MSB in the same manner as a font or bitmap file.

<b>Size</b>	<b>Double</b>	Size of the filesystem to upload.
<b>Data</b>	<b>Byte(s)</b>	Filesystem data to upload.

14.6 Filesystem Download	Dec <b>254 48</b>	v8.0
	Hex <b>FE 30</b>	
	ASCII <b>■ 0</b>	

Downloads complete filesystem containing all fonts and bitmaps stored in the display. A veritable heap of data.

<b>Response</b>	<b>Double</b>	Size of the filesystem to download.
	<b>Byte(s)</b>	Filesystem data to download.



14.7 File Download	Dec <b>254 178</b>	Type ID	<b>v8.1</b>
	Hex <b>FE B2</b>	Type ID	
	ASCII 	Type ID	

Downloads a single font or bitmap file from the display to the host using the File Upload Protocol.

Type	Byte	Variable length, see File Types .
ID	Short	Unique identification number of font or bitmap to download, value between 0 and 1023.
Response	Integer	File size.
	Byte(s)	File data.

14.8 File Move	Dec <b>254 180</b>	Old Type	Old ID	New Type	New ID	<b>v8.1</b>
	Hex <b>FE B4</b>	Old Type	Old ID	New Type	New ID	
	ASCII 	Old Type	Old ID	New Type	New ID	

Used to move a single file and/or alter the type of an existing file. Old ID location must be valid and new ID empty.

Old Type	Byte	Original file type, value between 0 and 1023, see File Types .
Old ID	Short	Original unique file identification number, value between 0 and 1023.
New Type	Byte	New file type, see File Types .
New ID	Short	New unique file identification number.

Table 35: File Types

Font	Bitmap	Script	9-Slice	Animation
0	1	2	3	4

14.9 XModem Filesystem Upload	Dec <b>254 219 133 6 48</b>	Size	Data	<b>v8.1</b>
	Hex <b>FE DB 85 6 30</b>	Size	Data	
	ASCII  à ACK 0	Size	Data	

Upload a filesystem image to the display using the XModem protocol. The size used is almost always the entire memory. Filesystem data is uploaded LSB to MSB using the protocol below.

Size	Double	Size of the filesystem to upload.
Data	Byte(s)	Filesystem data to upload, must be padded to an even multiple of 256 bytes.

14.10 XModem Filesystem Download	Dec <b>254 222 133 6 48</b>	<b>v8.3</b>
	Hex <b>FE DE 85 6 30</b>	
	ASCII  à ACK 0	

Downloads the complete filesystem via XModem protocol. A veritable heap of data, transmitted at a decent pace.

Response	Double	Size of the filesystem to download.
	Byte(s)	Filesystem data to download, an even multiple of 256 bytes.



14.11 XModem	Dec	<b>254 220 133 6 48</b>	File ID Type Size Data	v8.3
File Upload	Hex	<b>FE DC 85 6 30</b>	File ID Type Size Data	
	ASCII	<b>■ ■ à ACK 0</b>	File ID Type Size Data	

This command will upload a single file to the display. Unlike the standard protocol, there is one XModem upload command for all file types, see File Types for a complete list.

File ID	Word	Unique identification number for the file to upload.
Type	Byte	Type of file to upload, see File Types .
Size	Double	Size of the file to upload.
Data	Byte(s)	File data to upload, must be padded to an even multiple of 128 bytes.

14.12 XModem	Dec	<b>254 221 133 6 48</b>	File ID Type	v8.3
File Download	Hex	<b>FE DD 85 6 30</b>	File ID Type	
	ASCII	<b>■ ■ à ACK 0</b>	File ID Type	

Downloads a single file from the display to the host using XModem protocol.

File ID	Word	Unique identification number for the file to download.
Type	Byte	Type of file to download, see File Types .
Response	Double	Size of the filesystem to download.
	Byte(s)	Filesystem data to download, an even multiple of 128 bytes, may be padded with 255s.

### File Upload Protocol

Once a bitmap or font file has been created and paired to its command it must be sent using a file protocol developed specifically for Matrix Orbital displays. Once a file upload command has been sent requesting a unique reference number and specifying the file size required, the display will respond indicating whether it has enough room to save the file or not. As is the case throughout the upload protocol, a response of 1 will indicate confirmation while an 8 corresponds to rejection and will terminate the session.

Table 36: Upload Protocol Responses

Value	Action	Description
1	Acknowledged	Transfer successful, upload continues
8	Not Acknowledged	Transfer failed, abort upload

Once a file is confirmed to fit within the display, the upload will begin. A protocol is used here to ensure each byte is uploaded successfully. After each byte is sent, the module will echo it back to the host. It should then be checked against the value originally sent before a confirmation byte of 1 is returned. If the transmitted and echoed values do not match the upload should be aborted by sending a value of 8 instead. The upload will continue in this manner as indicated by the examples below which utilize familiar font and bitmap files.



Table 37: Font Upload Protocol

Host	Display	Comments
254		Command Prefix
36		Upload Font File Command
1		Reference ID LSB
0		Reference ID MSB
31		Font File Size LSB
0		Font File Size
0		Font File Size
0		Font File MSB
	1	Acknowledge Size
5		First Font Data Byte
	5	Echo Data Byte
1		Acknowledge Data Byte
7		Second Font Data Byte
...	...	...
96		Last Font Data Byte
96		Echo Data Byte
1		Acknowledge Data Byte

Table 38: Bitmap Upload Protocol

Host	Display	Comments
254		Command Prefix
94		Upload Bitmap File Command
1		Reference ID LSB
0		Reference ID MSB
5		Bitmap File Size LSB
0		Bitmap File Size
0		Bitmap File Size
0		Bitmap File MSB
	1	Acknowledge Size
5		First Bitmap Data Byte
	5	Echo Data Byte
1		Acknowledge Data Byte
4		Second Bitmap Data Byte
...	...	...
224		Last Bitmap Data Byte
224		Echo Data Byte
1		Acknowledge Data Byte

It should be noted that the display has a timeout setting of 2.1 seconds before it resets to prevent it from hanging during the upload process. Upon reset, the values 254 and 212 will be returned to indicate an error or lengthy delay has occurred in the upload process. If everything goes smoothly, the protocol will end with the host transmitting a final confirmation byte and the font will be stored in the display ready for any application.

### XModem Upload Protocol

In addition to its original simple upload format, Matrix Orbital has added an XModem based protocol. This facilitates much faster download speeds by increasing the packet size from 1 byte to 128 bytes and using only a two byte CRC for error checking, greatly increasing throughput. To begin the upload, a series of command bytes are sent, a list of valid file type bytes is shown in the File Types table. Once the command bytes are sent, the true size of the file is sent in four bytes, least significant byte first. At this point the display will respond with a C if the file fits or a NAK otherwise. Please note that these values are different than those of the original protocol as seen in the XModem Message Bytes table. If a NAK is seen at any point by the host, the upload is to be aborted in the same fashion as the regular protocol. If the file will fit, the start of header byte will be sent by the host, followed by a block count, in regular and inverted format, representing the number of 128 byte blocks remaining to be sent. The display will then check to make sure the block count value matches its own, if it doesn't it will NAK. The host can then send a 128 byte block of data followed by that blocks high and low CRC16 bytes.



The display then performs a CRC check on the data receive and ACKs if it matches that which was sent. Transfer continues with a block count and continues in this way until the end of file is reached. Files may be padded with 255 values to reach an even multiple of 128 bytes in size, but the download command will always report true size. Once the end of the upload file is reached, the host should transmit a single end of transmission byte. If the end of file is expected, the display will ACK one last time.

Table 39: XModem File Upload Protocol

Host	Display	Comments
254		Command Prefix
220		XModem Upload Command
133		Command Byte One
6		Command Byte Two
48		Command Byte Three
1		File ID LSB
0		File ID MSB
1		File Type
0		Size LSB
0		Size
1		Size
0		Size MSB
	67	C (If file fits)
1		Start of Header
128		Block Count
127		Inverted Block Count (255-Count)
<128 B>		128 Byte Data Block
30		*CRC MSB
71		*CRC LSB
	6	ACK (NAK if counts don't match)
...	...	...
4		End of Transmission
	6	ACK (NAK if EOT is not expected)

Table 40: XModem File Download Protocol

Host	Display	Comments
254		Command Prefix
221		XModem Download Command
133		Command Byte One
6		Command Byte Two
48		Command Byte Three
1		File ID LSB
0		File ID MSB
1		File Type
	0	Size LSB (NAK if not found)
	0	Size
	1	Size
	0	Size MSB
	67	C
	1	Start of Header
	128	Block Count
	127	Inverted Block Count (255-Count)
	<128 B>	128 Byte Data Block
	30	*CRC MSB
	71	*CRC LSB
	6	ACK (NAK if counts don't match)
...	...	...
	4	End of Transmission
	6	ACK (NAK if EOT is not expected)

Table 41: XModem Message Bytes

Value	Action	Description
1	Start of Header	Begin upload transfer
4	End of Transmission	End completed upload transfer
6	Acknowledged	Transfer successful, upload continues
21	Not Acknowledged	Transfer failed, upload aborted
67	C	Confirmation that file will fit

**\*Note:** CRC bytes are calculated using the XMODEM CRC-CCITT algorithm available at:  
<http://www.matrixorbital.ca/appnotes/XModem/ymodem.txt>.



## 6.15 Data Security

15.1 Set Remember	Dec <b>254 147</b>	Switch	<b>v8.0</b>
	Hex <b>FE 93</b>	Switch	
	ASCII      ■ ô	Switch	

Allows changes to specific settings to be saved to the display memory. Writing to non-volatile memory can be slow and each change consumes 1 write of at least 100,000 available. The Command Summary outlines which commands are saved always, never, and when this command is on only. Remember is off by default.

**Switch** **Byte** 1 for on or 0 for off.

15.2 Set Data Lock	Dec <b>254 202 245 160</b>	Level	<b>v8.0</b>
	Hex <b>FE CA F5 A0</b>	Level	
	ASCII      ■ JL á	Level	

Temporarily locks certain aspects of the display to ensure no inadvertent changes are made. The lock is released after a power cycle. A new level overrides the old, and levels can be combined. Default is 0.

**Level** **Byte** Lock level, see Data Lock Bits table.

Table 42: Data Lock Bits

Display	Command	Filesystem	Setting	Address	Reserved	Reserved	Reserved
7	6	5	4	3	2	1	0

Table 43: Lock Parameters

<b>Reserved</b>	Place holders only, should be 0
<b>Address</b>	Locks the Baud Rate and I2C address
<b>Setting</b>	Locks all settings from being saved
<b>Filesystem</b>	Locks all bitmaps and fonts
<b>Command</b>	Locks all commands, text can still be written
<b>Display</b>	Locks entire display, no new text can be displayed

15.3 Set and Save Data Lock	Dec <b>254 203 245 160</b>	Level	<b>v8.0</b>
	Hex <b>FE CB F5 A0</b>	Level	
	ASCII      ■ JL á	Level	

Locks certain aspects of the display to ensure no inadvertent changes are made. The lock is not affected by a power cycle. A new level overrides the old, and levels can be combined. Default is 0.

**Level** **Byte** See Data Lock Bits table.

## 6.16 Miscellaneous

16.1 Write Customer Data	Dec <b>254 52</b>	Data	<b>v8.0</b>
	Hex <b>FE 34</b>	Data	
	ASCII      ■ 4	Data	

Saves a user defined block of data to non-volatile memory. Useful for storing display information for later use.

**Data** **Byte [16]** User defined data.



16.2 Read Customer Data	Dec <b>254 53</b> Hex <b>FE 35</b> ASCII <b>■ 5</b>	<b>v8.0</b>
-------------------------	---	-------------

Reads data previously written to non-volatile memory. Data is only changed when written, surviving power cycles.

**Response** **Byte [16]** Previously saved user defined data.

16.3 Read Version Number	Dec <b>254 54</b> Hex <b>FE 36</b> ASCII <b>■ 6</b>	<b>v8.0</b>
--------------------------	---	-------------

Causes display to respond with its firmware version number. Test.

16.4 Read Module Type	Dec <b>254 55</b> Hex <b>FE 37</b> ASCII <b>■ 7</b>	<b>v8.0</b>
-----------------------	---	-------------

Causes display to respond with its module number.

16.4 Read Module Type	Dec <b>254 55</b> Hex <b>FE 37</b> ASCII <b>■ 7</b>	<b>v8.0</b>
-----------------------	---	-------------

**Response** **Byte** Module number, see Sample Module Type Responses for a partial list.

Table 44: Sample Module Type Responses

<b>41</b>	GLT12232-SM	<b>36</b>	GLK12232-25-SM
<b>35</b>	GLT12232-SM -USB	<b>32</b>	GLK12232-25-SM -USB

16.5 Read Screen	Dec <b>254 184</b> Hex <b>FE B8</b> ASCII <b>■ =</b>	<b>v8.3</b>
------------------	--	-------------

Return the current commanded state of each pixel on the screen.

16.5 Read Screen	Dec <b>254 184</b> Hex <b>FE B8</b> ASCII <b>■ =</b>	<b>v8.3</b>
------------------	--	-------------

**Response** **Byte(s)** Boolean values of each pixel on the screen, starting top left moving right then down.

16.6 Write to Scratchpad	Dec <b>254 204</b> Hex <b>FE CC</b> ASCII <b>■ =</b>	Address Length Data	<b>v8.3</b>
		Address Length Data	

Write information to volatile memory for later use.

Address	Word	Address where data is to be saved in volatile memory.
---------	------	---

Length	Word	Length of data to be saved, in bytes.
--------	------	---------------------------------------

Data	Byte(s)	Data to be saved in volatile memory.
------	---------	--------------------------------------

16.7 Read from Scratchpad	Dec <b>254 205</b> Hex <b>FE CD</b> ASCII <b>■ =</b>	Address Length	<b>v8.3</b>
		Address Length	

Read information previously saved in volatile memory.

Address	Word	Address where data is saved in volatile memory.
---------	------	---

Length	Word	Length of data to be read, in bytes.
--------	------	--------------------------------------

Response	Byte(s)	Data saved at the specified location in volatile memory.
----------	---------	--



## 7 Appendix

### 7.1 Command Summary

Available commands below include identifying number, required parameters, the returned response and an indication of whether settings are remembered always, never, or with remember set to on.

Table 45: Communication Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Change Baud Rate	57	39	9	Byte	None	Always
Change I2C Slave Address	51	33	3	Byte	None	Always
Transmission Protocol Select	160	A0	á	Byte	None	Remember On
Set a Non-Standard Baud Rate	164	A4	ñ	Short	None	Always
Set Flow Control Mode	63	3F	?	Byte	None	Remember On
Set Hardware Flow Control Trigger Level	62	3E	>	Byte	None	Remember On
Turn Software Flow Control On	58	3A	:	Byte[2]	None	Remember On
Turn Software Flow Control Off	59	3B	;	None	None	Remember On
Set Software Flow Control Response	60	3C	<	Byte[2]	None	Remember On
Echo	255	FF		Short, Byte[]	Byte[]	Never
Delay	251	FB	√	Short	None	Never
Software Reset	253	FD	²	Byte[4]	Byte[2]	Never

Table 46: Text Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Clear Screen	88	58	X	None	None	Never
Go Home	72	48	H	None	None	Never
Set Cursor Position	71	47	G	Byte[2]	None	Never
Set Cursor Coordinate	121	79	y	Byte[2]	None	Never
Initialize Text Window	43	2B	+	Byte[5], Short, Byte[3]	None	Remember On
Set Text Window	42	2A	*	Byte	None	Never
Clear Text Window	44	2C	,	Byte	None	Never
Initialize Label	45	2D	-	Byte[7], Short, Byte[2]	None	Remember On
Initialize Scrolling Label	47	2F	/	Byte[7], Short, Byte[2], Short, Byte	None	Remember On
Update Label	46	2E	.	Byte, String	None	Never
Auto Scroll On	81	51	Q	None	None	Remember On
Auto Scroll Off	82	52	R	None	None	Remember On



Table 47: Drawing Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Set Drawing Colour	99	63	c	Byte	None	Remember On
Draw Pixel	112	70	p	Byte[2]	None	Never
Draw a Line	108	6C	l	Byte[4]	None	Never
Continue a Line	101	65	e	Byte[2]	None	Never
Draw a Rectangle	114	72	r	Byte[5]	None	Never
Draw a Filled Rectangle	120	78	x	Byte[5]	None	Never
Draw a Rounded Rectangle	128	80	ç	Byte[5]	None	Never
Draw a Filled Rounded Rectangle	129	81	ü	Byte[5]	None	Never
Draw a Circle	123	7B	{	Byte[3]	None	Never
Draw a Filled Circle	124	7C		Byte[3]	None	Never
Draw an Ellipse	125	7D	}	Byte[4]	None	Never
Draw a Filled Ellipse	127	7F	DEL	Byte[4]	None	Never
Scroll Screen	89	59	Y	Byte[4], Word[2]	None	Never
Initialize a Bar Graph	103	67	g	Byte[6]	None	Remember On
Initialize 9-Slice Bar Graph	115	73	s	Byte[6], Word[2]	None	Remember On
Draw a Bar Graph	105	69	i	Byte[2]	None	Never
Initialize a Strip Chart	106	6A	n	Byte[5], Word[2], Byte[2], Word	None	Remember On
Update a Strip Chart	107	6B	o	Byte, Word	None	Never

Table 48: Font Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Upload a Font File	36	24	\$	Short, Integer, Byte[]	See Font File Creation	Always
Set the Current Font	49	31	1	Short	None	Never
Set Font Metrics	50	32	2	Byte[5]	None	Remember On
Set Box Space Mode	172	AC	¼	Byte	None	Remember On

Table 49: Bitmap Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Upload a Bitmap File	94	5E	^	Short, Integer, Byte[]	See Bitmap File Creation	Always
Upload a Bitmap Mask	92 5	5C 05	\ ENQ	Short, Integer, Byte[]	See Bitmap File Creation	Always
Draw a Bitmap from Memory	98	62	b	Short, Byte[2]	None	Never
Draw a Partial Bitmap	192	C0	l	Short, Byte[4]	None	Never
Draw a Bitmap Directly	100	64	d	Byte[2], Byte[]	None	Never



Table 50: 9-Slice Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Upload a 9-Slice File	92 3	5C 03	\ ETX	Word, Double, Byte[]	See 9-Slice File Creation	Always
Upload a 9-Slice Mask	92 6	5C 06	\ ACK	Word, Double, Byte[]	See 9-Slice File Creation	Always
Display a 9-Slice	91	5B	[	Word, Byte[4]	None	Never

Table 51: Animation Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Upload an Animation File	92 4	5C 04	\ EOT	Word, Double, Byte[]	See Animation File Creation	Always
Display Animation	193	C1	⊥	Byte[3]	None	Never
Delete Animation	199	C7		Byte	None	Always
Start/Stop Animation	194	C2	⊤	Byte[2]	None	Never
Set Animation Frame	197	C5	+	Byte[2]	None	Never
Get Animation Frame	196	C4	–	Byte	Byte	Never

Table 52: General Purpose Output Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
General Purpose Output On	86	56	V	Byte	None	Never
General Purpose Output Off	87	57	W	Byte	None	Never
Set Start Up GPO State	195	C3	⊤	Byte[2]	None	Always

Table 53: Piezo Buzzer Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Activate Piezo Buzzer	187	BB	⊤	Word[2]	None	Never
Set Default Buzzer Beep	188	BC	⊤	Word[2]	None	Remember On
*Set Touch Buzzer Beep	182	B6		Word[2]	None	Remember On
*Set Touch Buzzer Beep	182	B6		Word[2]	None	Remember On



Table 54: Keypad Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Auto Transmit Key Presses On	65	41	A	None	None	Remember On
Auto Transmit Key Presses Off	79	4F	`	None	None	Remember On
Poll Key Press	38	26	&	None	Byte	Never
Clear Key Buffer	69	45	E	None	None	Never
Set Debounce Time	85	55	U	Byte	None	Remember On
Auto Repeat Mode Off	96	60	`	None	None	Remember On
Assign Keypad Codes	213	D5	ƒ	Byte[25], Byte[25]	None	Always
Set Typematic Delay	159	9F	f	Byte	None	Remember On
Set Typematic Interval	158	9E	Pts	Byte	None	Remember On

Table 55: Touchpad Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Set Touch Mode	135	87	ç	Byte	None	Remember On
Set Region Reporting Mode	136	88	ê	Byte	None	Remember On
Set Touch Region	132	84	ä	Byte[7]	None	Remember On
Delete a Touch Region	133	85	à	Byte	None	Remember On
Delete All Touch Regions	134	86		None	None	Remember On
Create a Slider	186	BA	„	Byte[7], Word[2]	None	Remember On
Delete a Slider	189	BD	„	Byte	None	Always
Delete All Sliders	190	BE	„	None	None	Always
Set Dragging Threshold	137	89	ë	Byte	None	Remember On
Set Pressure Threshold	138	8A	è	Word	None	Remember On
Run Touchpad Calibration	139	8B	ï	None	Byte[2]	Always

Table 56: Display Functions Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Backlight On	66	42	B	Byte	None	Remember On
Backlight Off	70	46	F	None	None	Remember On
Set Brightness	153	99	Ö	Byte	None	Remember On
Set and Save Brightness	152	98	ÿ	Byte	None	Always
Set Backlight Colour	130	82	é	Byte[3]	None	Remember On
Set Contrast	80	50	P	Byte	None	Remember On
Set and Save Contrast	145	91	æ	Byte	None	Always

Table 57: Scripting Functions Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Upload a Script File	92 2	5C 02	\ stx	Word, Double, Byte[]	None	Always
*Set Scripted Button	70	46	Ä	Byte[3], Word[2], Byte, Word[2]	None	Remember On
*Set Scripted Key	142	8E	Ä	Byte[3], Word[2]	None	Remember On
Run Script File	153	99	]	Word	None	Never



Table 58: Filesystem Command Summary

Table 59: Data Security Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Set Remember	147	93	ô	Byte	None	Always
Set Data Lock	202, 245, 160	CA, F5, A0	�, , á	Byte	None	Remember On
Set and Save Data Lock	203, 245, 160	CB, F5, A0	�, , á	Byte	None	Always

Table 60: Miscellaneous Command Summary

Name	Dec	Hex	ASCII	Parameters	Response	Remembered
Write Customer Data	52	34	4	Byte[16]	None	Always
Read Customer Data	53	35	5	None	Byte[16]	Never
Read Version Number	54	36	6	None	Byte	Never
Read Module Type	55	37	7	None	Byte	Never
Read Screen	184	B8	1	None	Byte[]	Never
Write to Scratchpad	204	CC	¶	Byte, Word, Byte[]	None	Never
Read from Scratchpad	205	CD	=	Byte, Word	Byte[]	Never



## 7.1 Block Diagram




Figure 17: Functional Diagram

## 7.2 Data Types

The following table outlines native data types in common programming languages that can be used to represent the data types used in this manual.

Table 61: Data Types with Representations

	ANSI C/C++	C#	Visual Basic
Byte	unsigned char	byte	Byte
Signed Byte	signed char	sbyte	SByte
Short	unsigned short	ushort	UShort
Signed Short	short	short	Short
Integer	unsigned int	uint	UInteger
Signed Integer	int	int	Integer
String	string	string	String

Table 62: Data Type Descriptions

<b>Byte</b>	Unsigned 8 bit data type that can represent a value from 0 to 255.
<b>Signed Byte</b>	Signed 8 bit data type that can represent a value from -128 to 127.
<b>Short*</b>	Unsigned 16 bit data type can represent values from 0 to 65,536.
<b>Signed Short*</b>	Signed 16 bit data type that can represent values from -32,768 to 32,767.
<b>Integer *</b>	Unsigned 32 bit data type that can represent values from 0 to 4,294,967,295.
<b>Signed Integer*</b>	Signed 32 bit data type that can represent values of -2,147,483,648 to 2,147,483.
<b>String</b>	Strings are a multiple character bytes terminated by a single null byte. The ASCII character set is used by default, but Unicode or UTF-8 strings may be used where specifically outlined.

**\*Note:** Transmission of multiple byte values follows little endian order.



## 7.3 Environmental Specifications

Table 63: Environmental Limits

	Standard	*Extended (-E)
<b>Operating Temperature</b>	0°C to +50°C	-20°C to +70°C
<b>Storage Temperature</b>	-10°C to +60°C	-30°C to +80°C
<b>Operating Relative Humidity</b>	Maximum 90% non-condensing	

**\*Note:** The Extended Temperature option is not available for any variant of the GLT12232A-SM.

## 7.4 Electrical Tolerances

### Current Consumption

Table 64: Current Consumption

<b>Board</b> 65 mA	+	<b>Backlight</b> 30mA - 46mA	+	<b>GPOs</b> 3mA each maximum	+	<b>Piezo</b> 92mA
-----------------------	---	---------------------------------	---	---------------------------------	---	----------------------

Table 65: Backlight Current Draw

GW & WB	TCI
30mA	46mA

### Input Voltage Specifications

Table 66: Voltage Specifications

-LV	-VS
3.3V	4.75-15V

## 7.1 Optical Characteristics

Table 67: Display Optics

<b>Module Size</b>	86.10 x 35.10 x 21.92	mm
<b>Viewing Area</b>	60.2 x 18.0	mm
<b>Active Area</b>	53.64 x 15.64	mm
<b>Pixel Size</b>	0.40 x 0.45	mm
<b>Pixel Pitch</b>	0.44 x 0.49	mm
<b>Viewing Direction</b>	6	O'clock
<b>Viewing Angle</b>	-30 to +30	°
<b>Contrast Ratio</b>	3	
<b>Backlight Half-Life</b>	20,000	Hours



## 7.2 Dimensional Drawings




Figure 18: Standard Model Dimensional Drawing






Figure 19: USB Model Dimensional Drawing

## 8 Ordering

### 8.1 Part Numbering Scheme

Table 68: Part Numbering Scheme

GLT	-12232	A		-SM	-USB	-TCI	-VS	
1	2	3	4	5	6	7	8	9

### 8.2 Options

Table 69: Display Options

#	Designator	Options
1	Product Type	GLK: Graphic Liquid Crystal Display with Keypad Input GLT: Graphic Liquid Crystal Display with Touchpad Input
2	Display Size	-12232: 122 pixel columns by 32 rows
3	Display Style	A: A Display Style
4	Keypad Size	*NP: No keypad -25: 25 key maximum
5	Form Factor	-SM: Small Form Factor
6	Protocol	*NP: Standard Model -USB: USB Only Model
7	Colour	-GW: Grey Text with White Background -WB: White Text with Blue Background -TCI: Tricolour Text with Black Background
8	Voltage	-LV: Low Voltage Power Supply -VS: Super Wide Voltage Power Supply
9	Temperature	*NP: Standard **-E: Extended Temperature

**\*Note:** NP means No Populate; skip this designator in the part number and move to the next option.

**\*\*Note:** Extended Temperature is available for keypad input units only; -E is not available for GLT models.



## 8.3 Accessories

### Power

Table 70: Power Accessories

PCS	Standard Power Cable	
-----	----------------------	---

### Communication

Table 71: Communication Accessories

EXT4PUSB3FT	External 4pin USB Cable	
ESCCPC5V	Extended Serial Communication/5V Power Cable	
BBC	Breadboard Cable	

### Peripherals

Table 72: Peripheral Accessories

KPP4x4	16 Button Keypad	
--------	------------------	---



## 9 Definitions

ASCII: American standard code for information interchange used to give standardized numeric codes to alphanumeric characters.

BPS: Bits per second, a measure of transmission speed.

FFSTN: Double film super-twisted nematic in reference to an LCD. The addition of two layers of film between the STN display and polarizer improves contrast.

GPO: General purpose output, used to control peripheral devices from a display.

GUI: Graphical user interface.

Hexadecimal: A base 16 number system utilizing symbols 0 through F to represent the values 0-15.

I<sup>2</sup>C: Inter-integrated circuit protocol uses clock and data lines to communicate short distances at slow speeds from a master to up to 128 addressable slave devices. A display is a slave device.

LSB: Least significant bit or byte in a transmission, the rightmost when read.

MSB: Most significant bit or byte in a transmission, the leftmost when read.

RS232: Recommended standard 232, a common serial protocol. A low level is -30V, a high is +30V.

SDA: Serial data line used to transfer data in I<sup>2</sup>C protocol. This open drain line should be pulled high through a resistor. Nominal values are between 1K and 10K Ω.

SCL: Serial clock line used to designate data bits in I<sup>2</sup>C protocol. This open drain line should be pulled high through a resistor. Nominal values are between 1K and 10K Ω.

STN: Super-twisted nematic in reference to an LCD. In a relaxed or nematic state, crystals orientate themselves in the same direction and allow light to pass. In an excited state these crystals align to block light. Super-twisted crystals move from 180 to 270 degrees providing greater contrast than TN models.

TTL: Transistor-transistor logic applied to serial protocol. Low level is 0V while high logic is 5V.

## 10 Contact

### Sales

Phone: 403.229.2737

Email: [sales@matrixorbital.ca](mailto:sales@matrixorbital.ca)

### Support

Phone: 403.204.3750

Email: [support@matrixorbital.ca](mailto:support@matrixorbital.ca)

### Online

Purchasing: [www.matrixorbital.com](http://www.matrixorbital.com)

Support: [www.matrixorbital.ca](http://www.matrixorbital.ca)



# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

## Matrix Orbital:

[GLK12232A-25-SM-TCI-LV](#) [GLK12232A-25-SM-WB-LV](#) [GLK12232A-25-SM-USB-GW-VS](#) [GLK12232A-25-SM-TCI-VS](#) [GLK12232A-25-SM-USB-TCI-VS](#) [GLK12232A-25-SM-GW-LV-E](#) [GLK12232A-25-SM-GW-VS](#) [GLK12232A-25-SM-USB-GW-VS-E](#) [GLK12232A-25-SM-USB-WB-VS](#) [GLK12232A-25-SM-USB-TCI-VS-E](#) [GLK12232A-25-SM-GW-LV](#) [GLK12232A-25-SM-USB-WB-VS-E](#) [GLK12232A-25-SM-WB-LV-E](#) [GLK12232A-25-SM-TCI-LV-E](#) [GLK12232A-25-SM-WB-VS-E](#) [GLK12232A-25-SM-TCI-VS-E](#) [GLK12232A-25-SM-WB-VS](#) [GLK12232A-25-SM-GW-VS-E](#)