

### Document information

Info	Content
<b>Keywords</b>	LPCXpresso, LPC800, LPC1100, LPC1200, LPC1300, LPC1700, LPC1800, LPC2000, LPC2900, LPC3000, LPC3100, LPC3200, LPC4000, LPC4300
<b>Abstract</b>	LPCXpresso is a, low-cost development platform available from NXP. This document is a brief overview on how to get started with LPCXpresso.

## Revision history

Rev	Date	Description
12	20130417	<ul style="list-style-type: none"> <li>Added LPC800</li> <li>Added schematics for LPC800 and LPC1104 LPCXpresso boards.</li> <li>Updated screenshots to match LPCXpresso version 5</li> <li>Updated supported LPC products list.</li> </ul>
11.2	20120711	<ul style="list-style-type: none"> <li>Added system requirements for the Mac OS version.</li> <li>Updated supported LPC products list.</li> </ul>
11.1	20111201	<ul style="list-style-type: none"> <li>Updated supported LPC products list.</li> </ul>
11	20110614	<ul style="list-style-type: none"> <li>Updates for LPCXpresso 4- new screen shots</li> <li>Added 1.1 V4 new features section</li> <li>Updated comprehensive supported parts list</li> <li>Updated create new project process</li> </ul>
10	20110407	<ul style="list-style-type: none"> <li>Added Fig 45 and Fig 46.</li> </ul>
9	20110301	<ul style="list-style-type: none"> <li>Updated keywords and supported products throughout</li> <li>Updated Section 6.1</li> <li>Updated Section 6.2.5</li> <li>Updated Section 6.6.2</li> <li>Removed Fig 20</li> <li>Added Fig 41 and Fig 42</li> </ul>
8	20110211	<ul style="list-style-type: none"> <li>Updated Section 3.2</li> <li>Added Fig 38, Fig 39, Fig 40, Fig 48</li> </ul>
7	20100915	<ul style="list-style-type: none"> <li>Updated Section 3.1</li> </ul>
6	20100712	<ul style="list-style-type: none"> <li>Added 7.1 Schematics for LPCXpresso LPC1768 target side</li> <li>Added 6.1 Installing Eclipse plugins</li> </ul>
5	20100604	<ul style="list-style-type: none"> <li>Added new products supported to Introduction section: LPC2929, LPC3250</li> <li>Removed 6.1.6 Download performance</li> <li>Updated 6.4.2 Optimization section</li> </ul>
4	20100419	<ul style="list-style-type: none"> <li>Updated Fig 49</li> </ul>
3	20100315	<ul style="list-style-type: none"> <li>Updated Fig 37</li> <li>Added Fig 38</li> </ul>
2	20100311	<ul style="list-style-type: none"> <li>Updated Section 3.1</li> <li>Added Section 6.2.5</li> </ul>
1	20100111	<ul style="list-style-type: none"> <li>Initial version</li> </ul>

## Contact information

For additional information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: [salesaddresses@nxp.com](mailto:salesaddresses@nxp.com)

## 1. Introduction

---

LPCXpresso is a, low-cost development platform available from NXP. The software consists of an enhanced, Eclipse-based IDE, a GNU C compiler, linker, libraries, and an enhanced GDB debugger. The hardware consists of the LPCXpresso development board which has an LPC-Link debug interface and an NXP LPC ARM-based microcontroller target. LPCXpresso is an end-to-end solution enabling embedded engineers to develop their applications from initial evaluation to final production.

The LPCXpresso IDE, powered by Code Red Technologies (<http://lpcxpresso.code-red-tech.com>), is based on the popular Eclipse development platform and includes several LPC-specific enhancements. It is an industry-standard GNU tool-chain with an optimized C library that gives engineers all the tools necessary to develop high-quality software solutions quickly and cost-effectively. The C programming environment includes professional-level features. There is syntax coloring, source formatting, function folding, on- and offline help, and extensive project management automation.

The LPCXpresso target board, jointly developed by NXP, Code Red Technologies, and Embedded Artists (<http://www.embeddedartists.com/products/lpcxpresso/>), includes an integrated JTAG debugger (LPC-Link), so there's no need for a separate JTAG debug probe. The target portion of the board can connect to expansion boards to provide a greater variety of interfaces, and I/O devices. The on-board LPC-Link debugger provides a high-speed USB to JTAG/SWD interface to the IDE and it can be connected to other debug targets such as a customer prototype. Users can also use the LPCXpresso IDE with the Red Probe JTAG adapter from Code Red Technologies.

Supported LPC products and board part numbers on the LPCXpresso platform:

- LPC800: All part types supported
  - OM13053: LPC812
- LPC1100: All part types supported
  - OM13014: LPC11U14
  - OM13012: LPC11C24
  - OM13035: LPC1115
  - OM13047: LPC1104
- LPC1200: All part types supported
  - OM13008: LPC1227
- LPC1300: All part types supported
  - OM13045: LPC1347
- LPC1700: All part types supported
  - OM13000: LPC1769
- LPC1800: All part types supported
- LPC2000: LPC2109, LPC2109/01, LPC2134, LPC2142, LPC2362, LPC2929
- LPC3000: LPC3130, LPC3250
- LPC4000: All part types supported

LPCXpresso base board products:


- OM11083: Embedded Artists Base Board for LPCXpresso and mbed
- OM13009: Embedded Artists Motor Control Kit for LPCXpresso
- OM13016: NGX mbed-LPCXpresso baseboard

## 1.1 LPCXpresso 5 new features

- Support for Instruction Trace for Cortex-M3/M4 based MCUs implementing an Embedded Trace Buffer (ETB)
- Support for Instruction trace for Cortex-M0+ based systems implementing a Micro Trace Buffer (MTB)
- Based on Eclipse Juno and gcc 4.6.2
- New part support

For more information on LPCXpresso 5 new features visit:

<http://support.code-red-tech.com/CodeRedWiki/NewInVersion5>



## 1.2 LPCXpresso IDE

LPCXpresso's IDE is a highly integrated software development environment for NXP's LPC Microcontrollers, which includes all the tools necessary to develop high quality software solutions in a timely and cost effective fashion. LPCXpresso is based on Eclipse with many LPC specific enhancements. It also features the latest version of the industry standard GNU tool chain with a proprietary optimized C library providing professional quality tools at low cost. The LPCXpresso IDE can build an executable of any size with full code optimization and it supports a download limit of 128 kB after registration. LPCXpresso supports the full embedded product design cycle by moving beyond chip evaluation boards and supporting development on external target boards.




Fig 1. LPCXpresso IDE

### 1.3 LPCXpresso development board




Fig 2. LPCXpresso development board

## 1.4 LPC-LINK JTAG/SWD debugger

The LPCXpresso board contains a JTAG/SWD debugger called the “LPC-Link” and a target MCU. LPC-Link is equipped with a 10-pin JTAG header (highlighted on the above image) and it seamlessly connects to the target via USB (the USB interface and other debug features are provided by NXP’s ARM9 based LPC3154 MCU). Cutting the tracks between the LPC-link and the target will make the LPC-Link a stand-alone JTAG debugger. This enables the LPCXpresso platform to be connected to an external target and used to develop for a wide variety of NXP’s Cortex-M0, Cortex-M3, and ARM7/9 based applications. Currently supported microcontroller products include LPC800, LPC1100, LPC1200, LPC1300, LPC1700, LPC1800, LPC4000, LPC4300 series and specific members of the LPC2000 and LPC3000 families.

## 1.5 Integrated evaluation target

The target includes a small prototyping area and easily accessible connections for expansion. The LPCXpresso board with target can be used

- On its own for software development and benchmarking
- Connected to an off-the-shelf baseboard for rapid proof-of-concepts
- Connected to customer-designed board for a full prototype

## 1.6 LPCXpresso partners

NXP has partnered with Code Red Technologies and Embedded Artists for the LPCXpresso platform. For added flexibility and higher memory configurations, the LPCXpresso platform can easily be upgraded to include full-blown suites from Code Red Technologies and more advanced hardware kits from Embedded Artists. Please visit the LPCXpresso webpage for more information.



## 2. Evaluate, explore and develop




Fig 3. Product development stages

Users can envisage three stages from evaluation to product development. During evaluation, features and peripherals of the target MCU can be easily tested with the prototyping area and easily accessible connections on the target board. Complementing the target board are also easy-to-use example projects and a handy Getting Started guide. For rapid proof-of-concepts, users can get an off-the-shelf base board from Embedded Artists and quickly explore the next level of applications. And finally LPCXpresso users can seamlessly develop their final application by using the LPC-Link's 10-pin JTAG connector to attach any JTAG-capable custom board. This way, users can now enjoy the same user experience right from evaluation to product development.

## 3. Installation

### 3.1 System requirements

Operating System	Microsoft® Windows - XP 32-bit (SP2 or greater) Microsoft® Windows - Vista 32-bit or 64-bit Microsoft® Windows - Windows 7 32-bit or 64-bit Microsoft® Windows – Windows 8 Mac OS X 10.7.5 (Lion), and 10.8.2 (Mountain Lion) Linux - Ubuntu 9 through 12Linux - Fedora 14 and 17
System RAM	2 GB MB minimum (4 GB recommended)
Hard Disk	500+ MB of available space.
Screen/Display Adaptor	1024x768 minimum recommended
Internet Connection	High-speed internet is recommended to download and register the software

Note: LPCXpresso may install and run on other Linux distributions. However, only the distributions listed above have been tested. Desktop virtualization tools supporting a Linux or Windows guest with USB support can be used to run LPCXpresso on other computing platforms.

### 3.2 Installation process

LPCXpresso is installed into a single directory, of your choice. Multiple versions can be installed simultaneously without any issues. The installation process is to double-click the installer file after downloading. Then click “next” on the setup wizard. To install under Linux, the downloaded file should be marked as executable first using chmod +x.




Fig 4. Setup wizard




Fig 5. Setup wizard

Read the license agreement then click next. There are a number of other screens on the setup wizard, but generally the default options can be accepted. After the install, an information file will be displayed. Click "Next." Congratulations! Your LPCXpresso installation is complete!




Fig 6. Setup wizard

### 3.3 Activation

To activate your product from LPCXpresso, choose **Help->Product activation->Create serial number and Activate**. Once the wizard is open, click “Copy to clipboard” to copy the LPCXpresso serial number into the clipboard. This serial number is based on your machine’s hardware and operating system configuration, but contains no personally identifiable information. Now click the button to open the registration activation page. This should display a web form. After completing the form, you will receive an activation code via email within a few minutes. Highlight the activation code in your email program, and select Copy to place it into the Windows clipboard. Now, choose **Help->Product activation->Enter Activation code** from within LPCXpresso. Paste the product activation code into the Product activation dialog by right clicking in the Activation code field and choosing “Paste.” Then click the “OK” button. You should receive a dialog confirming acceptance of the activation code. It is also possible to complete LPCXpresso activation on a PC that is offline as long as another PC has access to the Internet. Refer to [Fig 7](#) for the process.




Fig 7. LPCXpresso activation with offline PC

## 4. Getting familiar with the LPCXpresso IDE

LPCXpresso IDE is based on the Eclipse IDE framework and many of the core features are described well in generic Eclipse documentation and in the help files found in the help menu of the product. Further documentation and pointers to useful documents are also available on the Code Red Technologies Wiki at <http://support.code-red-tech.com/CodeRedWiki>.

### 4.1 Layout of the LPCXpresso desktop

LPCXpresso's Desktop contains many windows. Each window is called a View, because it displays a particular view of data in the LPCXpresso environment. This data could be source code, hex dumps, disassembly, memory contents, or more. Views can be opened, moved, docked, and closed, and the layout of the currently displayed Views can be saved and restored. A specific configuration of Views is called a 'Perspective.' Typically, LPCXpresso operates in a single perspective under which both the code development & debug sessions operate as shown on the next page. The single perspective greatly simplifies the Eclipse environment and enhances the entire LPCXpresso experience.

All Views in the Perspective can be moved around by dragging and dropping. If a View is accidentally closed, it can be restored by selecting it from the Show View dialog. The Show View dialog can be opened from the Show View Other... option in the Window menu.




Fig 8. Show view/other menu

### 4.1.1 Single perspective (code development)




Fig 9. Single perspective (develop)

1. Project Explorer View: The 'Project Explorer' gives you a view of all the projects in your current 'Workspace'. A 'Workspace' is a collection of projects that are stored in a single Workspace Directory on your computer.
2. Editor: On the upper right is the editor which allows modification and saving of source code as well as setting breakpoints in debug mode.
3. Console and Problems Views: On the lower right are the Console and Problems Views. The Console View displays status information on compiling and debugging, as well as program output. The Problem View (available by changing tabs) shows all compiler errors and will navigate the Editor View to the error location.
4. Quick Start View: Below, the 'Quick Start' view has fast links to commonly used features. This is the best place to go to find options such as Build, Debug, and Import.

### 4.1.2 Single perspective (debug)




Fig 10. Single perspective (debug)

1. Core Register View: This shows all of the registers in the processor core. Registers that have changed from step to step are highlighted in yellow.
2. Debug View: This shows you the stack trace. In the 'stopped' state, you can click on any particular function and inspect its local variables in the Variables tab (parallel to the Registers View). Debug controls can be found on the global toolbar (at the top of the screen).
3. Editor: In here you will see the code you are executing and can step from line to line. By pressing the 'i' icon at the top of the Debug view, you can switch to stepping by assembly instruction. Clicking in the left margin will set and delete breakpoints.
4. Console View: On the lower right is the Console View. The Console View displays status information on compiling and debugging, as well as program output.
5. Quick Start View: Below, the 'Quick Start' view has fast links to commonly used features.

#### 4.1.2.1 Peripheral views

LPCXpresso includes full, annotated and interactive debug views of all the peripherals. Access to the views is found on the Peripherals View (click the Peripherals tab) behind the Project Explorer view. Each peripheral can be selected, and it is displayed in the 'Memory' view which is located behind the 'Console' view at the bottom of the LPCXpresso desktop.




Fig 11. Display of peripheral view showing selection of MRT peripheral




Fig 12. Display of memory view showing detail of MRT peripheral registers

## 4.2 Connecting the target

To begin development, the LPCXpresso can be connected to a PC using a USB 2.0 A/Mini-B cable.




Fig 13. USB 2.0 A / Mini-B cable


If you are debugging a prototype board or a target containing a different MCU, see the Appendix for a pin-out to connect the debugger section of the LPCXpresso to an external target.

## 5. Working with example projects

### 5.1 Downloading NXP sample code from the web



The LPCXpresso IDE includes several sample code bundles for various development boards. To work with these projects, select “Import project(s)” from the Quickstart panel in the lower left corner of the screen.



Next, select “Browse” from the “Project archive (zip)” section of the Import project(s) dialog.

The sample code bundles are located in the directory where the LPCXpresso IDE was installed, under .\lpcxpresso\Examples\NXP. Navigate to the sample code bundle that applies to your Target Device and select it.




Fig 16. Zip file from LPCXpresso-Support web site selected for importing

Now click the Next button and then choose which projects to import from the .zip file.




Fig 17. Import projects(s): Selecting which projects to import

Often, there will be references between projects in a .zip file so it is best to import all of them.




Fig 18. Import projects: Progress indicator

- Updates to the example code bundles can be found at <http://LPCWare.com> between releases of the LPCXpresso IDE.

## 5.2 Debugging/running 'blinky' or another project on your LPCXpresso board

In LPCXpresso, when you start to debug, your program will automatically download to the target and be programmed into flash memory.

To start debugging on your target, simply highlight the project in the Project Explorer and then in the Quickstart Panel select 'Debug 'Projectname' [Debug].




Fig 19. Debug

You may also enter debug mode by clicking the bug icon on the top LPCXpresso toolbar.




Fig 20. Bug icon

You are then presented with the debug view and toolbar and have run control over the code running on your target. The debug toolbar will pop up above the code window.




Fig 21. Debug toolbar

You can now do the following with the buttons towards the top of the 'Debug' view:




Fig 22. Debug buttons

### 5.3 Working with Instruction Trace

Instruction trace provides the ability to record and review the sequence of instructions executed on a target. LPCXpresso 5 introduces support for instruction trace via on board trace buffers. Instruction trace makes use of the Embedded Trace Buffer (ETB) on Cortex M3 and M4 parts and the Micro Trace Buffer (MTB) on the Cortex-M0+. The instruction trace which is generated at high speed can be captured in real time and stored in these on-chip buffers, so that they can be downloaded at lower speeds without the need for additional debug hardware.

For information on how to configure LPCXpresso 5 to work with Instruction Trace, please refer to the "Getting Started with Red Trace guide" that is available for download from the Code Red support website:

<http://support.code-red-tech.com/CodeRedWiki/NewInVersion5>

Please note that only the Instruction Trace part of the guide is applicable to the LPCXpresso-IDE.

## 6. LPCXpresso IDE tips and tricks

### 6.1 Installing Eclipse plugins

The LPCXpresso IDE contains many of the features of the Eclipse open-source IDE from <http://www.eclipse.org>. The browse and install plugin function is present in the help menu. To access it, choose Help -> Install New Software. This will display the Eclipse Install Software dialog which will allow browsing and installing of Eclipse plugins.

### 6.2 Debugging tips

#### 6.2.1 Debug features not enabled

All of the LPCXpresso features are context-sensitive. If features are disabled, double-check that you are navigated into a .c file in an open project on the Project Explorer View, or some menu items and toolbar buttons may be disabled. If your workspace

contains projects that create libraries such as CMSIS, please note that debug features will be disabled if you are currently editing a .c file that is part of a library project.

### 6.2.2 Error launching debug\filename.axf




Fig 23. Error starting debug

LPCXpresso checks the target chip ID against the currently selected chip ID for the project and will not start if there is not a match. Make sure that the correct NXP LPC microcontroller part is selected in LPCXpresso. The current part number is displayed in the status bar at the bottom of the LPCXpresso window. It can be changed by holding down the Ctrl key and clicking. A dialog will appear allowing selection of the correct part number.




Fig 24. Current part number




Fig 25. Selecting correct part number

### 6.2.3 Optimization issues

When optimization is enabled, it will reorder code. What this means is that the code from multiple C lines will be intermingled. In addition, assignments and initializations might be pulled out of loops so they are only executed once. Changes like these will make the code confusing to debug. Some symptoms you might see are breakpoints that only work the first time through, or seeing the debugger's current line indicator fail to advance or even move backwards when you click step. It is best to always use `-O0` for debugging. Since optimization can make such a big difference in code size and performance, it is a good idea to test your project with optimization and plan for a final build that is optimized.

### 6.2.4 Exiting debug mode and stopping debugging

To stop debug press the 'Stop' button (red square) shown in the toolbar at the top of the debug view.

### 6.2.5 Recovery of board

After playing around with the LPCXpresso board, especially when trying out new PLL settings, reconfiguring the SWDIO/SWDCLK pin functions, disabling AHBCLKCTRL bits, or trying power down modes, the board may be disabled and no longer enter debug mode. This is caused by code on the on-board flash that incorrectly disables the system clocks or the debug port soon after reset before the debugger can connect to the core. The easiest solution to this is to load a working project into LPCXpresso, ground the ISP pin (see the chip User's Manual for details) and then try to enter debug mode.

Grounding the ISP pin during reset will put the target MCU into In-System Programming (ISP) mode. It will wait for a command through the serial port or the USB port. This temporarily prevents the troublesome code in flash from starting. Although ISP is designed to enable serial and USB updates, while ISP is running, the LPCXpresso toolchain is able to connect to the Cortex core and reprogram the flash. After the flash is

reprogrammed, disconnect the ISP pin (pull it high or allow it to float) and stop debugging. Now you should be able to debug code again.

### 6.3 Datasheet browser

The LPCXpresso IDE comes with an integrated web browser that will direct viewers to the datasheet of the device. Just click on the part number in the lower right border of the LPCXpresso window to see the browser in action.




Fig 26. Integrated web browser

### 6.4 Code size

#### 6.4.1 printf

When optimizing a project for size, if you are using printf, make sure that Redlib is selected as the standard library in the Projects Properties dialog. This option can be set using the Quick Settings dropdown box in the Quick Start panel.




Fig 27. Reconfigure library setting

The printf implementation in Redlib is about half the size of the implementation in Newlib. A smaller printf library can be used in Redlib if floating point formatting strings are not used. To select this smaller library, define the symbol CR\_INTEGER\_PRINTF to the compiler (i.e. -DCR\_INTEGER\_PRINTF). To save even more space, avoid using printf or

any C standard library functions and select Redlib (none). Depending on your printf settings and code, this could free up 10K to 20K of flash memory.

#### 6.4.2 Optimization

Optimization can do a lot to save flash memory. It can be configured in the same dialog as the C standard library. Choose “Optimization” under “MCU C Compiler” in the “Tool Settings” tab. Higher levels of optimization will typically result in higher performance, but may result in larger code size. It is best to use –O0 for debugging and higher levels for Release. For best code size try –Os –mword-relocations. To further reduce code, add --gc-sections to the project linker flags. This causes the linker to remove unused functions from the compiled code. --gc-sections is enabled by default in new projects created by the project wizard. If you are working with an existing project, you may need to manually add this option to your project. --gc-sections is safe to use in both Release and Debug builds. There are many optimization options available for GCC. Visit <http://gcc.gnu.org/onlinedocs/gcc/Optimize-Options.html> to see all of them.

#### 6.5 Showing hidden views

A view is an on-screen representation of something in the IDE. A view can be source code, the project tree, or a debug window. If you accidentally close a view, you can open it again by going to the Window menu and choosing Show View and Other. It is a good idea to browse through the Show View window to see what is available.




Fig 28. Show view window

This will present a dialog allowing you to pick a view and display it.

#### 6.6 Creating a ‘skeleton’ project in a new Workspace

LPCXpresso includes several project Templates to help get started quickly.

### 6.6.1 Create a new Workspace

From the ‘File’ menu hover over ‘Switch Workspace’ and then select ‘Other...’ from the bottom of the list. You will then see the ‘Workspace Launcher’ dialog shown below.

Enter or browse to the new path for your workspace. We have called our new workspace ‘NewWorkspace’.




Fig 29. Workspace launcher

Then click on OK to re-open LPCXpresso with this new workspace selected.

### 6.6.2 Create the ‘Skeleton’ project

- If you are using a Cortex-based part, first, import the CMSIS header files for the chip family you are planning to work with. To do this, click “Import Project” and navigate to the CMSIS<version/part>.zip. The CMSIS header files are installed with LPCXpresso in C:\nxp\lpcxpresso\lpcxpresso\examples\nxp. Once this project is added to your workspace, click “Build all projects (Debug)” in the Quickstart Panel.
- Click on ‘New project...’ and select the NXP C project type for your architecture.
- Click “Next” and enter a project name. In this case we will use ‘MyProject’ then click ‘Next.’




Fig 30. Enter project name

- The next section of the dialog will ask you to specify which chip in the family you are using.




Fig 31. Enter project name

- If you are using a Cortex-based part, the next step in the wizard will ask which CMSIS project to use. CMSIS stands for Cortex Microcontroller Software Interface Standard. CMSIS defines a common way to access peripheral registers and to define interrupts. Please select the project that you imported into the workspace earlier and click Finish.




Fig 32. CMSIS selection

Congratulations! You have created your first project!





Fig 33. Project creation complete



## 7. Appendix

### 7.1 LPCXpresso target side schematics



### From LPC-LINK Side



### LPC176X Target Side




JP1 normally shorted. Can be used for current consumption measurements on U7.



(C) Embedded Artists AB  
TITLE: LPCXpresso LPC1769 rev B  
Document Number:  
Date: 2010-10-19 14:19:36 Sheet: 5/7

Fig 34. Schematic for the LPCXpresso LPC1769 target side (1 of 3)







Fig 36. Schematic for the LPCXpresso LPC1769 target side (3 of 3)

### From LPC-LINK Side



### LPC1114 Target Side


mbed	LPCXpresso
GND	GND
VIN (4.5-14V)	VIN (4.5-5.5V)
VB (battery supply)	not used
nR (reset)	PIO0_0 RESET
SP1-MOSI	PIO0_9 MOSI/SWO
SP1-MISO	PIO0_8 MISO
SP1-SCK	PIO2_11 SCK
GPIO	PIO0_2 SSEL
UART1-TX / I2C1-SDA	PIO1_7 TXD
UART1-RX / I2C1-SCL	PIO1_6 RXD
SPI2-MOSI	PIO0_7
SPI2-MISO	PIO2_0
SPI2-SCL / UART2-TX	PIO2_1
UART2-RX	PIO2_2
AIN0	PIO0_11 AD0
AIN1	PIO1_0 AD1
AIN2	PIO1_1 AD2
AIN3 / AOUT	PIO1_2 AD3
AIN4	PIO1_3 AD4/SWDO
AIN5	PIO1_4 AD5
	PIO1_5
	PIO1_8
	PIO0_6
	PIO0_6
	PIO0_10 SWCLK
	PIO3_0
	PIO3_1
	PIO3_2

### Expansion Connector (superset of mbed pinning)

LPCXpresso	mbed
GND	GND
VOUT (-3.3V out)    self powered else +3.3V Input	VOUT (3.3V out)
not used	VU (5.0V USB out)
-C J6-29	IF+
-C J6-30	IF-
-C J6-31	RD- (Ethernet)
-C J6-32	RD+ (Ethernet)
-C J6-33	TD- (Ethernet)
-C J6-34	TD+ (Ethernet)
-C J6-35	USB_DM Note wrong text in silkscreen
-C J6-36	D- (USB)
-C J6-37	USB_DP Note wrong text in silkscreen
-C J6-38	D+ (USB)
PIO0_1	CAN-RD
PIO0_3	CAN-TD
PIO0_5	I2C-SDA
PIO0_4	I2C-SCL
PIO1_9	PWMOUT0
PIO1_10	PWMOUT1
PIO1_11	PWMOUT2
PIO2_3	PWMOUT3
PIO2_4	PWMOUT4
PIO2_5	PWMOUT5
PIO2_6	
PIO2_7	
PIO2_8	
PIO2_9	
PIO2_10	
PIO2_11	
PIO3_3	
PIO3_4	
PIO3_5	
PIO3_6	
PIO3_7	
PIO3_8	
PIO3_9	
PIO3_10	
PIO3_11	
PIO3_12	
PIO3_13	
PIO3_14	
PIO3_15	
PIO3_16	
PIO3_17	
PIO3_18	
PIO3_19	
PIO3_20	
PIO3_21	
PIO3_22	
PIO3_23	
PIO3_24	
PIO3_25	
PIO3_26	
PIO3_27	
PIO3_28	
PIO3_29	
PIO3_30	
PIO3_31	
PIO3_32	
PIO3_33	
PIO3_34	
PIO3_35	
PIO3_36	
PIO3_37	
PIO3_38	
PIO3_39	
PIO3_40	
PIO3_41	
PIO3_42	
PIO3_43	
PIO3_44	
PIO3_45	
PIO3_46	
PIO3_47	
PIO3_48	
PIO3_49	
PIO3_50	
PIO3_51	
PIO3_52	
PIO3_53	
PIO3_54	
PIO3_55	
PIO3_56	
PIO3_57	
PIO3_58	
PIO3_59	
PIO3_60	
PIO3_61	
PIO3_62	
PIO3_63	
PIO3_64	
PIO3_65	
PIO3_66	
PIO3_67	
PIO3_68	
PIO3_69	
PIO3_70	
PIO3_71	
PIO3_72	
PIO3_73	
PIO3_74	
PIO3_75	
PIO3_76	
PIO3_77	
PIO3_78	
PIO3_79	
PIO3_80	
PIO3_81	
PIO3_82	
PIO3_83	
PIO3_84	
PIO3_85	
PIO3_86	
PIO3_87	
PIO3_88	
PIO3_89	
PIO3_90	
PIO3_91	
PIO3_92	
PIO3_93	
PIO3_94	
PIO3_95	
PIO3_96	
PIO3_97	
PIO3_98	
PIO3_99	
PIO3_100	
PIO3_101	
PIO3_102	
PIO3_103	
PIO3_104	
PIO3_105	
PIO3_106	
PIO3_107	
PIO3_108	
PIO3_109	
PIO3_110	
PIO3_111	
PIO3_112	
PIO3_113	
PIO3_114	
PIO3_115	
PIO3_116	
PIO3_117	
PIO3_118	
PIO3_119	
PIO3_120	
PIO3_121	
PIO3_122	
PIO3_123	
PIO3_124	
PIO3_125	
PIO3_126	
PIO3_127	
PIO3_128	
PIO3_129	
PIO3_130	
PIO3_131	
PIO3_132	
PIO3_133	
PIO3_134	
PIO3_135	
PIO3_136	
PIO3_137	
PIO3_138	
PIO3_139	
PIO3_140	
PIO3_141	
PIO3_142	
PIO3_143	
PIO3_144	
PIO3_145	
PIO3_146	
PIO3_147	
PIO3_148	
PIO3_149	
PIO3_150	
PIO3_151	
PIO3_152	
PIO3_153	
PIO3_154	
PIO3_155	
PIO3_156	
PIO3_157	
PIO3_158	
PIO3_159	
PIO3_160	
PIO3_161	
PIO3_162	
PIO3_163	
PIO3_164	
PIO3_165	
PIO3_166	
PIO3_167	
PIO3_168	
PIO3_169	
PIO3_170	
PIO3_171	
PIO3_172	
PIO3_173	
PIO3_174	
PIO3_175	
PIO3_176	
PIO3_177	
PIO3_178	
PIO3_179	
PIO3_180	
PIO3_181	
PIO3_182	
PIO3_183	
PIO3_184	
PIO3_185	
PIO3_186	
PIO3_187	
PIO3_188	
PIO3_189	
PIO3_190	
PIO3_191	
PIO3_192	
PIO3_193	
PIO3_194	
PIO3_195	
PIO3_196	
PIO3_197	
PIO3_198	
PIO3_199	
PIO3_200	
PIO3_201	
PIO3_202	
PIO3_203	
PIO3_204	
PIO3_205	
PIO3_206	
PIO3_207	
PIO3_208	
PIO3_209	
PIO3_210	
PIO3_211	
PIO3_212	
PIO3_213	
PIO3_214	
PIO3_215	
PIO3_216	
PIO3_217	
PIO3_218	
PIO3_219	
PIO3_220	
PIO3_221	
PIO3_222	
PIO3_223	
PIO3_224	
PIO3_225	
PIO3_226	
PIO3_227	
PIO3_228	
PIO3_229	
PIO3_230	
PIO3_231	
PIO3_232	
PIO3_233	
PIO3_234	
PIO3_235	
PIO3_236	
PIO3_237	
PIO3_238	
PIO3_239	
PIO3_240	
PIO3_241	
PIO3_242	
PIO3_243	
PIO3_244	
PIO3_245	
PIO3_246	
PIO3_247	
PIO3_248	
PIO3_249	
PIO3_250	
PIO3_251	
PIO3_252	
PIO3_253	
PIO3_254	
PIO3_255	
PIO3_256	
PIO3_257	
PIO3_258	
PIO3_259	
PIO3_260	
PIO3_261	
PIO3_262	
PIO3_263	
PIO3_264	
PIO3_265	
PIO3_266	
PIO3_267	
PIO3_268	
PIO3_269	
PIO3_270	
PIO3_271	
PIO3_272	
PIO3_273	
PIO3_274	
PIO3_275	
PIO3_276	
PIO3_277	
PIO3_278	
PIO3_279	
PIO3_280	
PIO3_281	
PIO3_282	
PIO3_283	
PIO3_284	
PIO3_285	
PIO3_286	
PIO3_287	
PIO3_288	
PIO3_289	
PIO3_290	
PIO3_291	
PIO3_292	
PIO3_293	
PIO3_294	
PIO3_295	
PIO3_296	
PIO3_297	
PIO3_298	
PIO3_299	
PIO3_300	
PIO3_301	
PIO3_302	
PIO3_303	
PIO3_304	
PIO3_305	
PIO3_306	
PIO3_307	
PIO3_308	
PIO3_309	
PIO3_310	
PIO3_311	
PIO3_312	
PIO3_313	
PIO3_314	
PIO3_315	
PIO3_316	
PIO3_317	
PIO3_318	
PIO3_319	
PIO3_320	
PIO3_321	
PIO3_322	
PIO3_323	
PIO3_324	
PIO3_325	
PIO3_326	
PIO3_327	
PIO3_328	
PIO3_329	
PIO3_330	
PIO3_331	
PIO3_332	
PIO3_333	
PIO3_334	
PIO3_335	
PIO3_336	
PIO3_337	
PIO3_338	
PIO3_339	
PIO3_340	
PIO3_341	
PIO3_342	
PIO3_343	
PIO3_344	
PIO3_345	
PIO3_346	
PIO3_347	
PIO3_348	
PIO3_349	
PIO3_350	
PIO3_351	
PIO3_352	
PIO3_353	
PIO3_354	
PIO3_355	
PIO3_356	
PIO3_357	
PIO3_358	
PIO3_359	
PIO3_360	
PIO3_361	
PIO3_362	
PIO3_363	
PIO3_364	
PIO3_365	
PIO3_366	
PIO3_367	
PIO3_368	
PIO3_369	
PIO3_370	
PIO3_371	
PIO3_372	
PIO3_373	
PIO3_374	
PIO3_375	
PIO3_376	
PIO3_377	
PIO3_378	
PIO3_379	
PIO3_380	
PIO3_381	
PIO3_382	
PIO3_383	
PIO3_384	
PIO3_385	
PIO3_386	
PIO3_387	
PIO3_388	
PIO3_389	
PIO3_390	
PIO3_391	
PIO3_392	
PIO3_393	
PIO3_394	
PIO3_395	
PIO3_396	
PIO3_397	
PIO3_398	
PIO3_399	
PIO3_400	
PIO3_401	
PIO3_402	
PIO3_403	
PIO3_404	
PIO3_405	
PIO3_406	
PIO3_407	
PIO3_408	
PIO3_409	
PIO3_410	
PIO3_411	
PIO3_412	
PIO3_413	
PIO3_414	
PIO3_415	
PIO3_416	
PIO3_417	
PIO3_418	
PIO3_419	
PIO3_420	
PIO3_421	
PIO3_422	
PIO3_423	
PIO3_424	
PIO3_425	
PIO3_426	
PIO3_427	
PIO3_428	
PIO3_429	
PIO3_430	
PIO3_431	
PIO3_432	
PIO3_433	
PIO3_434	
PIO3_435	
PIO3_436	
PIO3_437	
PIO3_438	
PIO3_439	
PIO3_440	
PIO3_441	
PIO3_442	
PIO3_443	
PIO3_444	
PIO3_445	
PIO3_446	
PIO3_447	
PIO3_448	
PIO3_449	
PIO3_450	
PIO3_451	
PIO3_452	
PIO3_453	
PIO3_454	
PIO3_455	
PIO3_456	
PIO3_457	
PIO3_458	
PIO3_459	
PIO3_460	
PIO3_461	
PIO3_462	
PIO3_463	
PIO3_464	
PIO3_465	
PIO3_466	
PIO3_467	
PIO3_468	
PIO3_469	
PIO3_470	
PIO3_471	
PIO3_472	
PIO3_473	
PIO3_474	
PIO3_475	
PIO3_476	
PIO3_477	
PIO3_478	
PIO3_479	
PIO3_480	
PIO3_481	
PIO3_482	
PIO3_483	
PIO3_484	
PIO3_485	
PIO3_486	
PIO3_487	
PIO3_488	
PIO3_489	
PIO3_490	
PIO3_491	

## Getting started with NXP LPCXpresso

### From LPC-LINK Side



### LPC1343 Target Side

Expansion Connector  
(superset of mbed pinning)

mbed	LPCXpresso
GND	GND
VIN (4.5-14V)	VIN (4.5-5.5V)
VB (battery supply)	not used
nR (reset)	PIO0_0 RESET
PI00_0	PIO0_9 MOSI/SWO
PI00_1	PI00_8 MISO
PI00_2	PI02_11 SCK
PI00_3	PI00_2 SSEL
PI00_4	UART1-TX / I2C1-SDA
PI00_5	UART1-RX / I2C1-SCL
PI00_6	PI00_7 SPI2-MOSI
PI00_7	PI02_0 SPI2-MISO
PI00_8	PI02_1 SPI2-SCL / UART2-TX
PI00_9	PI02_2 SPI2-RX
PI00_10	AIN0
PI00_11	PI01_11 AD0
PI00_12	AIN1
PI00_13	PI01_0 AD1
PI00_14	AIN2
PI00_15	PI01_1 AD2
PI00_16	AIN3 / AOUT
PI00_17	PI01_2 AD3 / SWDIO
PI00_18	AIN4
PI00_19	PI01_3 AD4 / SWDIO
PI00_20	PI01_4 AD5
PI00_21	PI01_5
PI00_22	PI01_8
PI00_23	PI00_6
PI00_24	PI00_10 SWCLK
PI00_25	PI00_9
PI00_26	PI00_11
PI00_27	PI00_12
PI00_28	PI00_13
PI00_29	PI00_14
PI00_30	PI00_15
PI00_31	PI00_16
PI00_32	PI00_17
PI00_33	PI00_18
PI00_34	PI00_19
PI00_35	PI00_20
PI00_36	PI00_21
PI00_37	PI00_22
PI00_38	PI00_23
PI00_39	PI00_24
PI00_40	PI00_25
PI00_41	PI00_26
PI00_42	PI00_27
PI00_43	PI00_28
PI00_44	PI00_29
PI00_45	PI00_30
PI00_46	PI00_31
PI00_47	PI00_32
PI00_48	PI00_33
PI00_49	PI00_34
PI00_50	PI00_35
PI00_51	PI00_36
PI00_52	PI00_37
PI00_53	PI00_38
PI00_54	PI00_39
PI00_55	PI00_40
PI00_56	PI00_41
PI00_57	PI00_42
PI00_58	PI00_43
PI00_59	PI00_44
PI00_60	PI00_45
PI00_61	PI00_46
PI00_62	PI00_47
PI00_63	PI00_48
PI00_64	PI00_49
PI00_65	PI00_50
PI00_66	PI00_51
PI00_67	PI00_52
PI00_68	PI00_53
PI00_69	PI00_54
PI00_70	PI00_55
PI00_71	PI00_56
PI00_72	PI00_57
PI00_73	PI00_58
PI00_74	PI00_59
PI00_75	PI00_60
PI00_76	PI00_61
PI00_77	PI00_62
PI00_78	PI00_63
PI00_79	PI00_64
PI00_80	PI00_65
PI00_81	PI00_66
PI00_82	PI00_67
PI00_83	PI00_68
PI00_84	PI00_69
PI00_85	PI00_70
PI00_86	PI00_71
PI00_87	PI00_72
PI00_88	PI00_73
PI00_89	PI00_74
PI00_90	PI00_75
PI00_91	PI00_76
PI00_92	PI00_77
PI00_93	PI00_78
PI00_94	PI00_79
PI00_95	PI00_80
PI00_96	PI00_81
PI00_97	PI00_82
PI00_98	PI00_83
PI00_99	PI00_84
PI00_100	PI00_85
PI00_101	PI00_86
PI00_102	PI00_87
PI00_103	PI00_88
PI00_104	PI00_89
PI00_105	PI00_90
PI00_106	PI00_91
PI00_107	PI00_92
PI00_108	PI00_93
PI00_109	PI00_94
PI00_110	PI00_95
PI00_111	PI00_96
PI00_112	PI00_97
PI00_113	PI00_98
PI00_114	PI00_99
PI00_115	PI00_100
PI00_116	PI00_101
PI00_117	PI00_102
PI00_118	PI00_103
PI00_119	PI00_104
PI00_120	PI00_105
PI00_121	PI00_106
PI00_122	PI00_107
PI00_123	PI00_108
PI00_124	PI00_109
PI00_125	PI00_110
PI00_126	PI00_111
PI00_127	PI00_112
PI00_128	PI00_113
PI00_129	PI00_114
PI00_130	PI00_115
PI00_131	PI00_116
PI00_132	PI00_117
PI00_133	PI00_118
PI00_134	PI00_119
PI00_135	PI00_120
PI00_136	PI00_121
PI00_137	PI00_122
PI00_138	PI00_123
PI00_139	PI00_124
PI00_140	PI00_125
PI00_141	PI00_126
PI00_142	PI00_127
PI00_143	PI00_128
PI00_144	PI00_129
PI00_145	PI00_130
PI00_146	PI00_131
PI00_147	PI00_132
PI00_148	PI00_133
PI00_149	PI00_134
PI00_150	PI00_135
PI00_151	PI00_136
PI00_152	PI00_137
PI00_153	PI00_138
PI00_154	PI00_139
PI00_155	PI00_140
PI00_156	PI00_141
PI00_157	PI00_142
PI00_158	PI00_143
PI00_159	PI00_144
PI00_160	PI00_145
PI00_161	PI00_146
PI00_162	PI00_147
PI00_163	PI00_148
PI00_164	PI00_149
PI00_165	PI00_150
PI00_166	PI00_151
PI00_167	PI00_152
PI00_168	PI00_153
PI00_169	PI00_154
PI00_170	PI00_155
PI00_171	PI00_156
PI00_172	PI00_157
PI00_173	PI00_158
PI00_174	PI00_159
PI00_175	PI00_160
PI00_176	PI00_161
PI00_177	PI00_162
PI00_178	PI00_163
PI00_179	PI00_164
PI00_180	PI00_165
PI00_181	PI00_166
PI00_182	PI00_167
PI00_183	PI00_168
PI00_184	PI00_169
PI00_185	PI00_170
PI00_186	PI00_171
PI00_187	PI00_172
PI00_188	PI00_173
PI00_189	PI00_174
PI00_190	PI00_175
PI00_191	PI00_176
PI00_192	PI00_177
PI00_193	PI00_178
PI00_194	PI00_179
PI00_195	PI00_180
PI00_196	PI00_181
PI00_197	PI00_182
PI00_198	PI00_183
PI00_199	PI00_184
PI00_200	PI00_185
PI00_201	PI00_186
PI00_202	PI00_187
PI00_203	PI00_188
PI00_204	PI00_189
PI00_205	PI00_190
PI00_206	PI00_191
PI00_207	PI00_192
PI00_208	PI00_193
PI00_209	PI00_194
PI00_210	PI00_195
PI00_211	PI00_196
PI00_212	PI00_197
PI00_213	PI00_198
PI00_214	PI00_199
PI00_215	PI00_200
PI00_216	PI00_201
PI00_217	PI00_202
PI00_218	PI00_203
PI00_219	PI00_204
PI00_220	PI00_205
PI00_221	PI00_206
PI00_222	PI00_207
PI00_223	PI00_208
PI00_224	PI00_209
PI00_225	PI00_210
PI00_226	PI00_211
PI00_227	PI00_212
PI00_228	PI00_213
PI00_229	PI00_214
PI00_230	PI00_215
PI00_231	PI00_216
PI00_232	PI00_217
PI00_233	PI00_218
PI00_234	PI00_219
PI00_235	PI00_220
PI00_236	PI00_221
PI00_237	PI00_222
PI00_238	PI00_223
PI00_239	PI00_224
PI00_240	PI00_225
PI00_241	PI00_226
PI00_242	PI00_227
PI00_243	PI00_228
PI00_244	PI00_229
PI00_245	PI00_230
PI00_246	PI00_231
PI00_247	PI00_232
PI00_248	PI00_233
PI00_249	PI00_234
PI00_250	PI00_235
PI00_251	PI00_236
PI00_252	PI00_237
PI00_253	PI00_238
PI00_254	PI00_239
PI00_255	PI00_240
PI00_256	PI00_241
PI00_257	PI00_242
PI00_258	PI00_243
PI00_259	PI00_244
PI00_260	PI00_245
PI00_261	PI00_246
PI00_262	PI00_247
PI00_263	PI00_248
PI00_264	PI00_249
PI00_265	PI00_250
PI00_266	PI00_251
PI00_267	PI00_252
PI00_268	PI00_253
PI00_269	PI00_254
PI00_270	PI00_255
PI00_271	PI00_256
PI00_272	PI00_257
PI00_273	PI00_258
PI00_274	PI00_259
PI00_275	PI00_260
PI00_276	PI00_261
PI00_277	PI00_262
PI00_278	PI00_263
PI00_279	PI00_264
PI00_280	PI00_265
PI00_281	PI00_266
PI00_282	PI00_267
PI00_283	PI00_268
PI00_284	PI00_269
PI00_285	PI00_270
PI00_286	PI00_271
PI00_287	PI00_272
PI00_288	PI00_273
PI00_289	PI00_274
PI00_290	PI00_275
PI00_291	PI00_276
PI00_292	PI00_277
PI00_293	PI00_278
PI00_294	PI00_279
PI00_295	PI00_280
PI00_296	PI00_281
PI00_297	PI00_282
PI00_298	PI00_283
PI00_299	PI00_284
PI00_300	PI00_285
PI00_301	PI00_286
PI00_302	PI00_287
PI00_303	PI00_288
PI00_304	PI00_289
PI00_305	PI00_290
PI00_306	PI00_291
PI00_307	PI00_292
PI00_308	PI00_293
PI00_309	PI00_294
PI00_310	PI00_295
PI00_311	PI00_296
PI00_312	PI00_297
PI00_313	PI00_298
PI00_314	PI00_299
PI00_315	PI00_300
PI00_316	PI00_301
PI00_317	PI00_302
PI00_318	PI00_303
PI00_319	PI00_304
PI00_320	PI00_305
PI00_321	PI00_306
PI00_322	PI00_307
PI00_323	PI00_308
PI00_324	PI00_309
PI00_325	PI00_310
PI00_326	PI00_311
PI00_327	PI00_312
PI00_328	PI00_313
PI00_329	PI00_314
PI00_330	PI00_315
PI00_331	PI00_316
PI00_332	PI00_317
PI00_333	PI00_318
PI00_334	PI00_319
PI00_335	PI00_320
PI00_336	PI00_321
PI00_337	PI00_322
PI00_338	PI00_323
PI00_339	PI00_324
PI00_340	PI00_325
PI00_341	PI00_326
PI00_342	PI00_327
PI00_343	PI00_328
PI00_344	PI00_329
PI00_345	PI00_330
PI00_346	PI00_331
PI00_347	PI00_332
PI00_348	PI00_333
PI00_349	PI00_334
PI00_350	PI00_335
PI00_351	PI00_336
PI00_352	PI00_337
PI00_353	PI00_338
PI00_354	PI00_339
PI00_355	PI00_340
PI00_356	PI00_341
PI00_357	PI00_342
PI00_358	PI00_343
PI00_359	PI00_344
PI00_360	PI00_345
PI00_361	PI00_346
PI00_362	PI00_347
PI00_363	PI00_348
PI00_364	PI00_349
PI00_365	PI00_350
PI00_366	PI00_351
PI00_367	PI00_352
PI00_368	PI00_353
PI00_369	PI00_354
PI00_370	PI00_355
PI00_371	PI00_356
PI00_372	PI00_357
PI00_373	PI00_358
PI00_374	PI00_359
PI00_375	PI00_360
PI00_376	PI00_361
PI00_377	PI00_362
PI00_378	PI00_363
PI00_379	PI00_364
PI00_380	PI00_365
PI00_381	PI00_366
PI00_382	PI00_367
PI00_383	PI00_368
PI00_384	PI00_369
PI00_385	PI00_370
PI00_386	PI00_371

## LPC11C24 Target Side

From LPC-LINK Side




Fig 39. Schematic for the LPCXpresso LPC11C24 target side (1 of 2)

mbed	LPCXpresso
GND	GND
VIN (4.5-14V)	VIN (4.5-5.5V)
VB (battery supply)	not used
nR (reset)	PIO0_0 RESET
SPI1-MOSI	PIO0_9 MOSIO/SWO
SPI1-MISO	PIO0_8 MISOO
SPI1-SCK	PIO2_11 SCK0
GPIO	PIO0_2 SSEL0
UART1-TX / I2C1-SDA	PIO1_7 TXD
UART1-RX / I2C1-SCL	PIO1_6 RXD
SPI2-MOSI	PIO0_7
SPI2-MISO	PIO2_0
SPI2-SCL / UART2-TX	PIO2_1
UART2-RX	PIO2_2
AIN0	PIO0_11 AD0
AIN1	PIO1_0 AD1
AIN2	PIO1_1 AD2
AIN3 / AOUT	PIO1_2 AD3
AIN4	PIO1_3 AD4/SWdio
AIN5	PIO1_4 AD5
	PIO1_5
	PIO1_6
	PIO1_7
	PIO1_8
	PIO0_6
	PIO0_10 SWCLK
	PIO3_0
	PIO3_1
	PIO3_2




Fig 40. Schematic for the LPCXpresso LPC11C24 target side (2 of 2)

NXP Semiconductors

TITLE: LPCXpresso LPC1200 rev

Document Number:

Date: not saved!


---

Digitized by srujanika@gmail.com

Digitized by srujanika@gmail.com

### From LPC-LINK Side

LPC1200 Target Side



J7 normally shorted. Can be used for current consumption measurements on U8.





Fig 41. Schematic for the LPCXpresso LPC1200 target side (1 of 2)



## Getting started with NXP LPCXpresso





Fig 43. Schematic for the LPCXpresso LPC11U14 target side (1 of 2)

mbed	LPCXpresso
GND	GND
VIN (4.5-14V)	VIN (4.5-5.5V)
VB (battery supply)	not used
nR (reset)	PIO0_0 RESET
SPI1-MOSI	PIO0_9 MOSIO/SWO
SPI1-MISO	PIO0_8 MISO0
SPI1-SCK	PIO1_29 SCK0
GPIO	PIO0_2 SSEL0
UART1-TX / I2C1-SDA	PIO0_19 TXD
UART1-RX / I2C1-SCL	PIO0_18 RXD
SPI2-MOSI	PIO0_7
SPI2-MISO	PIO1_19
SPI2-SCL / UART2-TX	PIO1_20
UART2-RX	PIO1_21
AIN0	PIO0_11 AD0
AIN1	PIO0_12 AD1
AIN2	PIO0_13 AD2
AIN3 / AOUT	PIO0_14 AD3
AIN4	PIO0_15 AD4/SWDIO
AIN5	PIO0_16 AD5
	PIO0_17
	PIO0_20
	PIO0_6 USB_SOFT_CONN
	PIO0_10 SWCLK
	PIO1_13
	PIO1_14
	PIO1_15



(C) Embedded Artists AB  
 TITLE: LPCXpresso LPC11U14 rev A  
 Document Number: REV:  
 Date: 2012-08-21 09:37:59 Sheet: 6/6

Fig 44. Schematic for the LPCXpresso LPC11U14 target side (2 of 2)

Getting started with NXP LPCpresso





Fig 45. Schematic for the LPCXpresso LPC1104 target side (1 of 2)



NXP Semiconductors

TITLE: LPCXpresso LPC1104 Rev A

Document Number:

REU#:

Date: 8/14/2012 1:15:56 PM Sheet: 6/6

Fig 46. Schematic for the LPCXpresso LPC1104 target side (2 of 2)

## Getting started with NXP LPCXpresso





Fig 47. Schematic for the LPCXpresso LPC800 target side



**Fig 48. Dimensioned drawing of LPCXpresso**

## 7.2 LPCXpresso PCB pinout and dimensions

The schematics of the LPCXpresso Target and the LPC-LINK debug connector appear in [Fig 34](#) to [Fig 47](#). The LPCXpresso board was designed to be pin compatible with NXP mbed. LPCXpresso can be powered either through the debug mini-USB port, by 3.3 V applied to the board, or by 5 V applied to the USB connector. A cable for the 10-pin mini JTAG connector on the LPC-LINK debugger portion of LPCXpresso can be purchased from Digi-Key, part number FFSD-05-D-06.00-01-N.

Dimensions: A dimensioned drawing of LPCXpresso can be found in [Fig 48](#). The outer dimensions of LPCXpresso are 1.35x5.45 inches. It contains two rows of holes 900 mil apart. Each row has 27 connections and holes are drilled at a 100 mil pitch.





Fig 49. LPCXpresso LPC-LINK JTAG/SWO pinout

## 7.3 Terminology

### LPCXpresso

The Code Red Technologies IDE (Integrated Development Environment) based on Eclipse with our own extensions for embedded development.

### SWD

Serial Wire Debugging (Single Wire Debugging). This is a debug connection technology available on the Cortex-M3 that allows debug through just 2-wires unlike 5 for JTAG.

### ELF (Executable and Linking Format)

This is the object code file format used by our development tool chain and most microprocessor tool chains.

### Workspace

LPCXpresso organizes groups of projects into a 'Workspace'. A workspace is stored as a directory on your host PC and has subdirectories containing individual projects.

### Project

An LPCXpresso project. A project contains all of the .c and .h files to build a single microcontroller flash image.

### Perspective

In LPCXpresso, a perspective is a particular collection of 'Views' that are grouped together to be suitable for a particular use. For example the 'C/C++ programming' perspective and the 'Debug' perspective.

### View

A 'View' is a window in LPCXpresso that shows a particular file or activity. A view could be of a C source code file or something live such as a disassembly window or register dump. A 'Perspective' is the layout of many 'Views'.

### Semi-hosting

The ability to use IO on your debugger host system for your target embedded system. For example a 'printf' will appear in the console window of the debugger.

### Debug Target

The system being debugged. LPCXpresso includes a target microcontroller on-board, but can also be connected to external targets.

### Redlib™

The optimized Code Red Technologies C runtime library (non-GNU). LPCXpresso includes both Redlib and Newlib libraries.

## 8. References

---

- [1] NXP LPCXpresso <http://www.nxp.com/lpcxpresso>
- [2] NXP LPCZone <http://www.nxp.com/lpczone>
- [3] NXP Microcontrollers <http://www.nxp.com/microcontrollers>
- [4] Code Red Technologies Wiki <http://lpcxpresso.code-red-tech.com/LPCXpresso/softwareknowledgebase>
- [5] Code Red Technologies LPCXpresso page <http://lpcxpresso.code-red-tech.com>
- [6] Embedded Artists AB <http://www.embeddedartists.com>
- [7] Harbison, S.P. & Steele, G.L. (2002). C: A Reference Manual (5<sup>th</sup> Edition). Prentice Hall.
- [8] Yiu, J. (2007). *The Definitive Guide to the ARM Cortex-M3*. Oxford, UK: Newnes.
- [9] Yiu, J. (2011). *The Definitive Guide to the ARM Cortex-M0*. Oxford, UK: Newnes.
- [10] ARM Cortex-M3 Technical Reference Manual. Revision: r2p0. (ARM DDI 0337G). <http://infocenter.arm.com/help/index.jsp>
- [11] ARM Cortex-M0 Technical Reference Manual. Revision: r1p0. (ARM DDI 0413D). <http://infocenter.arm.com/help/index.jsp>
- [12] ARMv7-M Architecture Reference Manual (ARM DDI 0403) <http://infocenter.arm.com/help/index.jsp>
- [13] ARMv6-M Architecture Reference Manual (Cortex-M0/LPC11) <http://infocenter.arm.com/help/index.jsp>

## 9. Legal information

### 9.1 Definitions

**Draft** — The document is a draft version only. The content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included herein and shall have no liability for the consequences of use of such information.

### 9.2 Disclaimers

**Limited warranty and liability** — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. NXP Semiconductors takes no responsibility for the content in this document if provided by an information source outside of NXP Semiconductors.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

**Right to make changes** — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

**Suitability for use** — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors and its suppliers accept no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

**Applications** — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

**Export control** — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

**Evaluation products** — This product is provided on an "as is" and "with all faults" basis for evaluation purposes only. NXP Semiconductors, its affiliates and their suppliers expressly disclaim all warranties, whether express, implied or statutory, including but not limited to the implied warranties of non-infringement, merchantability and fitness for a particular purpose. The entire risk as to the quality, or arising out of the use or performance, of this product remains with customer.

In no event shall NXP Semiconductors, its affiliates or their suppliers be liable to customer for any special, indirect, consequential, punitive or incidental damages (including without limitation damages for loss of business, business interruption, loss of use, loss of data or information, and the like) arising out the use of or inability to use the product, whether or not based on tort (including negligence), strict liability, breach of contract, breach of warranty or any other theory, even if advised of the possibility of such damages.

Notwithstanding any damages that customer might incur for any reason whatsoever (including without limitation, all damages referenced above and all direct or general damages), the entire liability of NXP Semiconductors, its affiliates and their suppliers and customer's exclusive remedy for all of the foregoing shall be limited to actual damages incurred by customer based on reasonable reliance up to the greater of the amount actually paid by customer for the product or five dollars (US\$5.00). The foregoing limitations, exclusions and disclaimers shall apply to the maximum extent permitted by applicable law, even if any remedy fails of its essential purpose.

### 9.3 Trademarks

Notice: All referenced brands, product names, service names and trademarks are property of their respective owners.

## 10. Contents

---

<b>1. Introduction .....</b>	<b>3</b>	<b>9. Legal information .....</b>	<b>48</b>
1.1 LPCXpresso 5 new features.....	4	9.1 Definitions.....	48
1.2 LPCXpresso IDE .....	4	9.2 Disclaimers.....	48
1.3 LPCXpresso development board .....	5	9.3 Trademarks .....	48
1.4 LPC-LINK JTAG/SWD debugger .....	6	<b>10. Contents .....</b>	<b>49</b>
1.5 Integrated evaluation target.....	6		
1.6 LPCXpresso partners .....	6		
<b>2. Evaluate, explore and develop .....</b>	<b>7</b>		
<b>3. Installation .....</b>	<b>8</b>		
3.1 System requirements .....	8		
3.2 Installation process .....	8		
3.3 Activation.....	10		
<b>4. Getting familiar with the LPCXpresso IDE .....</b>	<b>11</b>		
4.1 Layout of the LPCXpresso desktop .....	11		
4.1.1 Single perspective (code development) .....	12		
4.1.2 Single perspective (debug).....	13		
4.2 Connecting the target.....	15		
<b>5. Working with example projects.....</b>	<b>16</b>		
5.1 Downloading NXP sample code from the web .....	16		
5.2 Debugging/running 'blinky' or another project on your LPCXpresso board .....	19		
5.3 Working with Instruction Trace .....	20		
<b>6. LPCXpresso IDE tips and tricks .....</b>	<b>20</b>		
6.1 Installing Eclipse plugins .....	20		
6.2 Debugging tips .....	20		
6.2.1 Debug features not enabled .....	20		
6.2.2 Error launching debug\filename.axf.....	21		
6.2.3 Optimization issues .....	22		
6.2.4 Exiting debug mode and stopping debugging .....	22		
6.2.5 Recovery of board.....	22		
6.3 Datasheet browser .....	23		
6.4 Code size .....	23		
6.4.1 printf .....	23		
6.4.2 Optimization .....	24		
6.5 Showing hidden views.....	24		
6.6 Creating a 'skeleton' project in a new Workspace .....	24		
6.6.1 Create a new Workspace .....	25		
6.6.2 Create the 'Skeleton' project .....	25		
<b>7. Appendix .....</b>	<b>29</b>		
7.1 LPCXpresso target side schematics .....	29		
7.2 LPCXpresso PCB pinout and dimensions .....	45		
7.3 Terminology .....	46		
<b>8. References .....</b>	<b>47</b>		

Please be aware that important notices concerning this document and the product(s) described herein have been included in the section 'Legal information'.

---

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[NXP](#):

[OM13014,598](#) [OM13012,598](#) [OM11083,598](#)