


Between Series Adapters (Continued)


Jack-Jack (Continued)

TNC Flange Mount Jack – SMA Jack




Part No. 1057841-1
M/A COM Model No. 3180-2242-00

SMA Jack – TNC Bulkhead Jack




Part No. 1057908-1
M/A-COM Model No. 3184-2240-00

SMB Jack – SMA Jack




Part No. 1060487-1
M/A-COM Model No. 5180-2240-00

SMA Jack – OSMP Jack




Part No. 1056702-1
M/A-COM Model No. 2980-2240-00

SMA Jack – SSMT or OSMT Jack




Part No. 1055694-1
M/A-COM Model No. 2380-2240-00

OSP Jack – SMA Bulkhead Jack




Part No. 1059733-1
M/A-COM Model No. 4584-2244-02

SMA 18 GHz Jack – N Series Jack




Part No. 1058651-1
M/A-COM Model No. 3680-2240-00

SMA 18 GHz Jack – N Series Flange Mount Jack




Part No. 1058653-1
M/A-COM Model No. 3680-2242-00

SMA 18 GHz Jack – N Series Bulkhead




Part No. 1058675-1
M/A-COM Model No. 3684-2240-00

OSP Jack – SMA Jack




Part No. 1059707-1
M/A-COM Model No. 4580-2240-02

SMA Jack – OSP Bulkhead Jack



Part No. 1059729-1
M/A-COM Model No. 4584-2240-02

OSP Floating Flange Mount Jack – SMA Jack



Part No. 1059731-1
M/A-COM Model No. 4584-2242-02