


Between Series Adapters (Continued)


Jack-Jack

7-16 Jack – N Series Jack




Part No. 1311206-1
M/A-COM Model No. A55P22E999X

BNC Jack – SMB Jack




Part No. 1058056-1
M/A-COM Model No. 3280-2224-00

BNC Jack – 75 ohm SMB Jack




Part No. 1311209-1
M/A-COM Model No. A57R03G999X

TNC Jack – N Series Flange Mount Jack



Part No. 1057843-1
M/A-COM Model No. 3180-2302-00

TNC Jack – BNC Jack




Part No. 1057845-1
M/A-COM Model No. 3180-2320-00

MCX Jack – SMA Jack




Part No. 1061070-1
M/A-COM Model No. 5880-2240-00

SMA Jack – N Series Jack




Part No. 1057341-1
M/A-COM Model No. 3080-2240-00

SMA Jack – N Series Flange Mount




Part No. 1057343-1
M/A-COM Model No. 3080-2242-00

SMA Jack – N Series Bulkhead Jack




Part No. 1057463-1
M/A-COM Model No. 3084-2240-00

SMA Jack – BNC Jack




Part No. 1058058-1
M/A-COM Model No. 3280-2240-00

BNC Bulkhead Jack – SMA Jack



Part No. 1058117-1
M/A-COM Model No. 3284-2240-00

TNC Jack – SMA Jack



Part No. 1057839-1
M/A-COM Model No. 3284-2240-00