


97 series solder type

how to order

Example of part number for solder type connectors is given below.



8/29/89 16.24 * 89241 16.53 * PRELSE * 10-820120/139 0001

4321

REVISIONS

ZONE	LTR	DESCRIPTION	DATE	APPROVED
—	C	(CLII) ADDED NOTE 8 ECN:22391	08/29/89 BURNSIDE	<i>m.d.</i> <i>J.B.</i>

9	SEE NOTE	SEE NOTE 1	BACK SHELL, FEMALE	
8			SCREW, BACK SHELL	
7			CONTACTS	
6			SHELL	
5			RING, COUPLING	7
4			INSERT, FRONT	
3			RING, RETAINING	
2			INSERT, REAR	
1			BACK SHELL, MALE	

UNLESS OTHERWISE SPECIFIED
LINEAR DIMENSIONS ARE IN
INCHES.
TOLERANCES: .XXX±.010,
.XX ±.03, .X ±.1,
ANGLES ±2°.
OTHER STANDARDS PER 9-3800
AND DOD-D-1000.
NOTE REF.=

SEE SHEET 2.

NOTES:

THE USE OF THIS DOCUMENT IS UNLIMITED.
HOWEVER, DOCUMENTS REFERENCED HEREON
MAY CONTAIN LIMITED RIGHTS DATA.

N/A

N/A

NEXT ASSEMBLY

000000001

01251

TAB.

COMPUTER GENERATED DRAWING.

000000001

01251

TAB.

97-3106B

A

B

C

D

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Amphenol:

[97-3106B-16S-1S](#) [97-3106B-32-414S](#) [97-3106B-32-414P](#) [97-3106B-24-2S](#) [97-3106B-24-2P](#) [97-3106B-24-7S](#) [97-3106B-24-7P](#) [97-3106B-24-5S](#) [97-3106B-24-5P](#) [97-3106B-22-19P](#) [97-3106B-22-19S](#) [97-3106B-22-14P](#) [97-3106B-22-14S](#) [97-3106B-18-1P](#) [97-3106B-18-1S](#) [97-3106B-18-8S](#) [97-3106B-18-8P](#) [97-3106B-18-4P](#) [97-3106B-18-4S](#) [97-3106B-28-21S](#) [97-3106B-28-21P](#) [97-3106B-28-11S](#) [97-3106B-28-11P](#) [97-3106B-28-15P](#) [97-3106B-28-15S](#) [97-3106B-28-16P](#) [97-3106B-28-16S](#) [97-3106B-28-10S](#) [97-3106B-28-10P](#) [97-3106B-16S-1P](#) [97-3106B-16S-8P](#) [97-3106B-16S-8S](#) [97-3106B-32-8S](#) [97-3106B-32-8P](#) [97-3106B14S1P936624](#) [97-3106B14S5P936624](#) [97-3106B181P936624](#) [97-3106B-14S\(936\)624](#) [97-3106B-16S-1P\(936\)\(624\)](#) [97-3106B-16S-8P\(936\)\(624\)](#) [97-3106B-14S-1P\(946\)](#) [97-3106B-14S-1S\(946\)](#) [97-3106B-14S-2P\(946\)](#) [97-3106B-14S-2S\(946\)](#) [97-3106B-14S-5P\(946\)](#) [97-3106B-14S-5S\(946\)](#) [97-3106B-14S-6P\(946\)](#) [97-3106B-14S-6S\(946\)](#) [97-3106B-14S-7P\(946\)](#) [97-3106B-14S-7S\(946\)](#) [97-3106B-16S-1P\(946\)](#) [97-3106B-16S-1S\(946\)](#) [97-3106B-16S-8P\(946\)](#) [97-3106B-16S-8S\(946\)](#) [97-3106B-18-10P\(946\)](#) [97-3106B-18-10S\(946\)](#) [97-3106B-18-11P\(946\)](#) [97-3106B-18-11S\(946\)](#) [97-3106B-18-12P\(946\)](#) [97-3106B-18-12S\(946\)](#) [97-3106B-18-16P\(946\)](#) [97-3106B-18-16S\(946\)](#) [97-3106B-18-19P\(946\)](#) [97-3106B-18-19S\(946\)](#) [97-3106B-18-1P\(946\)](#) [97-3106B-18-1S\(946\)](#) [97-3106B-18-4P\(946\)](#) [97-3106B-18-4S\(946\)](#) [97-3106B-18-8P\(946\)](#) [97-3106B-18-8S\(946\)](#) [97-3106B-20-15P\(946\)](#) [97-3106B-20-15S\(946\)](#) [97-3106B-20-16P\(946\)](#) [97-3106B-20-16S\(946\)](#) [97-3106B-20-27P\(946\)](#) [97-3106B-20-27S\(946\)](#) [97-3106B-20-29P\(946\)](#) [97-3106B-20-29S\(946\)](#) [97-3106B-20-4P\(946\)](#) [97-3106B-20-4S\(946\)](#) [97-3106B-20-7P\(946\)](#) [97-3106B-20-7S\(946\)](#) [97-3106B-22-14P\(946\)](#) [97-3106B-22-14S\(946\)](#) [97-3106B-22-19P\(946\)](#) [97-3106B-22-19S\(946\)](#) [97-3106B-24-11P\(946\)](#) [97-3106B-24-11S\(946\)](#) [97-3106B-24-28P\(946\)](#) [97-3106B-24-28S\(946\)](#) [97-3106B-24-2P\(946\)](#) [97-3106B-24-2S\(946\)](#) [97-3106B-24-5P\(946\)](#) [97-3106B-24-5S\(946\)](#) [97-3106B-24-7P\(946\)](#) [97-3106B-24-7S\(946\)](#) [97-3106B-28-10P\(946\)](#) [97-3106B-28-10S\(946\)](#) [97-3106B-28-11P\(946\)](#) [97-3106B-28-11S\(946\)](#)