

Tube Testing Probes

Tube Testing Probes Complete List



RB 45-N4

Part No.: 66960

Tube testing probe for the inspection of longitudinal discontinuities. Tube must have a s/D-ratio ≤ 0.15 (s/D-ratio)
Frequency: 4 Mhz

Download: [Info Sheet \(77KB\)](#)



MRB 45-N4

Part No.: 56642

Miniature tube testing probe for the inspection of longitudinal discontinuities. Tube must have a s/D-ratio ≤ 0.15 (s/D-ratio)
Frequency: 4 Mhz

Download: [Info Sheet \(84KB\)](#)



IR-SEB 10 NZ ..

Part No.: 66764

Tube testing probe without guiding rod for wall thickness measurements. Probes have a hose connection
Frequency: 10 Mhz

Download: [Info Sheet \(74KB\)](#)



IR-SEB 10 GZ ..

Part No.: 66766

Tube testing probe without guiding rod for wall thickness measurements. Probes have a hose connection.
Frequency: 10 Mhz

Download: [Info Sheet \(74KB\)](#)



IR-SEB 10 NZ DB

Part No.: 68775

Tube testing probe with guiding rod for wall thickness measurements. Probes have a hose connection. I
Frequency: 10 Mhz

Download: [Info Sheet \(68KB\)](#)



IR-SEB 10 GZ DB

Part No.: 68776

Tube testing probe with guiding rod for wall thickness measurements. Probes have a hose connection. I
Frequency: 10 Mhz

Download: [Info Sheet \(70KB\)](#)



HW 45/45 B4 NZ DB

Part No.: 69778

Double angle beam probe for the inspection of tubes and wheel set axles for circumferential discontinuities

Frequency: 4 Mhz

Download: [Info Sheet \(71KB\)](#)



HW 45/45 B4 GZ DB

Part No.: 68779

Double angle beam probe for the inspection of tubes and wheel set axles for circumferential discontinuities

Frequency: 4 Mhz

Download: [Info Sheet \(72KB\)](#)