



# 985M Low-Solids No-Clean Liquid Flux

### **Product Description**

Kester 985M flux is a low solids, no-clean flux that is specially designed for use in the electronic industry to improve effectiveness in the wave soldering of conventional circuit board assemblies. Kester 985M has been developed for excellent solderability and through-hole fill in lead free wave soldering process. The residue left behind is minimum and non-tacky so that boards are cosmetically clean as they exit the wave solder machine. The minimal amount of residue remaining after soldering is non-conductive and non-corrosive. Hence it is possible for the residue to be left on the boards without degrading the reliability of the assembly. Kester 985M is classified as ROL0 flux under J-STD-004A Type specifications.

#### **Performance Characteristics:**

- Excellent through-hole fill
- Provides good solderability on surface mount circuit boards under air wave soldering
- Minimizes micro-solderballing at connectors and CPU and bridging by providing a clean snap-off during wave soldering
- Non-corrosive, non-conductive and tackfree residues
- No surface insulation degradation
- Suitable for leaded and lead-free (SnCu and SnAgCu) alloys
- Eliminates the need and expense of cleaning
- Classified as ROL0 per J-STD-004A
- Compliant to Bellcore GR-78-CORE

# **Physical Properties**

Specific Gravity (typical): 0.805 ± 0.005

Anton Paar DMA 35 @ 25°C

Percent Solids (theoretical): 3.60

Acid Number (typical): 20.0 mg KOH/g of flux

Tested by potentiometric titration

Thinner: Kester 108-S. 4662

### **Reliability Properties**

Copper Mirror Corrosion: Low Tested to J-STD-004A, IPC-TM-650, Method 2.3.32

Corrosion Test: Low

Tested to J-STD-004A, IPC-TM-650, Method 2.6.15

Silver Chromate: Pass

Tested to J-STD-004A, IPC-TM-650, Method 2.3.33

Chloride and Bromide: None Detected Tested to J-STD-004A, IPC-TM-650, Method 2.3.35

Fluorides by Spot Test: Pass

Tested to J-STD-004A, IPC-TM-650, Method 2.3.35.1

S.I.R., IPC (typical): Pass

Tested to J-STD-004A, IPC-TM-650, Method 2.6.3.3

	<u>Blank</u>	985M PD	985M PU
Day 1	$1.3 \times 10^{10} \Omega$	$4.2 \times 10^{9} \Omega$	$7.3 \times 10^{9} \Omega$
Day 4	9.7 x 10 <sup>9</sup> Ω	$4.8 \times 10^{9} \Omega$	$1.1 \times 10^{10} \Omega$
Day 7	8.2 x 10 <sup>9</sup> Ω	5.6x 10 <sup>9</sup> Ω	1.1 x 10 <sup>10</sup> Ω

#### Electromigration, Bellcore (typical): Pass

Tested to Bellcore GR-78-CORE

	<u>Blank</u>	985M PD	985M PU
Day 4 (96h)	$4.1 \times 10^{10} \Omega$	$3.8 \times 10^{8} \Omega$	$4.4 \times 10^{9} \Omega$
Day 21(500h)	$7.8 \times 10^{10} \Omega$	5.1 x 10 <sup>9</sup> Ω	$6.8 \times 10^{10} \Omega$

# **RoHS Compliance**

This product meets the requirements of the RoHS (Restriction of Hazardous Substances) Directive, 2002/95/EC Article 4 for the stated banned substances.

# **Application Notes**

### Flux Application:

Kester 985M is specially designed for spray fluxing. Flux deposition should be 90-190  $\mu$ g of solids/cm<sup>2</sup> (600-1200  $\mu$ g of solids/in<sup>2</sup>). An air knife after the flux tank is recommended to remove excess flux from the circuit board and prevent dipping on the preheater surface.

#### **Process Considerations:**

The optimum preheat temperature for most circuit assemblies is 85-105°C (185-221°F), as measured on the top or component side of the assembly. The optimum preheat temperature for most circuit assemblies is 105-145°C (221-293°F), as measured at the bottom or component side of the assembly. It is still important to note that the optimum preheat temperature for a given assembly will depend on the circuit board design, board thickness, length of contact time with molten solder, solder wave shape, speed of solder flow and preheating time.

Dwell time in the wave is typically 2-4 seconds. The wave soldering speed should be adjusted to accomplish proper preheating and evaporate excess solvent, which could cause spattering. For best results, speeds of 0.8-1.2 m/min (2.6-3.9 ft/min) are used. The surface tension has been adjusted to help the flux form a thin film on the board surface allowing rapid solvent evaporation. The solderpot temperature is recommended to be 245-260°C (473-500°F) for Sn63Pb37 alloy and about 260-270°C (500 – 518°F), for SnCu or SnAgCu alloy. Above information is a guideline and it is advisable to note that the optimum settings for a given assembly may vary and this is dependent on the circuit board design, board thickness, components used and equipment used. A design of experiment is recommended to be done to optimize the soldering process.

#### **Flux Control:**

The complex nature of the solvent system for the flux makes it imperative that Kester 108-S or 4662 Thinner be used to replace evaporative losses. When excessive debris from circuit boards, such as board fibers and from the air line build up in the flux tank, these particulates will redeposit on the circuit boards which may create a build up of residues on probe test pins. It is, therefore, necessary to clean the tank and then replenish it with fresh flux when excessive debris accumulates in the flux tank. Incoming solderability inspection of circuit boards and components is advisable as a part of process control to maintain consistent soldering results.

Acid number is normally the most reliable method to control the flux concentration of low solids, no-clean fluxes. To check concentration, a simple acid-base titration should be used. Kester PS-20 test kit method gives a more accurate procedure than the use of auto-density controller in the determination of flux concentration. The test method is outlined as follows:

- Dispense 5 ml of Kester PS-20 test kit solution into the test tube. The test tube has a 5 ml mark on it to facilitate this measurement. Add one drop of indicator, cap the test-tube and shake. The solution will change to a pink color.
- 2. Using a dropper, a sample from the flux tank is then drawn and added to the test solution in the test tube, dropwise by counting exactly 15 drops. The dropper must be held in a *vertical* position.
- 3. Replace the stopper to the test tube and mix by shaking.
- 4. Observe the color of the solution: some turbidity may be present, and this is acceptable. If the solution is pink, proceed to Step 5. If the solution is colorless (with or without turbidity), then proceed to Step 8.
- 5. Remove the stopper and add 1 more drop of flux using the same dropper.
- 6. Replace the stopper on the test tube and mix by shaking.
- 7. Observe the color of the solution. If the solution is pink, return to Step 5. Repeat Step 5 and 6 until the solution turns clear. Refer to Table 1 for the proper value of thinner for the flux in use.

- 8. If the test solution is colorless (with or without turbidity) from Step 4, it is an indication that the flux concentration is too high. The approximate concentration and the corrective action needed can be determined as follows:
- a) Using a fresh test tube, fill with 5 ml of test solution. Add 1 drop of indicator solution. Cap the tube and shake
- b) Add 12 drops of flux with the dropper provided. Mix by shaking and observed the colour of the solution. If the solution is colorless, a supervisor should be contacted. This is an indication that the flux concentration has exceeded the recommended level. Corrective actions should be taken immediately to drain the flux and replenish it with fresh flux.
- c) Continue adding flux, one drop at a time to the test solution, mixing between each additional drop. Keep count of the total number of drops needed to change the solution from pink to colorless. Using this count, refer to Table 1 for the correct amount of thinner to add to the flux tank.

Table 1: Flux tank adjustments using Kester PS-20 Test Kit			
Titer (Number of Drops)	Corrective Action		
25	Replace flux tank with fresh tank.		
24	Attention should be given as to how well the flux is performing on the process line. The flux concentration is too low and may need to be adjusted to a higher concentration or entirely replaces with fresh flux.		
19 - 23	No corrective action is needed.		
18	Add 195 ml thinner per gallon (3.8L) of flux.		
17	Add 302 ml thinner per gallon of flux.		
16	Add 387 ml thinner per gallon of flux.		
15	Replace flux tank with fresh flux.		

### Cleaning:

Kester 985M residues are non-conductive, non-corrosive and do not require removal in most applications. If residue removal is required, call Kester Technical Support.

### Storage and Shelf Life:

Kester 985M is flammable. Store away from sources of ignition. Shelf life is 1 year from date of manufacture when handled properly and held at 10-25°C (50-77°F).

#### Health & Safety:

This product, during handling or use, may be hazardous to health or the environment. Read the Material Safety Data Sheet and warning label before using this product.

World Headquarters: 800 West Thorndale Avenue, Itasca, Illinois, 60143 USA Phone: (+1) 630-616-4000 • Email: customerservice@kester.com • Website: www.kester.com

Asia Pacific Headquarters 500 Chai Chee Lane Singapore 469024 (+65) 6449-1133 customerservice@kester.com.sg European Headquarters
G Zum Plom 5
08541 Neuensalz
Germany
(+49) 3741 4233-0
customerservice@kester-eu.com

Japanese Headquarters 20-11 Yokokawa 2-Chome Sumida-Ku Tokyo 130 Japan (+81) 3-3624-5351 jpsales@kester.com.sq